

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [PAW Patrol](#) /
- › [PAW Patrol: Sea Patrol DVD Instruction Manual](#)

## PAW Patrol D59194155D

# PAW Patrol: Sea Patrol DVD Instruction Manual

Model: D59194155D

## INTRODUCTION

---

This manual provides instructions for the proper use and care of your PAW Patrol: Sea Patrol DVD. This DVD features six aquatic adventures of the PAW Patrol team, designed for home entertainment on compatible DVD players.

nickelodeon



The DVD cover features the PAW Patrol team, including Ryder, Chase, Marshall, Skye, Rubble, Zuma, and Rocky, in their special Sea Patrol uniforms and vehicles, ready for underwater adventures.

## SETUP

---

1. **Unpack the DVD:** Carefully remove the DVD disc from its case. Hold the disc by its edges to avoid fingerprints on the playing surface.
2. **Prepare Your DVD Player:** Ensure your DVD player is connected to your television or display device according to its own instruction manual. Verify that the player is powered on and the correct input source is selected on your TV.
3. **Insert the DVD:** Open the disc tray of your DVD player. Place the PAW Patrol: Sea Patrol DVD disc into the tray with the label side facing up. Close the disc tray.
4. **Automatic Playback:** Most DVD players will automatically begin playing the disc or display a main menu once the disc is loaded.

## OPERATING INSTRUCTIONS

---

Once the DVD is loaded, use your DVD player's remote control to navigate the menus and control playback.

- **Main Menu:** From the main menu, you can typically select "Play All" to watch all episodes consecutively, or "Episode Selection" to choose specific episodes.
- **Episode List:** This DVD includes the following episodes:
  - Pups Save a Baby Octopus
  - Pups Save a Shark
  - Pups Save the Pier
  - Pirate Pups to the Rescue
  - Pups Save a Frozen Flounder
  - Pups Save a Narwhal
- **Language Selection:** This DVD offers audio in English and Spanish (note: the final two episodes may not have a Spanish audio option). Use the "Audio" or "Language" option on the DVD menu or your remote control to switch between available languages.
- **Playback Controls:** Use the standard remote control buttons for Play, Pause, Stop, Fast Forward, Rewind, and Chapter Skip.

## MAINTENANCE

---

- **Cleaning the Disc:** If the disc becomes dirty or smudged, gently wipe the playing surface (the shiny side) with a soft, lint-free cloth. Wipe from the center of the disc outwards in a straight line. Do not wipe in a circular motion, as this can cause scratches. Avoid using abrasive cleaners or solvents.
- **Storage:** Store the DVD in its original case, away from direct sunlight, extreme temperatures, and high humidity. Proper storage helps prevent scratches and warping, extending the disc's lifespan.
- **Handling:** Always handle the disc by its edges or the center hole to prevent fingerprints and scratches on the data surface.

## TROUBLESHOOTING

---

### Disc does not play or skips:

- Check if the disc is clean and free of scratches or smudges. Clean if necessary (refer to Maintenance section).
- Ensure the disc is inserted correctly into the DVD player with the label side facing up.

- Try playing another DVD to confirm the DVD player is functioning correctly.
- If the issue persists, the disc may be damaged.

**No audio or video:**

- Verify that your DVD player is properly connected to your TV and that the TV is set to the correct input source.
- Check the volume level on both your TV and DVD player.
- Ensure the audio settings on your DVD player are configured correctly.

**"Region Code Error" message:**

- This DVD is formatted for Region 1 (USA and Canada). If you are attempting to play it on a DVD player from a different region, it may not be compatible unless your player is region-free.

## SPECIFICATIONS

<b>Model Number:</b>	D59194155D
<b>ASIN:</b>	B078DDYRHR
<b>Media Format:</b>	NTSC
<b>Number of Discs:</b>	1
<b>Language:</b>	English (with Spanish audio option for most episodes)
<b>MPAA Rating:</b>	NR (Not Rated)
<b>Genre:</b>	Kids & Family/Animation
<b>Product Dimensions:</b>	0.7 x 7.5 x 5.4 inches; 2.72 ounces
<b>Release Date:</b>	March 6, 2018
<b>Studio:</b>	PARAMOUNT

## WARRANTY AND SUPPORT

DVD media typically does not come with an explicit manufacturer's warranty beyond ensuring the disc is free from manufacturing defects upon purchase. If you encounter a defective disc, please contact the retailer where you purchased the product for assistance.

For general inquiries regarding PAW Patrol products or content, you may refer to the official PAW Patrol website or contact the studio, PARAMOUNT, directly. Contact information for PARAMOUNT can typically be found on their official website or on the DVD packaging itself.