

Whistler WBU-900W

Whistler WBU-900 Wireless Digital Backup Camera User Manual

Model: WBU-900W

INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Whistler WBU-900 Wireless Digital Backup Camera. Please read this manual thoroughly before using the product to ensure proper function and safety.

The Whistler WBU-900 is a wireless digital battery-operated backup camera system designed to enhance rear view safety. It features built-in solar panels for recharging, eliminating the need for complex hard-wiring during installation.

PRODUCT OVERVIEW



Figure 1: Front view of the Whistler WBU-900 product packaging, showing the camera unit, monitor, and a car with the camera installed, emphasizing wireless installation and solar charging.




Figure 2: Side view of the Whistler WBU-900 product packaging, highlighting the "Installs in minutes!" and "NO HARD-WIRING REQUIRED!" features, with an image of the camera mounted on a license plate.

Key Features:

- Wireless Digital Transmission
- Battery Operated Camera with Built-in Solar Panels for Recharging
- Easy Installation (No hard-wiring required)
- Provides Rear View Safety

SETUP AND INSTALLATION

The Whistler WBU-900 is designed for quick and easy installation. Follow these steps to set up your backup camera system.

Step 1: Charge the Backup Camera

Before installation, fully charge the camera unit. This initial charge ensures the solar panels can maintain the battery effectively.

Your browser does not support the video tag.

Video 1: Demonstrates the initial charging process of the backup camera unit by plugging it into a standard wall outlet.

Step 2: Connect Camera and Solar Charge Modules

Connect the camera to the solar charge modules and the backplate assembly. Ensure all connections are secure.

Your browser does not support the video tag.

Video 2: Shows how to connect the camera unit to the solar charge modules and the license plate backplate assembly.

Step 3: Slide License Plate into Assembly and Attach to Vehicle

Slide your vehicle's license plate into the assembled backplate and camera unit. Then, reattach the entire assembly to your vehicle's license plate mounting area.

Your browser does not support the video tag.

Video 3: Illustrates the process of integrating the license plate with the camera assembly and mounting it onto the vehicle.

Step 4: Plug Monitor into 12V Socket Inside Vehicle

Plug the monitor into a 12V power socket (cigarette lighter) inside your vehicle. The system is now ready for use.

Your browser does not support the video tag.

Video 4: Demonstrates plugging the monitor into the vehicle's 12V accessory socket and the monitor displaying the camera feed.

OPERATING INSTRUCTIONS

Once installed, the Whistler WBU-900 operates automatically. The monitor will display the rear view when the vehicle is in reverse or when manually activated.

Monitor Controls:

- **Power Button:** Turns the monitor on/off.
- **Menu Button:** Accesses settings for brightness, contrast, and guidelines.
- **Up/Down Arrows:** Navigate menu options or adjust settings.
- **OK Button:** Confirms selections.

Using the Backup Camera:

1. Ensure the monitor is securely mounted and plugged into the 12V socket.
2. When the vehicle is placed in reverse, the monitor should automatically display the camera feed.
3. Adjust the camera angle if necessary to optimize the view.
4. Utilize the on-screen guidelines (if enabled) to assist with parking and maneuvering.

MAINTENANCE

To ensure the longevity and optimal performance of your Whistler WBU-900, follow these maintenance guidelines:

- **Camera Lens:** Regularly clean the camera lens with a soft, damp cloth to remove dirt, dust, or water spots that may obstruct the view. Avoid abrasive cleaners.
- **Solar Panels:** Keep the solar panels on the camera unit clean and free from debris to ensure efficient recharging.
- **Monitor Screen:** Clean the monitor screen with a screen-safe cleaner and a microfiber cloth.
- **Battery:** While solar panels provide continuous charging, ensure the camera receives adequate sunlight. If the vehicle is stored in a garage for extended periods, occasional manual charging via USB may be necessary.
- **Connections:** Periodically check all cable connections for tightness and signs of wear.

TROUBLESHOOTING

If you encounter issues with your Whistler WBU-900, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No image on monitor	Monitor not powered; Camera battery low; Wireless interference; Camera not paired.	Ensure monitor is securely plugged into 12V socket. Charge camera unit fully. Check for strong wireless signals. Refer to pairing instructions in the full manual (if applicable).

Problem	Possible Cause	Solution
Poor image quality	Dirty camera lens; Low light conditions; Wireless interference.	Clean camera lens. Ensure adequate lighting. Minimize other wireless devices nearby.
Camera not charging via solar	Dirty solar panels; Insufficient sunlight exposure.	Clean solar panels. Ensure camera is exposed to direct sunlight. Manually charge if stored indoors.

For further assistance, please contact Whistler Customer Support.

SPECIFICATIONS

- **Model:** WBU-900W
- **Power Source (Camera):** Battery with Solar Recharging
- **Power Source (Monitor):** 12V Vehicle Socket
- **Wireless Technology:** Digital
- **Product Dimensions:** 3 x 13 x 8.88 inches
- **Item Weight:** 1.2 pounds
- **Video Capture Resolution:** 1080p or 4K (as per product specifications, though actual output resolution may vary)
- **Color:** Black

WARRANTY INFORMATION

This refurbished product is tested and certified to look and work like new. The refurbishing process includes functionality testing, basic cleaning, inspection, and repackaging. The product ships with all relevant accessories, and may arrive in a generic box. For specific warranty details, please refer to the documentation included with your product or contact Whistler Customer Support.

CUSTOMER SUPPORT

For technical support, troubleshooting, or warranty inquiries, please visit the official Whistler website or contact their customer service department. Contact information can typically be found on the product packaging or the manufacturer's website.

Note: An activation code may be required for some units. If you encounter issues, please contact Whistler support directly.

© 2023 Whistler. All rights reserved.
Information in this manual is subject to change without notice.



Warranty Information

Consumer Warranty

For Whistler Products Purchased in the USA

Whistler Products are warranted to the original purchaser for a period determined by the product's warranty (refer to your User Guide for specific year(s) of warranty) from the date of original purchase against all defects in materials and workmanship. This limited warranty is void if the unit is abused, modified, installed improperly, or if the housing and/or serial numbers have been removed. There are no express warranties covering this product other than those set forth in this warranty. All express or implied warranties for this product are limited to the above time. Whistler is not liable for damages arising from the use, misuse, or operation of this product.

Note: Units that cannot be repaired will be replaced with the same or similar model. Replacement unit's warranty will be based on the original unit's purchase date.

Service Under Warranty

During the warranty period, defective units will be repaired without charge to the purchaser when returned with a dated store receipt to the address below. Units returned without a dated store receipt will be handled as described in section "Service Out Of Warranty."

Due to the specialized equipment necessary for testing, there are no authorized service stations for Whistler brand products other than Whistler.

When returning a unit for service, please follow these instructions:

This website uses cookies to ensure you get the best experience on our website. Details can be found in our Privacy Policy (https://www.getyourcode.com/pages/privacy-policy/)

Get it!

[pdf] Guide Warranty Catalog

Tiny Dash Cam Warranty Whistler D24RS 052303408793 0052303408793 1004697326 4fbb8d1a efe5

4210 9927 2a54e77a899f images thdstatic catalog Images 4f |||

2/27/2019 Warranty Information Whistler Group My Account My Wishlist

/pages/wishlist / ... e Http://Www.Getyourcode.Com Jump Go Recall Information

/Pages/Jump-Go- Did You Purchase A **WBU-900W** Or WS-1010 From Recall-

Information Walmart And Have Lost Your Activation Code No Problem...

lang:en score:25 filesize: 273.23 K page_count: 4 document date: 2019-02-27