Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Arzum AR1032

Arzum AR1032 Personal Blender User Manual

Model: AR1032

Product Overview

The Arzum AR1032 Personal Blender is designed for convenience and portability, allowing you to prepare your favorite shakes and smoothies quickly. It comes with two BPA-free mixing bottles (570ml and 400ml capacity) that double as portable drinking containers, complete with drinking lids for on-the-go use.



The Arzum AR1032 Personal Blender set up with fresh fruits and a prepared smoothie, highlighting its compact design and ease of use.

Important Safety Instructions

To ensure safe operation and prevent injury or damage, please read all instructions carefully before using your Arzum AR1032 Personal Blender. Keep this manual for future reference.

- Always unplug the blender from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not immerse the motor base in water or any other liquid. Clean only with a damp cloth.
- Keep hands and utensils out of the blending bottle while blending to prevent personal injury and damage to the blender.
- Never blend hot liquids, as pressure buildup can cause the bottle to burst and result in scalding.
- Ensure the blade assembly is securely tightened onto the bottle before placing it on the motor base.
- Do not operate the blender with damaged cord or plug, or after the appliance malfunctions or has been dropped or

damaged in any manner.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not overfill the blending bottle. Refer to the MAX fill line on the bottle.
- Avoid contact with moving parts.

Package Contents

Your Arzum AR1032 Personal Blender package should include the following items:

- Blender Motor Base
- 570ml BPA-Free Mixing Bottle
- 400ml BPA-Free Mixing Bottle
- Blade Assembly
- 2 x Drinking Lids



The two BPA-free mixing bottles with their respective drinking lids, ready for use or transport.





The main blender unit with one bottle attached, and a second bottle shown separately, illustrating the complete set.

Setup and Assembly

Before First Use

- Wash the mixing bottles, drinking lids, and blade assembly in warm, soapy water. Rinse thoroughly and dry.
- Wipe the motor base with a damp cloth. Do not immerse the motor base in water.

Assembling the Blender

1. Add your desired ingredients into one of the mixing bottles. Ensure ingredients do not exceed the MAX fill line.
2. Carefully screw the blade assembly onto the open end of the mixing bottle until it is securely tightened.



Attaching the blade assembly to the mixing bottle filled with ingredients.

3. Invert the assembled bottle (with blade assembly facing down) and place it onto the motor base. Align the tabs on the bottle with the slots on the base and twist clockwise until it locks into place.





Placing the assembled bottle onto the blender's motor base.

Operating Your Personal Blender

Blending

1. Ensure the mixing bottle with blade assembly is securely locked onto the motor base.
2. Plug the power cord into a standard electrical outlet (220 Volts).
3. Press and hold the power button on the front of the motor base to begin blending. The blender will operate as long as the button is pressed.
4. Release the button to stop blending. For best results, use short pulses rather than continuous operation. Do not operate continuously for more than 1 minute to prevent overheating.
5. If ingredients are not blending smoothly, release the button, remove the bottle, shake it gently, and re-attach to continue blending.

After Blending

1. Unplug the blender from the power outlet.
2. Twist the mixing bottle counter-clockwise to unlock and remove it from the motor base.
3. Carefully unscrew the blade assembly from the mixing bottle.
4. Screw one of the drinking lids onto the mixing bottle for immediate consumption or storage.



The convenient flip-top drinking lid, allowing for easy on-the-go consumption.

Care and Maintenance

Cleaning

- Always unplug the blender before cleaning.

- Wash the mixing bottles, drinking lids, and blade assembly immediately after each use to prevent food residue from drying. These parts can be washed by hand with warm, soapy water or placed on the top rack of a dishwasher.
- For the blade assembly, be cautious of the sharp blades. Use a brush to clean around the blades if necessary.
- Wipe the motor base with a clean, damp cloth. Do not use abrasive cleaners or immerse the motor base in water.
- Ensure all parts are completely dry before reassembling or storing.

Storage

- Store the blender and its components in a clean, dry place when not in use.
- Do not store anything on top of the blender.

Troubleshooting Guide

If you encounter any issues with your Arzum AR1032 Personal Blender, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; Bottle not properly assembled or locked; Power outage.	Ensure the power cord is securely plugged into a working outlet. Check that the bottle is correctly twisted and locked onto the motor base. Verify power supply.
Ingredients are not blending smoothly.	Too little liquid; Too many ingredients; Ingredients are too large or hard.	Add more liquid. Do not overfill the bottle. Cut ingredients into smaller pieces. Use pulse function to break down larger items.
Blender leaks during operation.	Blade assembly not tightened properly; Seal ring is damaged or missing.	Ensure the blade assembly is securely tightened onto the bottle. Check the rubber seal ring on the blade assembly for proper placement and condition.
Motor smells or overheats.	Continuous operation for too long; Overloading.	Do not operate the blender continuously for more than 1 minute. Allow the motor to cool down for at least 10-15 minutes between blending cycles. Reduce the amount of ingredients.

Product Specifications

Detailed specifications for the Arzum AR1032 Personal Blender:

Feature	Specification
Brand	Arzum
Model	AR1032
Power Source	Corded Electric
Voltage	220 Volts
Capacity	570ml and 400ml Mixing Bottles

Feature	Specification
Blade Material	Stainless Steel
Material Type Free	BPA Free
Controls Type	Push Button
Product Dimensions	3.54 x 5.12 x 13.78 inches (8.99 x 13.00 x 35.00 cm)
Item Weight	1.1 pounds (0.5 kg)
Manufacturer	Arzum

Warranty and Customer Support

The Arzum AR1032 Personal Blender comes with a**Limited Warranty** provided by the manufacturer, Arzum. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration of the warranty.

For technical assistance, troubleshooting beyond this guide, or warranty claims, please contact Arzum customer support. Contact information can typically be found on the manufacturer's official website or on the product packaging.

© 2025 Arzum. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B078HFLPW7

More documents and user manuals: **https://manuals.plus/**