TOTO SW3054#01

TOTO WASHLET S550e Electronic Bidet Toilet Seat User Manual

Model: SW3054#01
Brand: TOTO

Introduction

The TOTO WASHLET S550e is an advanced electronic bidet toilet seat designed to provide enhanced personal hygiene and comfort. This manual provides detailed instructions for the installation, operation, and maintenance of your WASHLET S550e to ensure optimal performance and longevity.
Key features include a continuous warm water stream, AIR-IN WONDER WAVE cleansing, automatic open and close lid, nightlight, heated seat, EWATER+ for bowl and wand cleaning, PREMIST technology, and a remote control with user memory settings.

Setup

What's Included

- Electronic bidet seat
- Mounting bracket
- Remote control with batteries (2 AA batteries included)
- Tee-connector



Figure 1: Components included with the TOTO WASHLET S550e.

What's Required

- 120V GFCI Outlet (dedicated circuit recommended)
- Tools: Screwdriver, adjustable wrench, measuring tape
- Optional: 2-inch extender (9AU321-A) and 6-inch hose (THU9090R) for difficult-to-reach fill valves or skirted toilets.




Figure 2: Essential tools and electrical requirements for installation.



Figure 3: Optional accessories for specialized installation needs.

Installation Steps

For detailed, step-by-step interactive 3D instructions, download the BILT app. This app provides visual guidance for the installation process.

Easy step-by-step interactive 3D instructions

for this product can be found in



BILT® INTELLIGENT INSTRUCTIONS

Download on the App Store

GET IT ON Google Play

Available on most iOS and Adriod Devices

DOWNLOAD THE **FREE** APP

TOTO
WASHLET

Figure 4: The BILT app offers interactive 3D installation guides.

A general overview of the installation process includes:

1. Turn off the water supply to the toilet.
2. Remove the existing toilet seat.
3. Install the mounting bracket onto the toilet bowl.
4. Connect the tee-connector to the toilet's water supply line.
5. Attach the WASHLET unit to the mounting bracket.
6. Connect the WASHLET to the tee-connector and the power outlet.
7. Turn on the water supply and check for leaks.

Your browser does not support the video tag.

Video 1: TOTO USA BILT Install Demo. This video demonstrates the installation process using the BILT app's interactive instructions.



Figure 5: The improved tee connector design for simplified installation.

Compatibility

The WASHLET S550e is designed for elongated toilet bowls. Ensure your toilet is compatible before installation.



Figure 6: Toilet bowl shape and dimension compatibility guide.

Operating Instructions

Remote Control Functions

The WASHLET S550e is operated by an illuminated touch-activated remote control. The remote allows you to customize various settings for a personalized experience.

- **Cleansing Settings:** Adjust rear and front wash, pressure, and position.
- **Pulsating & Oscillating:** Enhance cleansing with dynamic water streams.
- **Dryer:** Activate the warm air dryer.
- **Temperature Settings:** Control water, seat, and dryer temperatures.
- **User Memory:** Save up to 2 preferred user settings for quick access.

Your browser does not support the video tag.

Video 2: TOTO Bidet Seat Functionality. This video demonstrates the various functions available on the remote control.

Automatic Features

- **Auto Open/Close Lid:** The lid automatically opens and closes as you approach and depart, providing a hands-free experience.
- **Nightlight:** A gentle nightlight illuminates the bowl for convenience during nighttime use.
- **PREMIST:** Before each use, the toilet bowl is misted with water to help prevent waste from adhering.
- **EWATER+:** Electrolyzed water cleans the wand before and after each use, and mists the bowl upon departure to maintain hygiene.

Cleansing Functions

The WASHLET S550e offers a variety of cleansing options:

- **Rear Cleansing:** Standard rear wash.
- **Rear Soft Cleansing:** A gentler rear wash.
- **Front Cleansing:** Standard front wash.
- **Wide Front Cleansing:** A wider spray for front cleansing.
- **Oscillating Cleansing:** The wand moves back and forth for a broader cleaning area.
- **Pulsating Cleansing:** The water stream pulses for a massage-like effect.
- **AIR-IN WONDER WAVE:** Air is infused into each water droplet for a gentle yet effective clean.

Your browser does not support the video tag.

Video 3: Water Stream Options. This video illustrates the different cleansing spray patterns available.

Your browser does not support the video tag.

Video 4: Air-In Wonderwave Stream Technology. This video explains the technology behind the gentle, air-infused water stream.

Warm Air Dryer and Air Deodorizer

After cleansing, the integrated warm air dryer provides a comfortable drying experience. The air deodorizer helps to neutralize odors.

Your browser does not support the video tag.

Video 5: Air Deodorizer. This video demonstrates the air deodorizing function.

Your browser does not support the video tag.

Video 6: Warm Air Dryer. This video shows the warm air drying feature in action.

Maintenance

Regular cleaning and maintenance will ensure the longevity and hygienic performance of your WASHLET S550e.

- **Wand Cleaning:** The EWATER+ system automatically cleans the wand before and after each use.
- **General Cleaning:** Use a soft cloth and mild, non-abrasive cleaner. Avoid harsh chemicals that can damage surfaces. Pay attention to seams and under the unit.
- **Quick Release:** The WASHLET unit can be easily removed from the mounting bracket for thorough cleaning of the toilet bowl and seat area.



Figure 7: Design features supporting easy maintenance and hygiene.

Troubleshooting

If you encounter any issues, refer to the following common troubleshooting tips:

- **Wand Extending:** The wand extends and water runs into the toilet bowl when the self-cleaning function starts. This indicates the WASHLET is ready for use.
- **Cannot Test Spray Function:** The WASHLET features a seat sensor. To test the spray, first press the seat down until you hear the "sensor click," then cover the spray from the wand with a cup to prevent getting wet.
- **Water Pressure Too Soft:** The rear spray setting has two options: soft and strong. Press the spray function button once for a softer stream and twice for added pressure.
- **Flickering Lights:** Ensure the unit is connected to a dedicated electrical circuit. Shared circuits may cause power fluctuations.
- **Auto Lid Opening:** If the auto lid opening is too sensitive or opens when not desired (e.g., near a bathtub), this feature can be disabled via the remote control settings.

For further assistance, please contact TOTO Technical Support at1-888-295-8134 (press 4 when prompted).

Specifications

Feature	Detail
Brand	TOTO
Model Number	SW3054#01
Color	Cotton White
Material	Plastic
Style	S550E | Classic Lid
Shape	Oval (Elongated)
Product Dimensions	20.69"L x 15.06"W
Item Weight	15 Pounds
UPC	739268335332
Voltage	120 Volts
Temperature Range	86 - 104 Degrees Fahrenheit
Batteries Required	Yes (2 AA batteries included for remote)
Usage	Inside

Warranty and Support

Warranty: The TOTO WASHLET S550e comes with a Manufacturer One Year Limited Warranty. Please refer to the warranty documentation included with your product for full details.
Technical Support: For any questions or assistance, please contact TOTO Technical Support at1-888-295-8134 (press 4 when prompted). You can also visit the official TOTO USA website for additional resources and support.



Figure 8: TOTO's network of factory-trained repair and installation technicians.

© 2025 TOTO. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question