

[Manuals.plus](#) /

› [Fagor](#) /

› Fagor Combi Oven Damper Keyboard Film User Manual

Fagor APE-061, APE-101, AE-202, AE-201, AE-061, 4251391543287

Fagor Combi Oven Damper Keyboard Film User Manual

Models: APE-061, APE-101, AE-202, AE-201, AE-061

PRODUCT OVERVIEW

This manual provides essential information for the installation, maintenance, and specifications of the Fagor Keyboard Film designed for electric combi oven dampers. This film serves as a protective and functional overlay for the control panel of compatible Fagor combi oven models.

The keyboard film is a critical component for the user interface, ensuring proper function and protection of the underlying electronics.

PRODUCT IMAGE




Figure 1: Fagor Combi Oven Damper Keyboard Film. This image displays the black control panel overlay, featuring a power switch (red circle for off, vertical line for on), a section for a digital display, multiple triangular arrow buttons for navigation or selection, and a circular control knob area with adjustment indicators. The Fagor logo is prominently displayed at the bottom.

INSTALLATION (SETUP)

Proper installation of the keyboard film is crucial for its longevity and the correct operation of the combi oven's control panel. It is recommended that installation be performed by qualified personnel.

Required Tools:

- Clean, lint-free cloth

- Mild cleaning solution (non-abrasive)
- Small flat-head screwdriver (if prying is needed for old film removal)
- Adhesive remover (if residue from old film is present)

Installation Steps:

1. **Power Disconnection:** Ensure the combi oven is completely disconnected from the main power supply before beginning any work.
2. **Remove Old Film (if applicable):** Carefully peel off the existing keyboard film. If it is adhered strongly, gently warm the surface with a hairdryer on a low setting to soften the adhesive. Avoid excessive heat.
3. **Clean Surface:** Thoroughly clean the control panel surface where the new film will be applied. Use a mild cleaning solution and a lint-free cloth to remove all dirt, grease, and adhesive residue. The surface must be completely dry before proceeding.
4. **Align New Film:** Carefully align the new Fagor keyboard film with the control panel. Pay close attention to the cutouts for buttons, display, and indicators to ensure a perfect fit.
5. **Apply Film:** Starting from one edge, slowly and evenly press the film onto the control panel, smoothing out any air bubbles as you go. Use a soft, flat tool (like a credit card wrapped in a cloth) to gently press down and ensure full adhesion.
6. **Verify Fit:** Once applied, visually inspect the film to ensure it is flat, securely adhered, and that all buttons and display areas are correctly aligned and functional.
7. **Reconnect Power:** After successful installation, reconnect the oven to the power supply and test the control panel's functionality.

OPERATING CONSIDERATIONS

This keyboard film is a component of the Fagor combi oven's control panel. Its primary function is to provide a durable and responsive interface for operating the oven. The operation of the oven itself is detailed in the main oven user manual. This film ensures the tactile feedback and visual clarity of the control panel.

Ensure that the film is not punctured or damaged, as this can affect the responsiveness of the buttons and compromise the protection of the underlying electronics.

MAINTENANCE

Regular cleaning and proper care will extend the life of your Fagor keyboard film.

Cleaning Instructions:

- **Daily Cleaning:** Wipe the surface of the keyboard film with a soft, damp cloth. Use a mild, non-abrasive cleaning agent if necessary.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or strong chemical agents, as these can damage the film's surface and printed legends.
- **Drying:** Ensure the film surface is dry after cleaning to prevent water spots or residue buildup.
- **Inspection:** Periodically inspect the film for signs of wear, peeling, or damage. Early detection can prevent further issues.

TROUBLESHOOTING

This section addresses common issues related to the keyboard film itself.

Problem	Possible Cause	Solution
Buttons unresponsive or sticky	Dirt/debris under film; film not properly adhered; internal oven issue.	Clean film surface. If film is peeling, re-adhere carefully or replace. Consult oven manual for internal issues.
Film peeling or bubbling	Improper installation; exposure to extreme heat/moisture; adhesive failure.	Ensure proper installation. Avoid extreme conditions. Replacement may be necessary.
Scratches or discoloration on film	Abrasive cleaning; physical damage; prolonged exposure to sunlight/chemicals.	Use only soft cloths and mild cleaners. Protect from physical impact. Replacement is the only solution for severe damage.

For issues not related to the film itself, please refer to the main Fagor combi oven user manual or contact Fagor technical support.

SPECIFICATIONS

- Product Type:** Keyboard Film for Combi Oven Damper
- Brand:** Fagor
- Compatible Models:** APE-061, APE-101, AE-202, AE-201, AE-061
- Manufacturer Reference Number:** 4251391543287
- Application:** Electric Combi Oven Damper
- Width:** 172 mm
- Length:** 540 mm
- Material Thickness:** 1 mm

WARRANTY AND SUPPORT

Information regarding the warranty for this Fagor Keyboard Film should be obtained from your original point of purchase or directly from the manufacturer, Gastroteileshop, or Fagor. Please retain your proof of purchase for warranty claims. For technical support or spare parts inquiries, please contact the seller or the manufacturer directly. Specific contact details are typically provided with your purchase documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B078HY46TX>

More documents and user manuals: <https://manuals.plus/>