

[Manuals.plus](#) /

> [Frifri](#) /

> Frifri Fryer Oil Filter Instruction Manual for FFM31, FFS41, FFE31, FFS31, FFE41, FFM41

Frifri FFM31, FFS41, FFE31, FFS31, FFE41, FFM41

Frifri Fryer Oil Filter Instruction Manual

Models: FFM31, FFS41, FFE31, FFS31, FFE41, FFM41

INTRODUCTION

This manual provides essential instructions for the proper use, installation, and maintenance of your Frifri Fryer Oil Filter. This filter is designed to extend the life of your cooking oil by removing food particles and impurities, ensuring optimal performance of your Frifri deep fryer models FFM31, FFS41, FFE31, FFS31, FFE41, and FFM41.

SAFETY INSTRUCTIONS

- Always ensure the fryer and oil are completely cooled before handling the oil filter. Hot oil can cause severe burns.
- Do not attempt to filter oil while the fryer is operating or still hot.
- Use appropriate protective gear, such as heat-resistant gloves, when handling cooled oil and the filter.
- Keep the filter away from open flames or heat sources.
- Dispose of used oil and filters according to local regulations.

SETUP AND INSTALLATION

The Frifri fryer oil filter is designed for easy integration into compatible Frifri deep fryers. Follow these steps for proper installation:

1. **Ensure Fryer is Cool:** Before beginning, confirm that your deep fryer is completely cool and unplugged from the power source.
2. **Prepare for Filtering:** Place a suitable, heat-resistant container beneath the fryer's oil drain valve or in the designated oil collection area.
3. **Position the Filter:** Carefully place the Frifri oil filter into the designated filter housing or directly into the oil collection container, ensuring it is securely seated and ready to receive the oil. The filter is a bag-like structure designed to fit within the fryer's oil collection system.
4. **Drain Oil:** Open the fryer's oil drain valve to allow the cooled oil to flow through the filter into the collection

container.

5. **Monitor Filtering:** Allow all oil to pass through the filter. The filter will capture food debris and sediment.



Image: The Frifri fryer oil filter, a white mesh bag with a reinforced top edge, designed for filtering cooking oil. This filter is used to remove impurities from cooled oil.

OPERATING INSTRUCTIONS

The oil filter is a passive component used during the oil draining process. Its operation is straightforward:

- **Regular Filtering:** Filter your cooking oil regularly, ideally after each major use or at least daily for commercial settings, to maintain oil quality and extend its lifespan.
- **Filter Replacement:** The filter is a consumable item. Replace the filter when it becomes visibly soiled, clogged, or when oil flow through it significantly slows down. The frequency of replacement depends on the volume and type of food being fried.
- **Oil Quality:** Even with filtering, oil quality degrades over time. Monitor your oil for changes in color, smell, and foaming, and replace the oil entirely when necessary.

MAINTENANCE

This oil filter is designed for single-use or limited-use applications depending on the level of debris. It is generally not intended for cleaning and reuse.

- **Disposal:** After use, carefully remove the filter containing the filtered debris. Dispose of the used filter and its contents responsibly, following all local waste disposal guidelines for food waste and oil-soaked materials.
- **Storage:** Store new, unused filters in a clean, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Oil drains too slowly.	Filter is clogged with food particles.	Replace the filter with a new one. Ensure oil is completely cooled before filtering.
Oil still appears cloudy after filtering.	Oil is too old or heavily degraded; filter cannot remove dissolved impurities.	Replace the cooking oil entirely. The filter removes solid particles, not chemical degradation.
Filter does not fit properly.	Incorrect filter model for your fryer.	Verify your fryer model (FFM31, FFS41, FFE31, FFS31, FFE41, FFM41) against the filter's compatibility. Ensure correct orientation.

SPECIFICATIONS

Brand: Frifri

Material: Filter bag is likely a fabric mesh. (Note: Product data mentions "Stainless steel" which may refer to a component of the fryer or a filter frame, not the filter bag itself.)

Dimensions (approximate):

- Width: 190 mm
- Height: 170 mm
- Length: 280 mm

Compatibility: Frifri Deep Fryer Models FFM31, FFS41, FFE31, FFS31, FFE41, FFM41

Feature: Without handle

WARRANTY AND SUPPORT

As a consumable item, this oil filter typically does not come with a long-term warranty. For specific warranty information or support regarding your Frifri deep fryer or accessories, please refer to the documentation provided with your fryer or contact Frifri customer service directly. Ensure you have your product model number and purchase details available when seeking support.

For further assistance, please visit the official Frifri website or contact your local distributor.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B078HYZDWG>

More documents and user manuals: **<https://manuals.plus/>**