Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete 2875

Ariete 2875 Wireless Electric Kettle User Manual

Brand: Ariete | Model: 2875

1. Product Overview

The Ariete 2875 Wireless Electric Kettle is designed for quick and efficient water boiling. Its cordless design and 1.7-liter capacity make it ideal for daily use in any kitchen. Key features include a clear water level indicator, automatic shut-off, and a durable plastic construction.

- **Capacity:** 1.7 Liters (approximately 7 cups)
- **Power:** 1850 - 2200 Watts
- **Voltage:** 220 Volts
- **Material:** Durable Plastic
- **Features:** Cordless design, Automatic Shut-off, Clear Water Level Indicator



Figure 1: Front view of the Ariete 2875 Wireless Electric Kettle, showcasing its sleek white design and water level indicator.

2. Safety Instructions

Please read all safety instructions carefully before using the appliance to prevent personal injury or damage to the kettle.

- Do not immerse the kettle, power base, cord, or plug in water or any other liquid.
- Ensure the voltage indicated on the appliance matches your local mains voltage before connecting.
- Always place the kettle on a firm, flat, heat-resistant surface, away from the edge of the worktop.
- Do not operate the kettle if the cord or plug is damaged, or if the kettle malfunctions or has been damaged in any way.
- Keep the appliance out of reach of children.
- Do not fill above the 'MAX' mark or below the 'MIN' mark to prevent boiling dry or overflow.
- Always close the lid securely before operating.
- Exercise caution when pouring hot water.

3. Setup

Follow these steps for initial setup of your Ariete electric kettle:

1. **Unpacking:** Carefully remove the kettle and its power base from the packaging. Retain the packaging for future storage or transport.
2. **First Use Cleaning:** Before first use, fill the kettle with clean water up to the 'MAX' level. Boil the water, then discard it. Repeat this process two to three times to remove any manufacturing residues.
3. **Placement:** Place the power base on a stable, flat, and dry surface. Ensure the power cord is not dangling or in a position where it can be tripped over.



Figure 2: The Ariete kettle correctly placed on its cordless power base.

4. Operating Instructions

Operating your Ariete kettle is simple and straightforward:

1. **Fill the Kettle:** Press the lid release button to open the lid. Fill the kettle with the desired amount of water, ensuring it is between the 'MIN' (0.5L) and 'MAX' (1.7L) marks on the water level indicator. Close the lid firmly until it clicks.



Figure 3: The kettle with its lid open, ready for filling. Note the clear water level markings.

2. **Place on Base:** Place the filled kettle onto its power base.
3. **Power On:** Plug the power base into a suitable electrical outlet. Press the ON/OFF switch located on the handle downwards. The indicator light will illuminate, signifying that the kettle is heating.



Figure 4: A close-up view of the ergonomic handle and the power switch.

4. **Automatic Shut-off:** The kettle will automatically switch off once the water has boiled. The indicator light will turn off, and the switch will return to the UP position.
5. **Pouring:** Carefully lift the kettle from its base and pour the hot water.

6. **Re-boiling:** If you need to re-boil, wait a few moments for the automatic shut-off mechanism to reset before pressing the switch again.

5. Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your kettle.

5.1. Daily Cleaning

- Always unplug the kettle and allow it to cool completely before cleaning.
- Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- Rinse the interior of the kettle with clean water.
- The filter at the spout can be removed for cleaning by rinsing it under running water. Ensure it is properly re-inserted before use.

5.2. Descaling

Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. Descale your kettle regularly to maintain performance.

- Fill the kettle with a mixture of one part white vinegar and two parts water.
- Bring the mixture to a boil and then let it stand for at least 30 minutes, or longer for heavy scale.
- Empty the kettle and rinse thoroughly with fresh water several times.
- For stubborn deposits, gently scrub the interior with a non-abrasive brush or sponge.
- Alternatively, use a commercial descaling solution following the product's instructions.

6. Troubleshooting

If you encounter issues with your kettle, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Kettle does not heat up.	Not plugged in; Power switch not pressed; Kettle not properly seated on base; No power at outlet.	Ensure plug is fully inserted; Press the ON/OFF switch down; Re-seat kettle firmly on base; Check power outlet with another appliance.
Kettle switches off before boiling.	Too much limescale build-up; Kettle is boiling dry (insufficient water).	Descale the kettle (refer to Maintenance section); Ensure water level is above 'MIN' mark.
Water tastes strange or has particles.	New kettle residue; Limescale particles.	Perform initial cleaning (refer to Setup section); Descale the kettle.
Lid does not close properly.	Obstruction; Misalignment.	Check for any foreign objects preventing closure; Gently adjust the lid until it aligns and clicks into place.

If the problem persists after trying these solutions, please contact customer support.

7. Specifications

Brand	Ariete
Model Number	2875
Color	White
Product Dimensions	22 x 17 x 20 cm
Item Weight	750 grams
Capacity	1.7 Liters (7 cups)
Power / Electrical Power	2200 Watts
Electrical Voltage	220 Volts
Material	Plastic
Automatic Shut-off	Yes
Noise Level	44 dB
Special Features	Automatic shut-off, Water level indicator, Wireless
First Available Date	January 8, 2018



Figure 5: Dimensions of the Ariete 2875 Wireless Electric Kettle.

8. Warranty and Support

Information regarding specific warranty terms and customer support contact details is not available in the provided product data. Please refer to the product packaging or the manufacturer's official website for warranty information and support contacts.

For general inquiries or assistance, you may visit the Ariete official website or contact their customer service department.

9. Official Product Videos

No official product videos from the seller were found in the provided data for this product.

© 2024 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B078J5HSZK

More documents and user manuals: **https://manuals.plus/**