

[Manuals.plus](#) /

> [LeadsaiL](#) /

> LeadsaiL LX001 Rechargeable Wireless Computer Mouse User Manual

LeadsaiL LX001

LeadsaiL LX001 Rechargeable Wireless Computer Mouse User Manual

Model: LX001

INTRODUCTION

Thank you for choosing the LeadsaiL LX001 Rechargeable Wireless Computer Mouse. This manual provides detailed instructions for setting up, operating, and maintaining your new mouse. Designed for comfort and efficiency, this 2.4G wireless mouse offers a quiet clicking experience and adjustable sensitivity, making it ideal for various computing tasks.

WHAT'S IN THE BOX

- 1 x LeadsaiL LX001 Wireless Mouse
- 1 x Nano USB Receiver
- 1 x USB Charging Cable
- 1 x User Manual

SETUP INSTRUCTIONS

Follow these steps to quickly set up your LeadsaiL wireless mouse:

1. **Locate the Nano USB Receiver:** The USB receiver is typically stored in a compartment on the underside of the mouse for safekeeping during transport. Gently remove it.
2. **Connect the Receiver:** Insert the Nano USB receiver into an available USB port on your laptop or desktop computer.
3. **Power On the Mouse:** Flip the ON/OFF switch located on the bottom of the mouse to the 'ON' position. The mouse will automatically connect to your computer.

No additional drivers are usually required for Windows XP, Vista, 7, 8, 10, or Mac OS X 10.4 and above. The mouse is plug-and-play.

2.4Ghz & 10 Meters Wireless Wide Compatibility



**Compatible with Windows 7/8/10, Windows XP,
Windows Vista, Linux, Mac OS etc.**

Image: The LeadsaiL wireless mouse connected to a desktop computer, highlighting its 2.4GHz wireless technology and wide compatibility.

Your browser does not support the video tag.

Video: A demonstration of connecting the LeadsaiL wireless mouse to a laptop and its immediate functionality.

OPERATING INSTRUCTIONS

Your LeadsaiL LX001 mouse is designed for intuitive use. Here are some key features:

- **Silent Click:** The mouse features a silent click design, allowing you to work without disturbing others.
- **Adjustable DPI:** Cycle through 5 adjustable DPI levels (800-1200-1600-2000-2400) by pressing the DPI button located behind the scroll wheel. This allows you to customize cursor sensitivity for different tasks.
- **Scroll Wheel:** Use the scroll wheel for smooth vertical navigation (page up and down).
- **Ergonomic Design:** The slim and ergonomic design provides a comfortable grip, reducing hand fatigue

during extended use.



Silent Click

Keep you stay focused
without disturbing others



Image: The Leadsail mouse demonstrating its silent click feature, ideal for quiet environments.

Ergonomic and Symmetric Design

Experience precise cursor control and smooth movements.



Durable and Responsive Clicks

Tested over **5,000,000** times keystrokes.

Image: A hand using the LeadsaiL mouse, emphasizing its ergonomic and symmetric design for comfortable and precise control.

MAINTENANCE

To ensure the longevity and optimal performance of your LeadsaiL LX001 mouse, follow these maintenance guidelines:

- **Charging:** The mouse features a built-in rechargeable lithium battery. Connect the included USB charging cable to the mouse's charging port (located at the front) and to a USB power source (e.g., computer USB port, USB wall adapter). A full charge takes approximately 2 hours and can last up to 120 days, depending on usage.
- **Power Saving Mode:** The mouse will automatically enter sleep mode after 8 minutes of inactivity to conserve power. Click any button to wake it up.
- **Cleaning:** Use a soft, dry cloth to clean the mouse. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use, especially during travel, you can store the Nano USB receiver inside the mouse's bottom compartment. Turn off the mouse using the ON/OFF switch to save battery.

Rechargeable Wireless Mouse

Charge 1 hour and work for 2 months



Image: The LeadsaiL wireless mouse being charged via its USB cable connected to a laptop.

TROUBLESHOOTING

If you encounter any issues with your LeadsaiL LX001 mouse, try the following solutions:

- **Mouse Not Responding:**

- Ensure the mouse is turned ON.
- Check if the Nano USB receiver is securely plugged into a working USB port. Try a different USB port.
- Recharge the mouse. A low battery can cause unresponsiveness.
- Restart your computer.

- **Lagging or Jerky Cursor:**

- Ensure the mouse is within the effective range (up to 15 meters) of the USB receiver.
- Avoid using the mouse on highly reflective or uneven surfaces. A mouse pad is recommended for optimal tracking.

- Check for interference from other 2.4GHz wireless devices.
- Adjust the DPI setting to a lower level if the cursor is too sensitive.

- **Connection Issues:**

- Unplug and re-plug the USB receiver.
- Turn the mouse off and then on again.

SPECIFICATIONS

Feature	Detail
Model Number	LX001
Connectivity Technology	2.4 GHz Wireless (USB Receiver)
Movement Detection Technology	Optical
DPI Levels	5 Adjustable (800, 1200, 1600, 2000, 2400)
Special Feature	Silent Click
Power Source	Rechargeable Lithium Polymer Battery
Battery Life (Approx.)	120 days on a 2-hour charge
Operating System Compatibility	Windows XP, Vista, 7, 8, 10; Mac OS X 10.4+ (Not compatible with Type-C only ports)
Item Weight	2.56 ounces
Product Dimensions (LxWxH)	4.45 x 2.48 x 1.22 inches



Image: Technical drawing showing the dimensions of the LeadsaiL mouse and its USB receiver.

WARRANTY AND SUPPORT

LeadsaiL products are designed for durability and performance. For specific warranty information, please refer to the packaging or contact LeadsaiL customer support directly.

If you require further assistance or have questions not covered in this manual, please visit the official LeadsaiL website or contact their customer service team. Contact details can typically be found on the product packaging or the LeadsaiL brand store on Amazon.

Please retain your proof of purchase for warranty claims.

