

Corbero CCVY460

CORBERO CCVY460 Vitroceramic Hob Instruction Manual

Model: CCVY460

1. INTRODUCTION

Thank you for choosing the CORBERO CCVY460 Vitroceramic Hob. This instruction manual provides essential information for the safe and efficient installation, operation, and maintenance of your new appliance. Please read this manual thoroughly before using the hob and keep it for future reference.

2. SAFETY INFORMATION

Your safety and the safety of others are paramount. Please observe the following safety precautions:

- **Electrical Safety:** Ensure the hob is installed by a qualified electrician in accordance with local wiring regulations. Do not use adapters or extension cords. Disconnect power before cleaning or maintenance.
- **Burn Hazard:** The hob surface and surrounding areas become hot during use. Do not touch hot surfaces. Use oven mitts.
- **Children and Vulnerable Persons:** This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure they do not play with the appliance.
- **Overheating:** Do not leave cooking unattended. Overheated fats and oils can ignite.
- **Glass Surface:** Do not place hot lids on the hob surface as they may create a vacuum and damage the glass when removed. Avoid dropping heavy or sharp objects on the hob. If the hob surface is cracked, disconnect power immediately and contact service.
- **Ventilation:** Ensure adequate ventilation around the appliance as specified in the installation instructions.

3. PRODUCT OVERVIEW

The CORBERO CCVY460 is a sleek vitroceramic hob designed for efficient cooking. It features four cooking zones with touch controls.



Image 1: Top view of the CORBERO CCVY460 Vitroceramic Hob, showing four circular cooking zones and integrated touch controls at the bottom center.

Key Components:

- **Vitroceramic Surface:** Durable and easy-to-clean cooking surface.
- **Cooking Zones:** Four independent heating zones for various pot and pan sizes.
- **Touch Controls:** Intuitive touch-sensitive panel for power, heat level adjustment, and other functions.
- **Residual Heat Indicators:** Lights that indicate when a cooking zone is still hot after use.

4. SETUP AND INSTALLATION

Installation of the CORBERO CCVY460 Vitroceramic Hob must be carried out by a qualified technician or electrician in accordance with all local regulations and standards.

General Installation Guidelines:

- **Unpacking:** Carefully remove the hob from its packaging. Inspect for any damage.
- **Worktop Preparation:** Ensure the worktop material is heat-resistant. Cut out the opening according to the dimensions provided in the separate installation template (not included in this manual, typically supplied with the product).
- **Ventilation:** Maintain adequate clearance around the hob for proper ventilation. Do not obstruct air inlets or outlets.
- **Electrical Connection:** Connect the hob to a suitable electrical supply as per the wiring diagram and local regulations. Ensure the appliance is properly earthed.
- **Securing the Hob:** Secure the hob into the worktop using the provided clips or brackets.
- **First Use:** Before first use, clean the hob surface with a damp cloth. Some odor may be present during the initial heating; this is normal and will dissipate.

5. OPERATING INSTRUCTIONS

The CORBERO CCVY460 Vitroceramic Hob features intuitive touch controls. Ensure your hands are clean and dry when operating the controls.

Basic Operation:

1. **Power On:** Touch the main power button (O/I symbol) to turn on the hob. The display will show "0" or similar.
2. **Select a Cooking Zone:** Touch the control for the desired cooking zone.

- 3. **Adjust Heat Level:** Use the "+" and "-" touch controls to set the desired heat level, typically from 1 (low) to 9 (high).
- 4. **Power Off a Zone:** Select the active zone and reduce the heat level to "0", or press the dedicated zone off button if available.
- 5. **Power Off Hob:** Touch the main power button (O/I symbol) to turn off the entire hob. Residual heat indicators ("H") will remain lit until the zone has cooled down.

Important Notes:

- Use flat-bottomed cookware that matches the size of the cooking zone for optimal efficiency.
- Do not use cookware with rough bottoms as they can scratch the glass surface.
- Avoid placing aluminum foil or plastic items on the hot hob surface.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your CORBERO CCVY460 Vitroceramic Hob.

Cleaning the Vitroceramic Surface:

- 1. **Before Cleaning:** Ensure the hob is switched off and has cooled down completely. Disconnect from the power supply if possible.
- 2. **Daily Cleaning:** Wipe the surface with a damp cloth and a small amount of mild dish soap. Rinse thoroughly and dry with a clean cloth to prevent water marks.
- 3. **Stubborn Stains:** For burnt-on food or stubborn stains, use a specialized ceramic hob cleaner and a hob scraper (plastic or metal blade designed for ceramic hobs). Follow the cleaner's instructions.
- 4. **Avoid:** Do not use abrasive sponges, scouring pads, harsh detergents, or steam cleaners, as these can damage the surface.

General Maintenance:

- Regularly check the hob for any signs of damage, especially to the glass surface.
- Ensure the ventilation openings are not blocked.

7. TROUBLESHOOTING

Before contacting customer service, please refer to the following troubleshooting guide for common issues:

Problem	Possible Cause	Solution
Hob does not turn on.	No power supply; main power switch off; control panel locked.	Check circuit breaker/fuse. Ensure hob is plugged in. Unlock control panel (refer to specific lock function in full manual if available).
Cooking zone not heating.	Incorrect heat setting; wrong cookware; zone not selected.	Increase heat setting. Use appropriate cookware. Ensure the correct zone is selected.
"H" indicator remains on.	Residual heat.	This is normal. The "H" indicates the zone is still hot. It will turn off when the temperature drops to a safe level.
Hob makes unusual noises.	Expansion/contraction of materials; fan noise (if applicable).	Minor noises are normal during heating and cooling. If loud or persistent, contact service.

If the problem persists after attempting these solutions, please contact CORBERO customer service or a qualified technician.

8. SPECIFICATIONS

The following are the general specifications for the CORBERO CCVY460 Vitroceramic Hob:

- **Brand:** Corbero
- **Model Number:** CCVY460
- **Material:** Vitroceramic
- **Color:** Black
- **Number of Cooking Zones:** 4
- **Control Type:** Touch Controls
- **Package Dimensions:** 20 x 20 x 20 cm
- **Package Weight:** 1 kilogram
- **ASIN:** B078JGHTQS

Note: Specific power ratings and cutout dimensions are typically provided in a separate installation guide or on the product's rating plate.

9. WARRANTY AND SUPPORT

CORBERO products are manufactured to high-quality standards and come with a manufacturer's warranty. The specific terms and duration of your warranty may vary by region and purchase date. Please retain your proof of purchase for warranty claims.






For Support:

- Refer to the warranty card included with your product for detailed information.
- Visit the official CORBERO website for customer service contact details, FAQs, and product registration.
- Contact your retailer for assistance with returns or initial product issues.

© 2023 Corbero. All rights reserved.

Related Documents - CCVY460

<div><div><div>Corberó</div><div><div>GAS HOB 5 BURNERS BLACK GLASS</div><div>CPCGM5F5021N</div></div><div><div>GAS HOB 4 BURNERS BLACK GLASS</div><div>CPCGM4F121N</div></div><div><div>GAS HOB 4 BURNERS WHITE GLASS</div><div>CPCGM4F122W</div></div><div><div>GAS HOB 3 BURNERS BLACK GLASS</div><div>CPCGM3F3121N</div></div><div><div>GAS HOB 3 BURNERS WHITE GLASS</div><div>CPCGM3F3122W</div></div><div>USER MANUAL</div></div></div>	<div><div>Corberó Gas Hob User Manual: Installation, Operation, and Safety Guide</div><div>Comprehensive user manual for Corberó gas hobs, covering installation, safe operation, cleaning, maintenance, and troubleshooting for models CPCGM5F5021N, CPCGM4F4121N, CPCGM4F4122W, CPCGM3F3121N, and CPCGM3F3122W.</div></div>
--	---

	<p>Corberó CCVM4604 Ceramic Hob - Instruction Manual</p> <p>Comprehensive instruction manual for the Corberó CCVM4604 ceramic hob. Learn about installation, operation, safety, and maintenance for this modern kitchen appliance.</p>
	<p>Corberó CFMMB430BLGL Mini Bar User Manual</p> <p>Comprehensive user manual for the Corberó CFMMB430BLGL Mini Bar, covering safety warnings, proper use, maintenance, and troubleshooting for optimal operation.</p>
	<p>CLVM6021X/CLVM6021W Dishwasher Instruction Manual</p> <p>Comprehensive instruction manual for the CLVM6021X and CLVM6021W dishwashers, covering safety information, product overview, usage instructions, maintenance, installation, and troubleshooting.</p>
	<p>Corberó CCH450MX Built-in Oven User Manual</p> <p>Comprehensive user manual for the Corberó CCH450MX built-in oven, covering safety instructions, installation, product features, operation, cleaning, maintenance, and troubleshooting.</p>
	<p>Corberó CCH324EW/CCH324EX Frigorífico Combi Manual de Instrucciones</p> <p>Manual de instrucciones para el frigorífico Corberó CCH324EW y CCH324EX con tecnología NO FROST. Incluye información de seguridad, instalación, uso diario y mantenimiento.</p>