

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [IFB](#) /
- › [IFB Seniorita WX 6.5 kg Front Load Washing Machine User Manual](#)

IFB SENORITA WX

IFB Seniorita WX 6.5 kg Front Load Washing Machine User Manual

Model: SENORITA WX | Brand: IFB

1. PRODUCT OVERVIEW

The IFB Seniorita WX is a 6.5 kg fully-automatic front loading washing machine designed for efficient and thorough laundry care. It features an inbuilt heater and Aqua Energie water softener technology, ensuring optimal wash quality and energy efficiency. This manual provides essential information for the safe and effective use of your appliance.



Figure 1: Front view of the IFB Senorita WX washing machine.

2. SAFETY INSTRUCTIONS

Before operating the washing machine, read all instructions carefully to prevent injury or damage. Keep this manual for future reference.

- Ensure the appliance is properly grounded.
- Do not allow children to play with or operate the machine.
- Do not wash items that are soiled with flammable substances.
- Unplug the machine before cleaning or performing any maintenance.
- Do not open the door forcefully during operation.

3. SETUP AND INSTALLATION

The IFB Senorita WX is a free-standing unit. Proper installation is crucial for optimal performance and safety.

3.1 Unpacking

Carefully remove all packaging materials, including the transit bolts at the rear of the machine. Retain packaging for potential future transport.

3.2 Leveling the Machine

Place the washing machine on a firm, level surface. Adjust the leveling feet at the bottom of the machine until it is stable and does not wobble.



Figure 2: Bottom view showing adjustable leveling feet for stability.

3.3 Water Connection

Connect the water inlet pipe to a cold water tap and to the inlet valve at the back of the machine. Ensure all connections are tight to prevent leaks. Position the drain hose into a suitable drain or sink, ensuring it is not kinked.



Figure 3: Rear view of the washing machine, illustrating water inlet and drain hose connections.

3.4 Power Connection

Plug the power cord into a dedicated, grounded electrical outlet. Ensure the voltage matches the machine's requirements (240 Volts).

4. OPERATING INSTRUCTIONS

The IFB Seniorita WX offers 12 wash programs and a maximum rotational speed of 1000 RPM for efficient washing and drying.

4.1 Loading Laundry

Open the front loading door and place laundry loosely into the drum. Do not overload the machine. The capacity is 6.5 kg.



Figure 4: Interior view of the Crescent Moon Drum, designed for gentle washing.

4.2 Adding Detergent

Add the appropriate amount of detergent and fabric softener to the dispenser drawer. Refer to your detergent packaging for recommended quantities.

4.3 Selecting a Wash Program

Turn the program selector knob to choose one of the 12 available wash programs. The LCD display will show the selected program and estimated time.



Figure 5: Close-up of the control panel with program selector knob and LCD display.

Available programs include:

- Express Wash
- Cotton Normal
- Woollens
- Cotton Eco Plus
- Anti-Allergen
- Synthetic/Daily
- Tub Clean
- Mixed Soiled
- Rinse+Spin
- Baby Wear
- Spin Dry/Drain
- CradleWash™

Special features like Aqua Energie, Air Bubble Wash, and the Inbuilt Heater are automatically integrated into relevant programs or can be selected via options if available.

4.4 Starting a Wash Cycle

Press the 'Start/Pause' button to begin the wash cycle. The machine will automatically proceed through the selected program.

4.5 Child Lock

Activate the child lock feature to prevent accidental program changes or interruptions during a wash cycle. Refer to the control panel diagram for specific button combinations to activate/deactivate.

5. MAINTENANCE

Regular maintenance ensures the longevity and efficiency of your washing machine.

5.1 Cleaning the Detergent Dispenser

Periodically remove and clean the detergent dispenser drawer to prevent residue buildup.

5.2 Drum Cleaning

Use the 'Tub Clean' program regularly to clean the drum and remove any detergent or fabric softener residues.

5.3 Filter Cleaning

Locate and clean the drain pump filter at the bottom front of the machine. This should be done periodically to remove lint and small objects.

5.4 Exterior Cleaning

Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners.

6. TROUBLESHOOTING

This section addresses common issues you might encounter. For more complex problems, contact customer support.

Problem	Possible Cause	Solution
Machine does not start	Power cord unplugged, door not closed properly, program not selected, child lock active.	Check power connection, ensure door is latched, select a program, deactivate child lock.
Water not draining	Drain hose kinked or blocked, drain pump filter clogged.	Straighten drain hose, clean drain pump filter.
Excessive vibration/noise	Machine not level, transit bolts not removed, uneven load.	Adjust leveling feet, ensure transit bolts are removed, redistribute laundry.
Error code on display	Specific malfunction.	Refer to the full user manual for a list of error codes and their solutions.

7. SPECIFICATIONS

Detailed technical specifications for the IFB Senorita WX washing machine.

Model: SENORITA WX

Capacity: 6.5 Kilograms

Type: Fully-Automatic Front Loading

Maximum Rotational Speed: 1000 RPM

Wash Programs: 12

Special Features: Inbuilt Heater, Aqua Energie, Air Bubble Wash, Child Lock, LCD Display, Crescent Moon Drum, Ball Valve Technology, Silk Special

Drum Material: Stainless Steel

Noise Level (Washing): 54 Decibels

Noise Level (Spinning): 68 dB

Dimensions (LxWxH): 50.6 x 59.8 x 85.8 Centimeters

Item Weight: 66 kg

Voltage: 240 Volts

Included Components: Drain Hose, Protective Rat Mesh, User Manual, Water Inlet Pipe, 1 Washing Machine

7.1 Energy Efficiency



Figure 6: Energy Savings Guide for the IFB Seniorita WX.

Energy Consumption: 0.089 kWh/cycle

Water Consumption: 8.9 L/kg/cycle

Energy Star Rating: 5 Stars

8. WARRANTY AND SUPPORT

Your IFB Seniorita WX washing machine comes with a comprehensive warranty and dedicated customer support.

8.1 Warranty Information

- **Product Warranty:** 4 years
- **Motor Warranty:** 4 years

Please retain your purchase receipt for warranty claims. The warranty covers manufacturing defects under normal use conditions.

8.2 Customer Support

For service, repairs, or any queries, please contact IFB customer service. You can find contact details on the official IFB website or your warranty card.

Manufacturer: IFB Industries Ltd., Verna Industrial Estate, Goa - 403722, India

