

KitchenAid KNS896BXGRA

KitchenAid Full Size Rust Resistant Dish Rack User Manual

Model: KNS896BXGRA

1. INTRODUCTION


The KitchenAid Full Size Dish Rack provides an efficient solution for air-drying various kitchenware. Its design accommodates plates, mugs, glasses, bowls, flatware, pots, and pans. This manual outlines the components, setup, operation, and maintenance of your dish rack to ensure optimal performance and longevity.

2. COMPONENTS

Your KitchenAid Full Size Dish Rack includes the following main components:

- **Dish Rack:** The primary structure for holding dishes.
- **Drainboard:** Collects and directs water into the sink.
- **Removable Flatware Caddy:** For organizing utensils.

KitchenAid®



Durable



Nonslip



Stainless Steel

Image 2.1: Overview of the KitchenAid Full Size Dish Rack with dimensions (approximately 20 inches wide, 14.96 inches deep, and 7 inches high).

REMOVABLE CADDY

Features adjustable compartments to separate utensils and a dishwasher-inspired handle for easy transport.



Image 2.2: Detailed view of the removable flatware caddy, showing compartments for various utensils.

3. SETUP

The KitchenAid Full Size Dish Rack is designed for effortless, tool-free assembly.

1. **Position the Drainboard:** Place the drainboard on a flat countertop surface next to your sink. Ensure the angled spout is positioned to direct water directly into the sink.
2. **Place the Dish Rack:** Carefully set the wire dish rack onto the drainboard. The soft, non-slip feet on the bottom of the rack will help keep it securely in place and protect your countertop.
3. **Attach the Flatware Caddy:** The flatware caddy can be attached to the side of the dish rack. It features adjustable compartments to separate utensils.



Image 3.1: The flatware caddy securely attached to the side of the dish rack, ready for use.

4. OPERATING INSTRUCTIONS

Using your KitchenAid Dish Rack is straightforward. Follow these guidelines for optimal drying and organization:

- **Loading Dishes:** Place plates vertically in the designated slots. Mugs, glasses, and bowls can be inverted over the wire frame to allow for proper drainage and airflow. The spacious design accommodates large loads, including pots and pans.
- **Using the Flatware Caddy:** Utilize the adjustable compartments within the flatware caddy to separate forks, spoons, knives, and other utensils. This helps in organization and ensures thorough drying. The built-in handle allows for easy removal and transport of utensils to drawers or cabinets.
- **Drainage:** The angled drainboard is designed to direct water directly into your sink, preventing pooling on your countertop. Ensure the drainboard's spout is positioned correctly over the sink's edge.



Image 4.1: The dish rack fully loaded with a variety of dishes, pots, and utensils, demonstrating its large capacity.

LARGE CAPACITY

Easily accommodates an entire meal's worth of cookware, dinner plates, glasses, and more.



Image 4.2: The dish rack accommodating cookware, dinner plates, and glasses, highlighting its versatility.

5. MAINTENANCE

Proper care will extend the life and appearance of your KitchenAid Dish Rack:

- **Cleaning:** All components of the dish rack should be hand washed only. Use mild soap and water. Avoid abrasive cleaners or scouring pads that could damage the finish.
- **Drying:** To maintain optimal rust resistance, it is recommended to dry the rack and drainboard after each use.
- **Drainboard Cleaning:** The drainboard is removable for easy cleaning. Periodically detach it and wash thoroughly to prevent mineral buildup or residue.

6. TROUBLESHOOTING

If you encounter any issues with your dish rack, refer to the following common solutions:

- **Water Not Draining Properly:** Ensure the drainboard is correctly angled and positioned over the sink. Check for any obstructions in the drain spout.
- **Rack Instability:** Verify that the dish rack is placed on a flat, even surface. The non-slip feet should

provide adequate stability.

- **Rust Appearance:** While designed to be rust-resistant, prolonged exposure to moisture without drying can lead to issues. Ensure the rack is dried after use as part of routine maintenance.

7. SPECIFICATIONS


Material	Carbon Steel, Plastic, Stainless Steel
Product Dimensions	14.96"D x 20"W x 7"H
Brand	KitchenAid
Color	Light Grey
Recommended Uses	Kitchen
Mounting Type	Sink, Tabletop
Item Weight	2.99 Pounds
Weight Limit	25 Pounds
Special Feature	Adjustable
Manufacturer	Lifetime Brands Inc.
Size	Full Size
UPC	024131392995
ASIN	B078JXFBDP
Item Model Number	KNS896BXGRA

8. WARRANTY AND SUPPORT

Your KitchenAid Full Size Dish Rack is backed by a **Lifetime Limited Warranty**. For warranty claims or product support, please refer to the official KitchenAid website or contact their customer service department.


You can also visit the [KitchenAid Store on Amazon](#) for additional product information and support resources.

Related Documents - KNS896BXGRA



[KitchenAid Freestanding Gas Range Quick Start Guide](#)

A quick start guide for KitchenAid freestanding gas ranges, covering oven and cooktop operation, rack positioning, burner size selection, and troubleshooting tips.



[KitchenAid Dishwasher Cycle Guide and Operation Manual](#)

Comprehensive guide to KitchenAid dishwasher cycles, including ProWash, Tough, Normal, Express, and Rinse Only. Details wash and dry options like Hi-Temp, Sani Rinse, ProDry, and ProDry Max, along with control functions and operational procedures.



[KitchenAid 730-0953A Freestanding Outdoor Grill Owner's Manual & Installation Guide](#)

Comprehensive owner's manual and installation guide for the KitchenAid 730-0953A freestanding outdoor grill, covering safety, assembly, usage, care, and troubleshooting.



[KitchenAid 720-0953A Freestanding Outdoor Grill Owner's Manual](#)

Official owner's manual, installation guide, and use & care instructions for the KitchenAid 720-0953A freestanding outdoor grill. Covers safety, assembly, operation, maintenance, and troubleshooting.



[KitchenAid 7 & 9 Speed Hand Mixers: Instructions, Recipes, and Warranty](#)

Comprehensive guide for KitchenAid 7 and 9 Speed Hand Mixers, including setup, operation, safety, troubleshooting, care, and a collection of recipes. Features warranty information and product details.



[KitchenAid 5KSMMGA Stand Mixer Attachment: Use, Care, and Guarantee Guide](#)

Comprehensive guide for the KitchenAid 5KSMMGA Stand Mixer Attachment, covering parts, assembly, usage, safety, care, cleaning, and warranty information. Learn how to use your food grinder and sausage stuffer attachments effectively.

