**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## SoBuy FRG241-W

# SoBuy FRG241-W Microwave Oven Cabinet and Kitchen Cart User Manual

Brand: **SoBuy** | Model: **FRG241-W**

## 1. Introduction

Thank you for choosing the SoBuy FRG241-W Microwave Oven Cabinet and Kitchen Cart. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before use and retain them for future reference.

## 2. Safety Information

- Do not exceed the maximum weight capacity of**50 kg (110 lbs)**.
- Ensure correct assembly to prevent tipping and ensure stability.
- Exercise caution when moving the cabinet, especially when loaded, to avoid injury or damage.
- Be careful when adjusting shelves to prevent fingers from being pinched.
- Keep small parts away from children during assembly.

## 3. Product Overview

The SoBuy FRG241-W is a versatile and compact cabinet designed to enhance storage and functionality in various spaces. It features a dedicated platform for a microwave oven, an adjustable internal shelf, and smooth-rolling casters for easy mobility.

### Key Features:

- **Elevated Microwave Platform:** The top platform is positioned at 84 cm (33.1 inches) from the floor, allowing

comfortable access to your microwave without bending.

- **Adjustable Internal Shelf:** Behind the two doors, a shelf can be adjusted to three different heights, accommodating items of various sizes.
- **Mobile Design:** Equipped with four smooth-rolling casters, two of which are lockable, for easy movement and secure positioning.
- **Multi-purpose Functionality:** Ideal for use as a microwave stand, kitchen cart, printer stand, coffee station, or general storage cabinet.
- **Sleek Design:** A clean white finish with simple lines allows it to blend seamlessly with various interior styles.

### Dimensions:

Overall Dimensions (Depth x Width x Height): **55 cm x 38 cm x 84 cm (21.7 x 15 x 33.1 inches)**




Image: Detailed dimensions of the SoBuy FRG241-W cabinet, showing overall measurements and internal compartment sizes.

## 4. Setup and Assembly

Assembly of the SoBuy FRG241-W cabinet is required. Detailed assembly instructions are included in the product packaging. Please follow these instructions step-by-step to ensure correct and safe construction.

- Identify all components and hardware before starting.
- Use appropriate tools as indicated in the manual.
- **Important:** Exercise caution when inserting screws, as the engineered wood material can be prone to crumbling if excessive force is applied.
- Ensure all connections are secure before placing items on or inside the cabinet.

## 5. Operating Instructions

### Microwave Placement:

Place your microwave oven on the top platform. The elevated height allows for convenient access, reducing the need to bend down.




Image: The cabinet provides an ideal height for microwave use, allowing comfortable access.

### Adjustable Storage:

Utilize the adjustable shelf within the lower cabinet to customize storage space for various items, such as dishes, pots, or office supplies. The shelf can be set at three different heights.




Image: The adjustable shelf allows flexible storage for items of different heights.

### Mobility and Stability:

The four casters allow you to easily move the cabinet between rooms. Engage the two locking brakes when the cabinet is in its desired position to ensure stability and prevent accidental movement.




Image: The casters provide mobility, and the locking brakes ensure stability when stationary.

### Versatile Applications:

This cabinet is designed for multiple uses across different environments:

- **Kitchen:** Store kitchen appliances, dishes, and pantry items.
- **Dining Room:** Use as a serving cart or for additional storage.
- **Office:** Function as a printer stand, file storage, or a coffee station.
- **Living Room:** Provide extra storage or a display surface.




Image: The cabinet's adaptable design makes it suitable for various rooms and functions.

## 6. Maintenance

To maintain the appearance and longevity of your SoBuy FRG241-W cabinet, follow these simple care instructions:

- Wipe surfaces with a dry, soft cloth.
- Avoid using abrasive cleaners or harsh chemicals, as these may damage the finish.
- Periodically check all screws and connections to ensure they remain tight.
- Keep the cabinet away from direct sunlight and excessive moisture.

## 7. Troubleshooting

- **Difficulty during assembly:** If you encounter difficulties, re-check the assembly instructions carefully. Ensure all parts are correctly oriented. Do not force components together.
- **Wobbly cabinet:** Ensure all screws are tightened evenly. If the floor is uneven, consider placing shims under the casters or feet.
- **Missing or damaged parts:** If any parts are missing or damaged upon arrival, please contact SoBuy customer support immediately for assistance.
- **Casters not rolling smoothly:** Check for any debris caught in the wheels. Ensure the locking brakes are disengaged.

## 8. Specifications

| Feature | Detail |
|---|---|
| Brand | SoBuy |
| Model Number | FRG241-W |
| Color | White |
| Material | Engineered Wood, Plastic |
| Product Dimensions (D x W x H) | 55 x 38 x 84 cm (21.7 x 15 x 33.1 inches) |
| Item Weight | 18 Kilograms (39.7 lbs) |
| Maximum Weight Capacity | 50 Kilograms (110 lbs) |
| Number of Shelves | 1 (adjustable) |
| Number of Doors | 2 |
| Base Type | Casters (2 lockable) |
| Assembly Required | Yes |
| Recommended Uses | Kitchen countertop, kitchen utensils, beverage cart, microwave stand, printer stand |

## 9. Warranty and Support

### Return Policy:

This product is eligible for a refund or replacement within**31 days** of purchase. Please refer to your purchase platform's return policy for detailed instructions.

### Customer Support:

For any questions, concerns, or issues regarding your SoBuy FRG241-W cabinet, please contact SoBuy customer support. You can often find contact information on the packaging or through the retailer where you purchased the product.

- **Shipping Inquiries:** Your item may be shipped via UPS or DPD. If you require a specific parcel service, please inform us before shipment.
- **Assembly Instructions:** Instructions are included in each package. You can also scan the QR code on the packaging or contact us for digital instructions.
- **Product Returns:** If you are not satisfied with this product or encounter a problem, please contact us for a free return label.

Manufacturer: SoBuy

© 2023 SoBuy. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B078M7D582**

More documents and user manuals: **https://manuals.plus/**