

Adesso AKB-111UB

Adesso AKB-111UB SlimTouch Mini Keyboard User Manual

Model: AKB-111UB

INTRODUCTION

Thank you for choosing the Adesso AKB-111UB SlimTouch Mini Keyboard. This compact keyboard is designed for efficiency and space-saving, making it suitable for various environments including desktops, homes, and offices. It features 78 keys, an embedded numeric keypad, and multimedia hotkeys for enhanced functionality. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your keyboard.



Image: Front view of the Adesso AKB-111UB SlimTouch Mini Keyboard, showcasing its compact layout.

SETUP

1. **Unpacking:** Carefully remove the keyboard from its packaging. Ensure all components, including the keyboard and this instruction guide, are present.
2. **Connectivity:** The AKB-111UB keyboard connects to your computer via a USB cable. Locate the USB connector at the end of the keyboard cable.
3. **Connecting to Computer:** Plug the USB connector into an available USB port on your desktop computer or PC.
4. **Driver Installation:** The keyboard is designed for plug-and-play functionality. No additional driver installation is typically required. Your operating system should automatically detect and configure the device.
5. **Placement:** Position the keyboard on a stable, flat surface. Its mini size (less than 12 inches wide) is ideal for space-saving on any desktop.



Image: The Adesso AKB-111UB keyboard illustrating its compact 12-inch width, highlighting its space-saving design.

OPERATING INSTRUCTIONS

The Adesso AKB-111UB keyboard offers a range of features for efficient typing and media control.

Basic Typing

Use the standard QWERTY layout for everyday typing tasks. The membrane key switches provide a quiet and comfortable typing experience.

Embedded Numeric Keypad

The keyboard includes an embedded numeric keypad. To activate or deactivate the numeric keypad, press the **Num Lock** key. An LED indicator will illuminate when Num Lock is active.

LED Indicators

The keyboard features LED indicators for:

- **Num Lock:** Indicates whether the embedded numeric keypad is active.

- **Caps Lock:** Indicates whether capital letters are being typed.
- **Scroll Lock:** (Functionality may vary by application)

Multimedia and Internet Hotkeys

The keyboard is equipped with built-in multimedia and internet hotkeys for quick access to various functions. These keys are typically located on the F-row (F1-F12) and may require pressing the **Fn** key simultaneously for activation.

- **Media Control:** Play/Pause, Stop, Previous Track, Next Track.
- **Volume Control:** Volume Down, Volume Up, Mute.
- **Internet Access:** Dedicated keys for easy access to your favorite media or websites.

Page Up/Down, Home, End Hotkeys

These keys provide quick navigation within documents and web pages. Their functionality may be combined with the **Fn** key depending on the specific key layout.




Image: The Adesso AKB-111UB keyboard with labels indicating Function Key, Windows Key, Embedded Numeric Keypad, Multimedia Hotkeys, LED Indicators, and Page Up/Down, Home, End Hotkeys.

Your browser does not support the video tag.

Video: An official product video from Adesso demonstrating the features and compact design of the AKB-111UB SlimTouch Mini Keyboard.

MAINTENANCE

Cleaning

To maintain the keyboard's performance and appearance, follow these cleaning guidelines:

- Disconnect the keyboard from your computer before cleaning.

- Use a soft, lint-free cloth slightly dampened with water or a mild, non-abrasive cleaning solution.
- Gently wipe the keycaps and the keyboard surface. Avoid excessive moisture.
- Do not spray cleaners directly onto the keyboard.
- For debris between keys, use compressed air to dislodge particles.

Storage

When not in use, store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.

Membrane Key Switch Longevity

The membrane key switch features a lifecycle of more than five million keystrokes. The silicone rubber material used in its design helps reduce typing noise and contributes to its durability.



Image: A close-up view of the membrane key switches beneath the keycaps of the Adesso AKB-111UB keyboard, illustrating the mechanism responsible for quiet typing.

TROUBLESHOOTING

If you encounter issues with your Adesso AKB-111UB keyboard, please refer to the following common solutions:

- **Keyboard Not Responding:**
 - Ensure the USB cable is securely plugged into both the keyboard and the computer's USB port.
 - Try plugging the keyboard into a different USB port on your computer.
 - Restart your computer.
 - Test the keyboard on another computer to determine if the issue is with the keyboard or the original computer.
- **Keys Not Functioning Correctly (e.g., sticky, unresponsive):**
 - Clean the keyboard as described in the Maintenance section to remove any debris that might be affecting key

presses.

- Ensure no liquids have been spilled on the keyboard. If so, allow it to dry completely before use.

• **Numeric Keypad Not Working:**

- Press the **Num Lock** key to activate the numeric keypad. Check if the Num Lock LED indicator is on.

• **Multimedia Hotkeys Not Working:**

- Ensure you are pressing the **Fn** key simultaneously with the desired function key (F1-F12) if required by your system or application.
- Check your operating system's settings for keyboard shortcuts or media key configurations.

If these steps do not resolve the issue, please contact Adesso customer support for further assistance.

SPECIFICATIONS

Feature	Description
Brand	Adesso
Model Number	AKB-111UB
Connectivity Technology	USB
Number of Keys	78
Keyboard Layout	QWERTY
Key Switch Type	Membrane
Material	Silicone
Special Features	LED Indicators (Num Lock, Caps Lock, Scroll Lock), Embedded Numeric Keypad, Multimedia Hotkeys
Compatible Devices	Desktop Computer, PC
Color	Black
Item Weight	9.92 ounces

WARRANTY

The Adesso AKB-111UB SlimTouch Mini Keyboard comes with a**1-Year Limited Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by accident, abuse, misuse, modification, improper installation, or power surges. For warranty claims or service, please retain your proof of purchase and contact Adesso customer support.

SUPPORT

For technical support, product inquiries, or warranty information, please visit the official Adesso website or contact their customer service department.

Adesso Official Store: [Visit the Adesso Store on Amazon](#)

Please have your product model number (AKB-111UB) and proof of purchase ready when contacting support.

© 2026 Adesso. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question