

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [OMOTON](#) /

› OMOTON Keyboard with Sliding Stand Instruction Manual (Model OM-Upgraded Version Keyboard-White02)

OMOTON OM-Upgraded Version Keyboard-White02

OMOTON Keyboard with Sliding Stand Instruction Manual

Model: OM-Upgraded Version Keyboard-White02

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your OMOTON Keyboard with Sliding Stand. Please read this manual thoroughly before using the product to ensure proper function and longevity.

PACKAGE CONTENTS

- OMOTON Keyboard with Sliding Stand
- Instruction Manual

SPECIFICATIONS

Feature	Detail
Brand	OMOTON
Model Number	OM-Upgraded Version Keyboard-White02
Product Dimensions	11.2"L x 4.9"W x 0.6"H (28.4cm x 12.4cm x 1.5cm)
Item Weight	10.6 ounces (300g)
Connectivity Technology	Bluetooth
Compatible Devices	Tablet (iOS, iPadOS compatible)
Power Source	2 AAA batteries (not included)
Material	Plastic

SETUP

1. Battery Installation

1. Locate the battery compartment on the back of the keyboard.
2. Open the battery cover.
3. Insert two AAA batteries (not included), ensuring correct polarity (+/-).
4. Close the battery cover securely.





A visual guide detailing the five essential steps for setting up the OMOTON Bluetooth Keyboard, from inserting AAA batteries to successfully pairing it with a tablet via Bluetooth.

2. Bluetooth Pairing

1. Ensure the keyboard has fresh batteries installed.
2. Slide the power switch on the keyboard to the 'ON' position. The indicator light may flash.
3. Press the **Fn + C** keys simultaneously on the keyboard to enter pairing mode. The Bluetooth indicator light will start blinking.
4. On your device (tablet, smartphone, etc.), go to **Settings > Bluetooth**.
5. Turn on Bluetooth. Your device will search for available Bluetooth devices.
6. Select "Bluetooth Keyboard" from the list of found devices.
7. Follow any on-screen prompts to complete the pairing process. Once paired, the indicator light on the keyboard will stop blinking.

iPadOS & iOS Compatible



This image illustrates the OMOTON Bluetooth Keyboard's compatibility with a range of Apple devices, from smaller iPhones to larger iPads, highlighting its versatility.

OPERATING INSTRUCTIONS

1. Using the Sliding Stand

The OMOTON Keyboard features an integrated sliding stand designed to hold your tablet or smartphone at an optimal viewing angle.

1. Gently pull the stand out from the top edge of the keyboard.
2. Extend the stand until it locks into position.
3. Place your device (tablet or smartphone) into the stand's groove.
4. To retract, gently push the stand back into the keyboard until it is flush.



The OMOTON Bluetooth Keyboard with its integrated sliding stand, shown with a tablet in landscape orientation.



This image shows a user engaging with the OMOTON Bluetooth Keyboard, with a tablet securely positioned on the integrated sliding stand, ideal for typing or viewing content.

2. Function Keys

The keyboard includes a row of function keys (F1-F12) that provide quick access to various features on compatible devices. These keys often require pressing the **Fn** key simultaneously with the desired function key.

- **Fn + F1:** Home Screen
- **Fn + F2:** Brightness Down
- **Fn + F3:** Brightness Up
- **Fn + F4:** Search
- **Fn + F5:** Hide/Show Keyboard
- **Fn + F6:** Previous Track
- **Fn + F7:** Play/Pause
- **Fn + F8:** Next Track
- **Fn + F9:** Mute
- **Fn + F10:** Volume Down
- **Fn + F11:** Volume Up
- **Fn + F12:** Lock Screen

Featured Shortcut Keys

Instantly unlock the powerful features on your iPad or iPhone




A detailed view of the keyboard's top row, showcasing the dedicated shortcut keys designed for quick access to common functions on connected devices.

3. Typing Experience

The keyboard features responsive and quiet keys with an improved scissor switch mechanism, designed for a comfortable and efficient typing experience.

Portable and Versatile



Quiet




Responsive



Ergonomic

0.2 inch



0.6 inch

This image provides a close-up of a keycap, illustrating the internal scissor switch mechanism that contributes to a responsive and quiet typing experience.

MAINTENANCE

Cleaning

- Turn off the keyboard before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the surface.
- Avoid using harsh chemicals, abrasives, or solvents.
- Do not allow moisture to enter the key gaps or internal components.

Battery Care

- Replace batteries when the low power indicator light appears or when performance degrades.
- Remove batteries if the keyboard will not be used for an extended period to prevent leakage.
- Dispose of used batteries according to local regulations.

TROUBLESHOOTING

Keyboard Not Connecting/Pairing

- Ensure the keyboard is powered on and has fresh batteries.
- Make sure Bluetooth is enabled on your device.
- Ensure the keyboard is in pairing mode (Fn + C).
- Move the keyboard closer to your device.
- Forget the device in your device's Bluetooth settings and attempt to pair again.
- Restart both the keyboard (turn off/on) and your device.

Keys Not Responding

- Check battery level and replace if necessary.
- Ensure the keyboard is properly connected via Bluetooth.
- Clean any debris from around the keys.

Sliding Stand Feels Loose

- Ensure the stand is fully extended and locked into position.
- Avoid applying excessive force when extending or retracting the stand.

WARRANTY AND SUPPORT

Warranty Information

OMOTON products are designed and manufactured to high-quality standards. This product is covered by a limited warranty from the date of purchase. Please refer to the warranty card included with your product or visit the official OMOTON website for detailed warranty terms and conditions.

Customer Support

If you encounter any issues or have questions regarding your OMOTON Keyboard, please contact our customer support team. You can typically find contact information on the OMOTON official website or through the retailer where you purchased the product.

When contacting support, please have your product model number (OM-Upgraded Version Keyboard-White02) and purchase details ready.