Konwin TQH-06

Konwin Large-Room Infrared Quartz Tower Heater

Model: TQH-06 User Manual

1. Important Safety Instructions

Please read all instructions carefully before using this heater. Failure to follow these instructions may result in fire, electric shock, serious injury, or death.

- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not use outdoors. This heater is intended for indoor use only.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- Do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable vapors or liquids are used or stored.

2. Product Overview

The Konwin TQH-06 is a powerful and portable infrared quartz tower heater designed to provide supplemental heat for large indoor spaces. It features a compact tower design and easy-to-use controls.




THERMOSTAT
OFF



Image 1: Front view of the Konwin TQH-06 Infrared Quartz Tower Heater, showing the heating elements behind a protective grille and control knobs on top.

Key Features:

- Portable electric infrared heater
- 1500 Watts of heating power
- 120 Volts operation
- Tower form factor for efficient space utilization
- Designed for indoor use

3. Setup

Before first use, ensure the heater is placed on a firm, level surface away from any obstructions or flammable materials. Do not place the heater directly under a power outlet.



Image 2: The Konwin TQH-06 heater positioned in a living room, demonstrating appropriate placement away from furniture and curtains.

1. Unpack the heater carefully and remove all packaging materials.
2. Place the heater on a stable, flat, and heat-resistant surface. Ensure there is at least 3 feet (0.9 m) of clear space around the front, sides, and rear of the heater.
3. Ensure the power cord is not pinched or routed under the heater or any other objects.

4. Plug the power cord directly into a grounded 120V AC wall outlet. Do not use extension cords or power strips.

4. Operating Instructions

The Konwin TQH-06 heater features simple controls for ease of use.

1. **Power On/Off:** Locate the power knob, typically marked with 'OFF', 'LOW', and 'HIGH' settings. Turn the knob to 'LOW' or 'HIGH' to turn the heater on. Turn to 'OFF' to power down.
2. **Heat Settings:**
    - **LOW:** Provides a lower heat output (e.g., 750W).
    - **HIGH:** Provides the maximum heat output (1500W).
3. **Thermostat Control:** The thermostat knob allows you to set your desired room temperature. Turn the knob clockwise to increase the desired temperature and counter-clockwise to decrease it. The heater will cycle on and off to maintain the set temperature.
4. **Safety Features:** This heater is equipped with an overheat protection system that automatically shuts off the heater if it overheats. It also includes a tip-over switch that turns the heater off if it is accidentally knocked over. If either safety feature activates, unplug the heater, wait 10-15 minutes for it to cool down, and then plug it back in. Ensure the heater is on a stable surface before restarting.

5. Maintenance

Regular maintenance ensures the longevity and efficient operation of your heater.

- **Cleaning:** Always unplug the heater from the wall outlet before cleaning. Use a soft, damp cloth to wipe the exterior surfaces of the heater. Do not use abrasive cleaners or solvents. Do not immerse the heater in water.
- **Dust Removal:** Use a vacuum cleaner with a brush attachment to remove dust from the air intake and exhaust grilles. This should be done regularly to maintain optimal airflow.
- **Storage:** When not in use, store the heater in a cool, dry place. It is recommended to store it in its original packaging to protect it from dust and damage.

6. Troubleshooting

If your heater is not operating correctly, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	No power to the unit, tip-over switch activated, or overheat protection activated.	Ensure the heater is plugged into a live 120V outlet. Check if the heater was tipped over; place it upright. Unplug and wait 10-15 minutes for cooling if it overheated.
Heater produces no heat.	Thermostat set too low, or heating elements are faulty.	Increase the thermostat setting. If still no heat, contact customer support.
Heater cycles on and off frequently.	Room temperature has reached the thermostat setting, or airflow is restricted.	This is normal operation if the room is warm enough. Ensure air intake/exhaust are not blocked.

Problem	Possible Cause	Solution
Burning smell.	Dust accumulation on heating elements (common for first use), or foreign object inside.	Unplug and clean the heater. If the smell persists or is strong, discontinue use immediately and contact support.

7. Specifications

Specification	Value
Brand	Konwin
Model	TQH-06
Power Output	1500 Watts
Voltage	120 Volts
Form Factor	Tower
Use Environment	Indoor
Special Feature	Portable
Product Weight	3.36 Kilograms
Package Dimensions	65.79 x 36.58 x 21.59 cm

8. Warranty and Support

Specific warranty information for the Konwin TQH-06 heater is typically provided with the product packaging or can be found on the manufacturer's official website. Please retain your proof of purchase for any warranty claims.

For technical support, replacement parts, or further assistance, please refer to the contact information provided by Konwin in your product documentation or visit their official support channels online.

© 2024 Konwin. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question