Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DORISILK 1 Inch Black Steam Straightener Flat Iron

DORISILK 2.0 Upgraded Steam Straighteners for Hair

Model: 1 Inch Black Steam Straightener Flat Iron

Brand: DORISILK

1. Introduction

The DORISILK 2.0 Upgraded Steam Straightener is a versatile 2-in-1 tool designed for both straightening and curling hair. It features advanced steam technology, ceramic tourmaline plates, and adjustable temperature settings to provide salon-like results while minimizing hair damage. This manual will guide you through the proper setup, operation, and maintenance of your new steam straightener.

Product Overview



Image: The DORISILK 2.0 Upgraded Steam Straightener in its packaging and open, showcasing its sleek design and steam vents.



Image: Comparison illustrating the difference between normal flat iron results (frizz & dry) and DORISILK flat iron results (smooth & silky).



Image: Visual representation of hair treatment outcome with steam, showing reduced damage and healthy hair through steam moisturization.

2. Important Safety Information

- Keep out of reach of children.
- Do not touch the splint (heating plates) while it is working, as it can cause severe burns.
- Use pure water only in the water tank. Do not use other liquids, such as oils, as this can damage the device and pose a safety risk.
- Ensure the device is unplugged when not in use and before cleaning.
- Do not immerse the device in water or any other liquid.
- If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- Avoid using the straightener near bathtubs, showers, basins, or other vessels containing water.

3. Setup

3.1 Filling the Water Tank

1. Ensure the straightener is unplugged and cool.
2. Locate the water tank on the device.
3. Open the water tank cover.
4. Fill the tank with pure water using the provided dropper or a small bottle. Do not overfill.
5. Securely close the water tank cover.



Image: Step-by-step guide on how to correctly fill the water tank with pure water.

3.2 Powering On and Initial Heating

Plug the straightener into a suitable power outlet (110V-240V compatible). Press the power button to turn on the

device. The LED indicators will blink as the plates heat up. Once the desired temperature is reached, the lights will stop blinking, indicating it's ready for use.

Video: Demonstrates how to select temperature and steam settings, including the initial heating process.

4. Operating Instructions

4.1 Temperature and Steam Settings

The straightener offers 6 different temperature settings (150-235℃ / 302-455℉) to suit various hair types. It also has 3 conditioning steam settings: OFF, MED, and HIGH.

Recommended Settings by Hair Type

Temperature	Steam Gear	Heat Time	Hair Types
300-340℉	OFF	30-40s	Thin/Fine Hair
370-410℉	Med	70-90s	Normal/Medium Hair
430-450℉	High	110-130s	Thick/Coarse Hair

To activate steam, ensure the temperature is ideally at or above 370℉. Turn on the steam gear, then open and merge the splint 3-5 times; steam will appear. For best results, pause for 10 seconds during operation to allow for sufficient steam output after heating.

Video: Shows the DORISILK Steam Straightener in action, demonstrating its effectiveness on hair.

Video: Demonstrates the 2-in-1 functionality of the DORISILK iron for both straightening and curling hair.

Video: Illustrates the LED temperature control for the 1-inch steam flat iron, showing settings up to 450 degrees.

Video: A detailed demonstration of the DORISILK steam flat iron hair straightener in use.

Video: Highlights the features of the 2.0 Upgraded Steam Straightener Flat Iron for Hair.

4.2 Straightening Hair

Ensure your hair is clean and dry before use. Section your hair into manageable portions. Take a small section of hair and place it between the heating plates. Gently clamp the plates together and glide the straightener down the hair shaft from roots to ends in a smooth, continuous motion. Repeat as necessary until desired straightness is achieved. The 3D floating ceramic plates are designed to prevent snagging and pulling.

4.3 Curling Hair

For curling, take a section of hair and clamp it between the plates near the roots. Rotate the straightener 180 degrees away from your face, then slowly pull it down the hair shaft. The rounded edges of the plates will help create smooth curls or waves. The 2-in-1 design allows for versatile styling.

5. Maintenance

5.1 Cleaning

Always ensure the straightener is unplugged and completely cool before cleaning. Wipe the ceramic plates and the exterior of the device with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals, as these can damage the surfaces. Regularly empty and clean the water tank to prevent mineral buildup.

5.2 Storage

After use, allow the straightener to cool completely. Engage the plate locking switch for compact storage and travel. Store the device in a dry, safe place away from moisture and extreme temperatures. The 360° swivel cord should be stored untangled to prevent damage.

6. Troubleshooting

- **No Steam or Little Steam:** Ensure the water tank is filled with pure water. Verify that the steam function is turned ON (not OFF). The temperature must be at least 370°F for steam to appear. If the temperature is too low, steam production will be minimal or absent.
- **Water Leakage:** Water leakage can occur if the heating process is unfinished or if the water tank is not properly sealed. Ensure the straightener has reached its set temperature before activating steam. Always securely close the water tank cover after filling.
- **Hair Snagging or Pulling:** While the 3D floating plates are designed to prevent this, ensure you are using the straightener on clean, detangled hair. Take smaller sections of hair to allow for smooth gliding.
- **Device Not Heating:** Check if the device is properly plugged into a working power outlet. Ensure the power button is pressed and the LED indicators are active. If the issue persists, contact customer support.

7. Specifications

- **Brand:** DORISILK
- **Model:** 1 Inch Black Steam Straightener Flat Iron
- **Material:** Ceramic Tourmaline
- **Hair Type Compatibility:** All, Straight
- **Product Dimensions:** 13 x 4 x 4 inches
- **Weight:** 1.21 Pounds
- **Voltage:** Dual Voltage 110V-240V
- **Temperature Settings:** 150-235°C / 302-455°F (6 adjustable modes)
- **Steam Settings:** OFF/MED/HIGH (5 Conditioning Steam Vents)
- **Auto Shut-off:** 60 minutes
- **Cord:** 360° Swivel Cord
- **Features:** 3D Floating Plates, PTC System, Lockable Plates, Anti-static, Anti-scald
- **Manufacturer:** DORISILK
- **Country of Origin:** China
- **GTIN/UPC:** 786118300828, 717553338848, 758232144398

8. Warranty and Support

Specific warranty details for the DORISILK 2.0 Upgraded Steam Straightener are not provided in this manual. For warranty information, product support, or any inquiries, please contact DORISILK customer service directly through their official website or the retailer where the product was purchased.
Thank you for choosing DORISILK. We hope you enjoy your new steam straightener!

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question