Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Arzum AR1032-P

Arzum Shake & Take Personal Blender

Model: AR1032-P User Manual

Introduction

Thank you for choosing the Arzum Shake & Take Personal Blender. This manual provides essential information for the safe and efficient use of your new appliance. Please read all instructions carefully before first use and retain this manual for future reference.

Important Safety Precautions

- Always unplug the blender from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not immerse the motor base in water or any other liquid. Clean only with a damp cloth.
- Keep hands and utensils out of the blending bottle while blending to prevent injury.
- Ensure the blending bottle is securely attached to the motor base before operating.
- Do not blend hot liquids, as pressure buildup may cause injury.
- This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Keep out of reach of children.

Product Overview & Components

Familiarize yourself with the parts of your Arzum Shake & Take Personal Blender:

1. Motor Base
2. Blending Bottle (with measurement markings)
3. Blade Assembly
4. Travel Lid



Image: The Arzum Shake & Take Personal Blender showing the motor base, a blending bottle with fresh ingredients (lemon and cucumber), and a second portable bottle containing a green beverage. This illustrates the compact design and dual bottle functionality.



Image: Two portable blending bottles with their respective travel lids, highlighting the convenience for on-the-go use. Both bottles feature a grey silicone grip with "SHAKE & TAKE" embossed.

Setup

1. Unpacking and Initial Cleaning

Carefully remove all components from the packaging. Wash the blending bottle, blade assembly, and travel lid with warm, soapy water before first use. Rinse thoroughly and dry all parts. Wipe the motor base with a damp cloth.

2. Assembly

1. Place the motor base on a clean, dry, and stable surface.

2. Fill the blending bottle with your desired ingredients. Do not exceed the "MAX" fill line.
3. Screw the blade assembly firmly onto the open end of the blending bottle, ensuring it is tightly sealed to prevent leaks.
4. Invert the blending bottle so the blade assembly faces downwards, and align the tabs on the bottle with the slots on the motor base.
5. Press the bottle down and twist clockwise until it locks securely into place.



Image: A hand demonstrating how to attach the blade assembly to the blending bottle, which is filled with various berries and fruits, illustrating the preparation step before blending.



Image: The blending bottle being detached from the motor base of the Arzum Shake & Take Personal Blender, showing the connection point between the bottle and the base unit.

Operating Instructions

1. Preparing Ingredients

Cut fruits and vegetables into small pieces (approximately 1-2 cm) to ensure smooth blending. For best results, add liquids first, then soft ingredients, followed by harder ingredients and ice (if using). Do not overfill the bottle.

2. Blending

1. Once the bottle is securely locked onto the motor base, plug the power cord into a suitable electrical outlet.
2. Press and hold the power button to begin blending. For continuous blending, some models may have a lock feature or require constant pressure.
3. Blend until desired consistency is achieved. For optimal performance and to prevent overheating, blend in short bursts (e.g., 30 seconds on, 1 minute off) rather than continuously for extended periods.
4. Once blending is complete, release the power button and unplug the appliance.
5. Twist the blending bottle counter-clockwise to unlock and remove it from the motor base.
6. Carefully unscrew the blade assembly from the bottle.
7. Attach the travel lid to the blending bottle for on-the-go consumption.



Image: A close-up view of the travel lid for the Arzum Shake & Take blending bottle, showing the flip-top spout and integrated carrying loop,

designed for convenient portability.

Maintenance and Cleaning

Regular cleaning ensures the longevity and hygiene of your blender.

Daily Cleaning

1. Unplug the blender from the power outlet.
2. Remove the blending bottle and blade assembly.
3. Rinse the blending bottle, blade assembly, and travel lid immediately after use with warm water to prevent food from drying on.
4. For thorough cleaning, wash these parts with warm, soapy water using a brush for the blades.
5. Rinse and dry completely.
6. Wipe the motor base with a damp cloth. Do not submerge the motor base in water.

Storage

Store the blender in a dry, clean place, away from direct sunlight and heat sources. Ensure all parts are completely dry before storing.

Troubleshooting

If you encounter issues with your blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; bottle not securely attached; motor overheating.	Ensure power cord is firmly plugged in. Twist bottle clockwise until it locks. Unplug and let motor cool for 15-20 minutes if overheated.
Ingredients not blending smoothly.	Too little liquid; ingredients too large; too much ice/frozen fruit.	Add more liquid. Cut ingredients into smaller pieces. Reduce amount of ice/frozen fruit. Blend in pulses.
Leakage from bottle.	Blade assembly not tightened; seal ring missing or damaged.	Ensure blade assembly is screwed on tightly. Check if the seal ring is properly seated or if it needs replacement.
Burning smell from motor.	Overloading; continuous operation for too long.	Reduce ingredients. Blend in short bursts. Unplug and allow motor to cool down. If smell persists, contact customer support.

Specifications

Brand	Arzum
Model Number	AR1032-P
Color	Pink
Power / Wattage	300 watts
Voltage	230V

Capacity	1 load (bottles typically 400-600ml)
Product Dimensions	23 x 21 x 16 cm (approximate, as per product data)
Item Weight	500 g
Material	Mixed
Special Features	Portable

Warranty and Support

Warranty Information

This Arzum Shake & Take Personal Blender comes with a**two-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects and malfunctions under normal household use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

Customer Support

For technical assistance, warranty claims, or any questions regarding your Arzum product, please contact our customer support hotline:

Hot Line: 15789

(Please note: This hotline number is provided based on product information and may be specific to certain regions.)

© 2025 Arzum. All rights reserved. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B078W8FQ5M

More documents and user manuals: **https://manuals.plus/**