

Saitake BT 7002

Saitake BT 7002 Smartphone Joystick User Manual

Model: BT 7002 | Brand: Saitake

1. INTRODUCTION

Thank you for choosing the Saitake BT 7002 Smartphone Joystick. This device is designed to enhance your mobile gaming experience by providing precise control and comfortable ergonomics. It connects wirelessly via Bluetooth to your Android smartphone or tablet, offering a seamless gaming experience.

2. SETUP AND CONNECTION

2.1 First-Time Connection

1. Ensure the joystick is powered off.
2. Press and hold the **HOME** button for 5 seconds until the gamepad indicator light begins to flash rapidly (approximately 4 flashes per second). This indicates pairing mode.
3. On your Android device, activate Bluetooth and search for available devices.
4. Select the gamepad when it appears in your device list to connect.

2.2 Subsequent Connections

1. Ensure the joystick is powered off.
2. Press and hold the **HOME** button for 3 seconds until the gamepad indicator light flashes slowly (approximately 2 flashes per second).
3. The device will automatically connect to the last paired Android device.



Figure 1: Saitake BT 7002 Joystick with a smartphone attached, ready for gaming.

Note: The Saitake BT 7002 requires Bluetooth 2.0 or higher on your Android device. It does not require a driver for installation when connecting and playing. This controller is designed exclusively for Android devices and is **not compatible with iOS or PC systems**.

3. OPERATING MODES

The Saitake BT 7002 features different operating modes to optimize compatibility with various applications:

- **G Mode:** Designed for general Android gaming.
- **M Mode:** Optimized for Multimedia control.
- **I Mode:** Intended for specific iOS compatibility (though general product description states no iOS support, this mode might be for specific, limited scenarios or older models. For best results, use with Android as specified).

The controller supports wireless transmission via Bluetooth 2.1, allowing for an operating range of 6-8 meters.



Figure 2: The joystick in use with a smartphone during a racing game.

3.1 Automatic Power Off

To conserve battery life, the controller will automatically power off if it is not used for 5 minutes.

4. KEY FEATURES

- **Portable Design:** Pocket-sized for easy transport during travel.
- **Built-in Battery:** Features a 300mA built-in lithium battery, providing approximately 5-8 hours of continuous play.
- **Adjustable Phone Mount:** Accommodates smartphones up to 3.0 inches (7.5 cm) wide, supporting phones with screens smaller than 5.9 inches (15 cm).
- **Wide Compatibility:** Connects wirelessly to any Android mobile phone, tablet, or VR headset running Android 3.2 or above with Bluetooth 2.0 or higher.
- **Driver-Free:** No additional drivers are needed for installation.
- **Wireless Range:** Offers a wireless transmission range of 6-8 meters.



Figure 3: User holding the Saitake BT 7002 Joystick with a smartphone.

5. MAINTENANCE

5.1 Charging the Battery

When the battery is low, the indicator light may flash or the controller may stop responding. Connect the joystick to a USB power source using a compatible charging cable (not specified if included, typically micro-USB). The indicator light will show charging status and turn off when fully charged.

5.2 Cleaning and Storage

- Wipe the controller with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- Avoid exposing the controller to extreme temperatures, direct sunlight, or high humidity.
- Store the controller in a cool, dry place when not in use.

6. TROUBLESHOOTING

6.1 Controller Not Turning On or Responding

- Ensure the battery is charged. Connect the controller to a power source and allow it to charge for at least 30 minutes before attempting to power it on again.
- If the controller still does not respond, try pressing the **RESET** button (usually a small pinhole button, refer to diagram if available on product).

6.2 Connection Issues

- Make sure Bluetooth is enabled on your Android device.
- Ensure the controller is in pairing mode (rapid flashing for first-time connection, slow flashing for subsequent connections).
- Forget the device in your phone's Bluetooth settings and attempt to pair again.
- Ensure your Android device's operating system is Android 3.2 or above and has Bluetooth 2.0 or higher.
- Remember, this controller is **not compatible with iOS or PC systems**.

6.3 Games Not Recognizing Controller

- Verify that the game you are playing supports external game controllers. Not all mobile games have controller support.
- Check the game's settings for controller configuration options.
- Ensure the controller is in the correct operating mode (G Mode for most games).

7. SPECIFICATIONS







Model	BT 7002
Connectivity	Bluetooth 2.1
Battery Type	1 Lithium Ion (Built-in 300mA)
Battery Life	Approx. 5-8 hours (continuous play)
Operating Range	6-8 meters
Compatible Phone Width	Up to 3.0 inches (7.5 cm)
Supported Phone Screen Size	Below 5.9 inches (15 cm)
Package Dimensions	16.6 x 13.4 x 7 cm
Weight	125 g

8. WARRANTY INFORMATION

Please refer to the manufacturer's official website or the product packaging for detailed warranty information. Keep your purchase receipt as proof of purchase for any warranty claims.

9. CUSTOMER SUPPORT

For technical assistance, troubleshooting, or product inquiries, please contact Saitake customer support through their official website or the contact information provided with your product packaging.

	<p><u>STK-7038 Wireless Controller User Manual</u></p> <p>User manual for the STK-7038 Wireless Controller by Shenzhen Saitake Electronic Co., Ltd., detailing setup, features, and FCC compliance.</p>
	<p><u>STK-7009F Mobile Gaming Controller User Manual - Saitake</u></p> <p>Comprehensive user manual for the Saitake STK-7009F mobile gaming controller, covering setup, cloud gaming, key configuration, RGB lighting, and TURBO functions for Android and iOS devices.</p>
	<p><u>Saitake STK-7040RG Game Controller User Manual</u></p> <p>Comprehensive user manual for the Saitake STK-7040RG game controller, detailing its features, connectivity, and operation for various gaming platforms.</p>
	<p><u>Saitake STK-7032SN Wireless Gamepad for Nintendo Switch: User Manual</u></p> <p>Comprehensive user manual for the Saitake STK-7032SN wireless gamepad, covering pairing, connection, vibration and turbo speed adjustment, NFC functionality, PC X-Input mode, calibration, and warranty information.</p>
	<p><u>Saitake STK-7024S Wireless Gamepad User Manual</u></p> <p>User manual for the Saitake STK-7024S wireless gamepad, detailing first-time pairing, reconnection, vibration adjustment, and FCC compliance information.</p>
	<p><u>Saitake STK-7046 Portable Wireless Joypad User Manual</u></p> <p>User manual for the Saitake STK-7046 Portable Wireless Joypad, detailing installation, connection, features like Turbo and vibration, and troubleshooting steps for gaming consoles.</p>