Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Adesso 4191-01

Adesso 4191-01 Floor Lamp User Manual

Model: 4191-01 | Brand: Adesso

1. Introduction

The Adesso 4191-01 Piper LED Floor Lamp combines energy efficiency with a modern design, making it an ideal lighting solution for various spaces. Its thin silhouette and compact footprint allow it to fit perfectly in tight corners or smaller rooms. This manual provides essential information for the safe and effective use of your new floor lamp.



Figure 1: Front view of the Adesso 4191-01 Piper LED Floor Lamp, showcasing its sleek design and frosted cylinder shade.

2. Safety Information

Please read all safety instructions carefully before operating the lamp. Retain this manual for future reference.

- Ensure the lamp is connected to a 127 Volts (AC) power source.
- Do not attempt to replace the integrated LED lights. They are designed to last approximately 50,000 hours.
- This lamp is not compatible with smart outlets or external dimmer switches. Use only the integrated touch dimmer.
- Keep the lamp away from water or excessive moisture. It is not water resistant.
- Do not disassemble or modify the lamp. Any unauthorized modifications may void the warranty and pose safety risks.
- Ensure the lamp is placed on a stable, level surface to prevent tipping. The black marble base provides stability.



Figure 2: Adesso lighting products, including this lamp, are ETL and UL listed, confirming they meet government-regulated safety standards for the USA.

3. Package Contents

Carefully unpack the box and ensure all items are present and undamaged. If any parts are missing or damaged, please contact Adesso customer support.

- 1 x Adesso 4191-01 Floor Lamp (includes base, pole, and integrated LED shade)
- 1 x User Manual

4. Setup Instructions

Assembly of the Adesso 4191-01 Floor Lamp is straightforward and requires minimal effort.

1. Carefully remove all components from the packaging.
2. Place the heavy black marble base on your desired flat, stable surface.
3. Align the threaded end of the lamp pole with the opening in the base.
4. Gently screw the lamp pole into the base until it is securely tightened. Do not overtighten.

5. Ensure the lamp stands upright and is stable before proceeding.
6. Plug the power cord into a standard 127V AC electrical outlet.





Figure 3: Side view of the assembled lamp, illustrating its slender profile suitable for tight spaces.

5. Operating Instructions

The Adesso 4191-01 Floor Lamp features a convenient 4-way touch dimmer switch for easy control of lighting levels.

1. **Locate the Touch Switch:** The touch switch is discreetly located on the lower part of the brass section, just below the frosted cylinder shade.
2. **Turning On/Off:** Lightly tap the touch switch once to turn the lamp on. Tap it again to turn it off.
3. **Adjusting Brightness (4-Way Dimmer):**
    - First tap: Low brightness setting (mood lighting).
    - Second tap: Medium brightness setting.
    - Third tap: High brightness setting (bright ambient light for reading/work).
    - Fourth tap: Turns the lamp off.

Note: This lamp is designed for manual operation via its integrated touch switch and is not compatible with external smart outlets or wall switches that control power to the outlet. If connected to a switched outlet, the lamp will need to be manually turned on via its touch switch each time the outlet receives power.

6. Maintenance

To ensure the longevity and optimal performance of your Adesso 4191-01 Floor Lamp, follow these simple maintenance guidelines:

- **Cleaning:** Disconnect the lamp from the power outlet before cleaning. Use a soft, dry cloth to wipe down the metal and plastic surfaces. For the frosted shade, a slightly damp cloth can be used, followed by a dry cloth. Avoid abrasive cleaners or solvents, as they may damage the finish.
- **LED Care:** The integrated LED lights are designed for long-term use and do not require replacement. Avoid direct impact or excessive force on the frosted cylinder.
- **Stability Check:** Periodically check that the lamp pole is securely screwed into the base to maintain stability.

7. Troubleshooting

If you encounter any issues with your Adesso 4191-01 Floor Lamp, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Lamp does not turn on.	Not plugged in; power outlet is off; loose connection; faulty switch.	Ensure the power cord is fully plugged into a live outlet. Check if the wall switch (if any) is on. Tap the touch switch firmly. If the issue persists, contact customer support.
Lamp does not respond to touch switch.	Improper touch; power interruption.	Ensure you are tapping the designated touch switch area. Unplug the lamp for 30 seconds, then plug it back in and try again.
Light appears uneven or individual LEDs are visible.	Characteristic of the design.	This can be a characteristic of the lamp's design, especially at lower brightness settings or when viewed closely. It is not typically a defect.
Lamp does not work with smart outlet/wall switch.	Incompatibility.	The lamp is designed for manual operation via its integrated touch switch and is not compatible with external smart outlets or wall switches that cut power. It must be manually turned on after power is restored.

8. Specifications

Feature	Detail
Model Number	4191-01
Brand	Adesso
Lamp Type	Floor Lamp
Light Source Type	Integrated LED
Brightness	Up to 1200 Lumens
Color Temperature	3000 Kelvin (Warm Ambient)
LED Lifespan	Approx. 50,000 hours
Switch Type	4-Way Touch Dimmer
Power Source	Corded Electric
Voltage	127 Volts (AC)
Wattage	12 Watts
Product Dimensions	8.5"D x 8.5"W x 72"H
Item Weight	11.66 Pounds
Base Material	Marble

Feature	Detail
Shade Material	Frosted Plastic
Finish Type	Antique Brass / Matte Black
Certifications	ETL Listed, UL Listed
UPC	798919419111

9. Warranty and Support

Adesso stands behind the quality of its products. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Adesso website. If you require technical assistance, have questions about your lamp, or need to report a defect, please contact Adesso customer support:

- **Adesso Official Website:** www.adessohome.com (Please check for the most current contact information)
- **Customer Service:** Refer to the website for phone numbers or email contact forms.

When contacting support, please have your model number (4191-01) and purchase date readily available.

© 2024 Adesso. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B078WL46SB

More documents and user manuals: **https://manuals.plus/**