

[Manuals.plus](#) /

› [Runleader](#) /

› Runleader RL-KT001 9999 Days Events Timer Instruction Manual

Runleader RL-KT001

Runleader RL-KT001 9999 Days Events Timer Instruction Manual

Model: RL-KT001

1. INTRODUCTION

This manual provides detailed instructions for the operation and maintenance of your Runleader RL-KT001 9999 Days Events Timer. This digital timer is designed to count down to significant events, displaying days, hours, minutes, and seconds. It features a clear display, customizable faceplates, a backlight, and an audible reminder.



2. PRODUCT FEATURES

- **Large Digit Display:** Provides clear visibility of the countdown.
- **Extended Countdown Range:** Capable of counting down up to 9999 days.
- **Replaceable Faceplates:** Includes 5 decorative faceplates for various occasions.
- **Buzzer Alarm Reminder:** Emits an audible alert upon reaching the target time.
- **Backlight Function:** Illuminates the display for visibility in low-light conditions.
- **User-Replaceable Battery:** Designed for easy battery replacement.



Image 2.1: Visual representation of the timer's key features, including its large display, long countdown capability, replaceable faceplates, and alarm reminder.

3. SETUP

3.1 Package Contents

Before proceeding, please verify that all items are present in the package:

- Runleader RL-KT001 9999 Days Events Timer (x1)
- User Manual (x1)
- Colorful Sticker Faceplates (x5)

ACCESSORIES



Product*1



User manual*1

Box*1

Colorful sticker*5

Image 3.1: The accessories included with the Runleader RL-KT001 timer: the timer unit, user manual, and five colorful faceplates.

3.2 Battery Installation

The timer requires 1 Lithium Metal battery. To install or replace the battery:

1. Locate the battery compartment on the back of the timer.
2. Open the battery compartment cover.
3. Insert the Lithium Metal battery, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

4. OPERATING INSTRUCTIONS

4.1 Button Functions

The timer features five control buttons and a buzzer reminder on the back. Familiarize yourself with their functions:

No.	Button	Function
1	Finish	Access target time setting mode.

No.	Button	Function
2	Look	View the currently set target time.
3	Clear	Delete the current tracking event.
4	Enter	Confirm settings and begin tracking.
5	Current	Access current time setting mode.
6	Buzzer Reminder	Audible alarm output.




Image 4.1: Location and function of the control buttons and buzzer on the back of the timer.

4.2 Display Elements

The timer display shows the countdown in days, hours, minutes, and seconds:

No.	Symbol	Meaning
1	12 Hrs	Hours remaining.

No.	Symbol	Meaning
2	00 Min	Minutes remaining.
3	00 Sec	Seconds remaining.
4	317 Days	Days remaining.



Image 4.2: Explanation of the numerical display segments for hours, minutes, seconds, and days.

4.3 Setting Current Time

To ensure accurate countdowns, first set the current date and time:

1. Press the **Current** button to enter current time setting mode.
2. Use the arrow buttons (usually located on the side or near the setting buttons) to adjust the Year (2000-2099), Month (1-12), Day (1-31), Hour (0-23), Minute (0-59), and Second (0-59).
3. Press **Enter** to confirm each setting and move to the next, or to exit current time setting mode once all values are set.

4.4 Setting Target Time

After setting the current time, you can set your desired event countdown:

1. Press the **Finish** button to enter target time setting mode.
2. Use the arrow buttons to adjust the Target Year (2000-2099), Month (1-12), Day (1-31), Hour (0-23), Minute (0-59), and Second (0-59).
3. **Important:** The target time must be later than the current time.
4. Press **Enter** to confirm each setting and move to the next. Once all target values are set, press **Enter** again to begin the countdown tracking.




Image 4.3: Detailed instructions for setting both the current time and the target countdown time.

4.5 Viewing and Clearing Events

- To view the set target time without interrupting the countdown, press the**Look** button.
- To stop and clear an active countdown, press the**Clear** button.

4.6 Backlight Operation

The backlight is activated by pressing any button. It will remain illuminated for a short period to conserve battery life.

5. FACEPLATE REPLACEMENT

The Runleader RL-KT001 timer comes with five interchangeable faceplates to customize its appearance for different events or preferences. These faceplates are held in place by a magnetic frame.

1. Gently take down the magnetic frame from the front of the timer.
2. Remove the current faceplate.
3. Select your desired new faceplate and place it onto the timer's display area.
4. Reattach the magnetic frame to fix the new faceplate securely in position.



Image 5.1: Step-by-step guide for replacing the decorative faceplates using the magnetic frame.

6. MAINTENANCE

6.1 Cleaning

To clean the timer, use a soft, dry cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the display or casing.

6.2 Battery Replacement

When the display becomes dim or unresponsive, it is time to replace the battery. Refer to Section 3.2 for battery installation instructions. Always dispose of used batteries responsibly according to local regulations.

6.3 Storage

If storing the timer for an extended period, remove the battery to prevent leakage and potential damage to the device.

7. TROUBLESHOOTING

- **Display is blank or dim:** Check if the battery is correctly installed or needs replacement.
- **Countdown not starting:** Ensure the target time is set to a date and time later than the current time. Press the 'Enter' button after setting the target time.
- **Backlight not staying on:** The backlight is designed to illuminate temporarily after a button press to conserve battery. This is normal operation.
- **Incorrect time displayed:** Re-enter the current time and date carefully, following the steps in Section 4.3.

8. SPECIFICATIONS

Feature	Specification
Model Number	RL-KT001
Product Dimensions	2.52"D x 1.97"W x 5.2"H (64mm D x 50mm W x 132mm H)
Item Weight	0.5 Ounces (14.17 grams)
Power Source	1 Lithium Metal Battery (required)

Feature	Specification
Countdown Range	Up to 9999 Days
UPC	606412395231




Image 8.1: Detailed product dimensions of the Runleader RL-KT001 timer.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Runleader website. Keep your purchase receipt as proof of purchase.

