

[Manuals.plus](#) /

› [VINGLI](#) /

› VINGLI Portable 5.3 Gallon Camping Toilet Instruction Manual VLPT607

VINGLI VLPT607

VINGLI Portable 5.3 Gallon Camping Toilet Instruction Manual

Model: VLPT607

INTRODUCTION

This manual provides detailed instructions for the safe and effective use, setup, operation, and maintenance of your VINGLI Portable 5.3 Gallon Camping Toilet, Model VLPT607. Please read this manual thoroughly before initial use and retain it for future reference.



Image: The VINGLI Portable 5.3 Gallon Camping Toilet, shown fully assembled.

PRODUCT COMPONENTS

The VINGLI Portable Camping Toilet consists of two main detachable sections: the upper freshwater tank and the lower waste holding tank. Key features include:

- **Piston Pump:** For clean and strong flushing.
- **Water Tank Cap:** Secures the freshwater in the upper tank.
- **Rotatable Waste Pipe with Cap:** Allows for easy and anti-splash emptying of the waste tank.
- **Built-in Handle:** For easy carrying of the waste tank.
- **Level Indicator:** Displays when the waste tank is getting full (red indication).
- **Carrying Bag:** Included for convenient transport and storage.



Image: Detailed view of the portable toilet with its main components labeled, including the piston pump, water tank cap, rotatable waste pipe, built-in handle, and level indicator.



Each tank features handles and carrying bag for easy dumping and transportation

Image: The portable toilet shown alongside its included carrying bag, highlighting its portability.

SETUP INSTRUCTIONS

1. **Separate Tanks:** Ensure the upper freshwater tank and lower waste holding tank are securely latched together. If separated, align and press firmly until latched.
2. **Fill Freshwater Tank:** Unscrew the water tank cap on the upper section. Fill the freshwater tank with clean water. Securely replace the cap.
3. **Prepare Waste Tank:** For optimal odor control and waste breakdown, it is recommended to add approximately 0.5 gallons (2 liters) of fresh water and an RV black tank enzyme/deodorizer treatment to the waste holding tank before first use. This can be done by opening the waste valve and pouring the solution directly into the tank. Close the waste valve after adding.

1

Fill the
freshwater
tank



3

SIMPLE STEPS

3

Pour out the waste



2

Lift, push and flush



Image: Visual guide demonstrating the three primary steps: filling the freshwater tank, operating the flush mechanism, and emptying the waste tank.

OPERATING INSTRUCTIONS

1. **Open Waste Valve:** Before use, locate the handle on the front of the toilet. Pull this handle to open the valve, allowing waste to pass into the lower holding tank. It is important to open this valve slowly to prevent splash-back.
2. **Flushing:** After use, push the handle back to close the waste valve. Then, locate the piston pump on the upper tank. Pull the pump handle up and push down firmly and quickly to flush fresh water into the bowl. One firm pump is typically sufficient to rinse the bowl.
3. **Monitor Waste Level:** The toilet is equipped with a level indicator. When the indicator shows red, the waste tank is approaching full and requires emptying.



Level Indicator



T type 3 way flush



Rotating Spout



Image: Detailed view showing the level indicator, the T-type 3-way flush mechanism within the bowl, and the rotating spout for emptying.

MAINTENANCE AND CLEANING

Emptying the Waste Tank

1. Ensure the waste valve is closed.
2. Detach the upper freshwater tank from the lower waste holding tank.
3. Carry the waste tank using its built-in handle to an appropriate disposal site (e.g., RV dump station, regular toilet).
4. Unscrew the cap from the rotatable waste pipe and extend the pipe.
5. Carefully pour out the waste. The rotatable pipe helps prevent splashing.
6. After emptying, rinse the waste tank thoroughly with water. For enhanced cleaning and odor control, add a few ounces of bleach to the rinse water, swish it around, and let it sit for a few hours before emptying again.
7. Rinse both tanks again and allow them to air dry completely before reassembling or storing.

8. Apply a silicone lubricant to the valve seals periodically to maintain smooth operation and prevent leaks.

General Cleaning Tips

- Regularly clean the toilet bowl with a mild cleaner and a toilet brush.
- To minimize odors and tank volume, consider disposing of toilet paper in a separate waste bin rather than flushing it.
- For continuous odor control, add a few cups of bleach to the freshwater flush tank. This helps kill bacteria that cause odors.
- Thoroughly clean the flush valve on the interior side of the bowl with a high-pressure rinse when emptying the tank to remove any obstructions.

TROUBLESHOOTING

- **Splash-back during valve opening:** Always open the waste valve slowly and gently. Rapid opening can cause contents to splash back.
- **Odor issues:** Ensure the waste valve is fully closed after each use. Use recommended RV black tank treatments and consider adding bleach to the flush water. Regular and thorough cleaning of both tanks is essential.
- **Waste tank dripping:** If the orange dump spout drips, the waste tank may be over 90% full. Empty the tank immediately to prevent leaks. Ensure the cap on the rotatable waste pipe is securely fastened.
- **Flushing issues:** If the flush is weak or inconsistent, check the freshwater tank level. Ensure the piston pump is operated firmly and quickly. Clean the flush valve thoroughly to remove any obstructions.

SPECIFICATIONS

Feature	Detail
Model Number	VLPT607
Brand	VINGLI
Color	Gray
Product Dimensions (D x W x H)	16.5" x 14.6" x 17.3"
Material	High Density Polyethylene Plastic
Item Weight	7.98 pounds
Waste Tank Capacity	5.3 Gallons
Installation Type	Free Standing
Included Components	Portable Toilet, Foldable Carrying Bag



Image: Diagram illustrating the dimensions (height, width, depth) of the VINGLI Portable Camping Toilet.

USAGE SCENARIOS

The VINGLI Portable Camping Toilet is designed for versatility and convenience in various outdoor and travel settings. Its compact and detachable design makes it suitable for:

- Camping and Hiking
- Boating and Fishing
- RV and Van Travel
- Road Trips
- Emergency Preparedness



Camping



Boating



Image: Examples of the portable toilet being used in different environments, including a tent campsite, on a boat deck, in a car trunk, and beside an RV.

WARRANTY AND SUPPORT

Information regarding product warranty and customer support was not provided in the available product data. For any inquiries or support needs, please refer to the contact information provided by your retailer or the manufacturer's official website, if available.

OFFICIAL PRODUCT VIDEOS

No official product videos from the seller were found in the provided data for this model.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question