Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Whirlpool W10860255

Whirlpool W10860255 Microwave Metal Rack User Manual

Model: W10860255 | Brand: Whirlpool

Introduction

This manual provides essential information for the proper use and care of your Whirlpool W10860255 Microwave Metal Rack. This accessory is designed to provide a stable surface for cookware within your microwave oven, particularly for convection or baking functions. It is a genuine Whirlpool accessory, ensuring compatibility and quality.



Image: Front view of the Whirlpool W10860255 Microwave Metal Rack, a rectangular metal grid with support feet.

Setup and Installation

The Whirlpool W10860255 Microwave Metal Rack is designed for straightforward placement and does not require any tools, disassembly, or prior repair experience for installation.

1. Ensure your microwave oven is clean and free of debris before placing the rack.

2. Carefully place the metal rack inside the microwave oven cavity. Position it securely on the microwave's floor or designated support points, ensuring it is level and stable.
3. Verify that the rack does not obstruct the microwave's turntable (if applicable) or any internal sensors.




Image: Angled view of the Whirlpool W10860255 Microwave Metal Rack, showing its sturdy construction.

Operating Instructions

This metal rack is specifically designed for use during **convection cooking or baking functions** within your microwave oven. It is crucial to understand its intended use to prevent damage to the appliance or the rack itself.

- **Convection/Baking Use:** Place cookware directly on the metal rack when using the microwave's convection or baking modes. The rack allows for proper air circulation around the food, facilitating even cooking and browning.
- **Important Restriction:** *Do not leave the metal rack inside the microwave oven when using standard microwave (non-convection) functions.* Metal objects can cause arcing and damage the microwave oven during standard microwave operation. Remove the rack before using any non-convection cooking modes.

- Ensure cookware placed on the rack is microwave-safe and suitable for the selected cooking mode.

Maintenance and Care

To ensure the longevity and cleanliness of your microwave metal rack, follow these maintenance guidelines:

- **Cleaning:** Clean the rack regularly after use. It can be washed by hand with warm, soapy water and a soft cloth or sponge. For stubborn food residues, a non-abrasive cleaner can be used.
- **Drying:** Thoroughly dry the rack after washing to prevent water spots or corrosion.
- **Storage:** Store the rack in a clean, dry place when not in use, especially when not performing convection or baking functions in the microwave.

Troubleshooting

This simple accessory typically requires minimal troubleshooting. However, consider the following if you encounter issues:

- **Rack does not fit:** Verify that your microwave model number is compatible with the W10860255 rack. Refer to your microwave's user manual or Whirlpool's compatibility list.
- **Arcing during operation:** This is a critical safety concern. If arcing occurs, immediately stop the microwave. Ensure the rack is only used during convection or baking modes and is removed for all other microwave functions. Ensure no other metal objects are inside the microwave during operation.
- **Rack appears unstable:** Ensure the rack is placed on a flat, stable surface within the microwave cavity. Check for any obstructions or unevenness.

Specifications

Feature	Detail
Brand Name	Whirlpool
Model Info	W10860255
Item Weight	1.96 pounds
Product Dimensions	26 x 18 x 0.25 inches
Part Number	W10860255
Included Components	CONVECTION COOKING RACK
Installation	No tools required
Replacement For	W10637931
Compatible Model Example	Jmv9196Cs

Warranty and Support

The Whirlpool W10860255 Microwave Metal Rack is a Factory Certified Accessory, signifying that it meets Whirlpool's strict quality specifications and engineering standards. This ensures it is designed specifically for your appliance.



Image: Banner highlighting Whirlpool Genuine OEM Parts & Accessories, designed to meet tested engineering standards.

For specific warranty details, claims, or technical support, please contact Whirlpool Customer Service directly. You can find contact information on the official Whirlpool website or through the documentation provided with your microwave oven.
For more information and support, visit the official Whirlpool website: www.whirlpool.com

© 2024 Whirlpool Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B078Z4SSW2

More documents and user manuals: **https://manuals.plus/**