

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Hama](#) /

› [Hama Anzano USB QWERTZ German Keyboard Instruction Manual](#)

Hama 00182663

Hama Anzano USB QWERTZ German Keyboard Instruction Manual

Model: 00182663

INTRODUCTION

Thank you for choosing the Hama Anzano USB QWERTZ German Keyboard. This manual provides essential information for the safe and efficient operation of your new keyboard. Please read these instructions carefully before use and keep them for future reference.

PRODUCT OVERVIEW

The Hama Anzano keyboard is a standard-sized, wired USB keyboard designed for office and general computer use. It features a QWERTZ German key layout, 113 keys, and integrated multimedia keys for enhanced functionality. A distinctive side reflector strip provides ambient backlighting, which can be activated or deactivated as needed.



Figure 1: Angled view of the Hama Anzano keyboard, highlighting its design and side lighting.

SETUP

- Unpack the Keyboard:** Carefully remove the keyboard from its packaging. Ensure all components are present and undamaged.
- Connect to Computer:** The Hama Anzano keyboard uses a standard USB connection. Locate an available USB port on your computer.
- Plug-and-Play:** Insert the USB connector of the keyboard into the USB port on your computer. The keyboard is plug-and-play, meaning it should be automatically recognized by your operating system without the need for additional driver installation.
- System Compatibility:** The keyboard is compatible with Windows 7, Windows 8, and Windows 10 operating systems.



Figure 2: Top-down view of the keyboard, showing the QWERTZ German layout and multimedia keys.

OPERATING INSTRUCTIONS

Basic Typing

The keyboard functions as a standard input device. Simply begin typing to enter text into any compatible application on your computer.

Multimedia Keys

The Hama Anzano keyboard includes eight dedicated multimedia keys located above the function keys (F1-F12). These keys provide quick access to common functions such as:

- Volume control (up, down, mute)
- Media playback control (play/pause, stop, previous track, next track)
- Web browser home page
- Email client

Press the desired multimedia key to activate its corresponding function. Specific functionality may vary depending on your operating system and software configuration.

Backlighting Control

The keyboard features a side reflector strip with ambient backlighting. This lighting can be toggled on or off using a dedicated key. Refer to the keyboard layout (Figure 2) to locate the backlight control key, typically found near the function keys or multimedia keys. Press this key to activate or deactivate the lighting feature

according to your preference.

MAINTENANCE

To ensure the longevity and optimal performance of your Hama Anzano keyboard, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the keyboard with a soft, dry, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid using harsh chemicals, abrasive cleaners, or solvents.
- **Dust Removal:** Use compressed air to remove dust and debris from between the keys. Hold the can upright and spray in short bursts.
- **Liquid Spills:** In case of a liquid spill, immediately disconnect the keyboard from your computer. Turn it upside down to drain as much liquid as possible. Allow it to dry completely for at least 24-48 hours before reconnecting. Do not attempt to use the keyboard if it is still wet.
- **Storage:** When not in use for extended periods, store the keyboard in a clean, dry environment away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your Hama Anzano keyboard, refer to the following common troubleshooting steps:

- **Keyboard Not Responding:**

- Ensure the USB cable is securely connected to both the keyboard and the computer's USB port.
- Try connecting the keyboard to a different USB port on your computer.
- Test the keyboard on another computer to determine if the issue is with the keyboard or your computer's setup.
- Restart your computer.

- **Keys Not Functioning Correctly:**

- Check for any physical obstructions or debris under the affected keys.
- Ensure the keyboard is clean (refer to the Maintenance section).
- Verify that no software conflicts are present by testing in a different application or after a system restart.

- **Backlighting Not Working:**

- Press the dedicated backlight control key to ensure it is activated.
- Ensure the keyboard is properly connected and receiving power.

If these steps do not resolve the issue, please contact Hama customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Brand	Hama

Feature	Detail
Model Number	00182663
Connectivity Technology	Wired USB
Keyboard Layout	QWERTZ (German)
Number of Keys	113
Special Features	Multimedia keys, Side backlighting (toggleable)
Recommended Use	Office / PC / Server
Compatible Devices	Computer
Operating System Support	Windows 10, Windows 7, Windows 8
Color	Black
Keyboard Dimensions (LxWxH)	450 x 154 x 12 mm
Power Source	USB powered



Figure 3: Bottom view of the keyboard, illustrating its construction and adjustable feet.

WARRANTY AND SUPPORT

Hama products are subject to statutory warranty regulations. For specific warranty terms and conditions, please refer to the documentation included with your purchase or visit the official Hama website. If you require technical support or have questions regarding your Hama Anzano keyboard, please contact Hama customer service through their official channels.

For more information, visit: www.hama.com