

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [MindKoo](#) /

> [MindKoo 33-inch Bluetooth Soundbar User Manual](#)

MindKoo MK-BR01#DE

MindKoo 33-inch Bluetooth Soundbar User Manual

Model: MK-BR01#DE | Brand: MindKoo

1. INTRODUCTION

Thank you for choosing the MindKoo 33-inch Bluetooth Soundbar. This powerful 2.0 channel soundbar is designed to enhance your home entertainment experience with rich, clear audio and powerful bass. It offers versatile connectivity options, including Bluetooth for wireless streaming and wired connections via Optical, AUX, and RCA. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure you get the most out of your new soundbar.



Image 1.1: The MindKoo 33-inch Bluetooth Soundbar and its remote control.

2. PACKAGE CONTENTS


Please check the package carefully to ensure all items are present and in good condition:

- MindKoo 33-inch Bluetooth Soundbar
- Remote Control

- User Guide
- 3.5mm RCA Audio Cable
- Optical Cable
- Wall Mounting Screws and Anchors



MindKoo Soundbar (Model:MK-BR01)



Position Karte



Dank-Karte



Bedienungsanleitung



Fernbedienung



3.5mm RCA Audio Kabel



Optical Kabel



Schrauben

Image 2.1: All components included in the MindKoo Soundbar package: soundbar, remote, user guide, RCA cable, optical cable, and mounting hardware.

3. PRODUCT OVERVIEW

3.1 Rear Panel Connections

The rear panel of the soundbar features various input ports for connecting to your audio sources.



Image 3.1: Rear view of the soundbar showing the Main Power ON/OFF Switch, RCA (L,R) Input, Coaxial Input, 3.5mm Aux-in Input, and Optical Input.

3.2 Remote Control Functions

The included remote control allows for convenient operation of all soundbar functions.

LEICHTE BEDIENUNG MIT FERNBEDIENUNG




Image 3.2: Diagram of the remote control highlighting buttons for Standby, Mute, Bluetooth, Coaxial, Optical, and AUX/RCA Input Mode selection.

4. SETUP

4.1 Placement Options

The MindKoo Soundbar can be placed directly on a table or mounted on the wall below your TV.

MODISCHES DESIGN & EINFACHE BEDIENUNG

Platzieren auf dem Tisch oder hängen an die Wand



Platzieren auf dem Tisch



Platzieren auf dem Tisch



Image 4.1: The soundbar can be placed on a table or mounted on the wall for optimal sound projection.

4.2 Connecting to Your TV or Audio Source

Choose one of the following methods to connect your soundbar to your audio source:

4.2.1 Bluetooth Connection

1. Ensure the soundbar is powered on.
2. Press the 'BT' button on the remote control or the physical button on the soundbar to switch to Bluetooth mode. The LED indicator will flash.
3. Enable Bluetooth on your device (e.g., smartphone, tablet, TV) and search for 'MindKoo Soundbar'.
4. Select 'MindKoo Soundbar' from the list to pair. Once connected, the LED indicator will stop flashing and remain solid.

4.2.2 Optical Connection

1. Connect one end of the optical cable to the 'Optical Out' port on your TV and the other end to the 'Optical Input' port on the soundbar.
2. Press the 'OPT' button on the remote control to select Optical input.

3. Ensure your TV's audio output settings are set to 'PCM' or 'Optical Out'.

4.2.3 AUX (3.5mm) Connection

1. Connect one end of a 3.5mm audio cable (not included) to the headphone jack or AUX output of your device and the other end to the '3.5mm Aux-in Input' on the soundbar.
2. Press the 'AUX' button on the remote control to select AUX input.

4.2.4 RCA Connection

1. Connect the RCA audio cable (included) to the 'RCA (L,R) Input' ports on the soundbar, matching the red and white connectors.
2. Connect the other end of the RCA cable to the corresponding 'Audio Out' ports on your TV or audio source.
3. Press the 'AUX' button on the remote control to select RCA input (often shared with AUX).



Image 4.2: The soundbar positioned below a television, demonstrating its role in a home theater setup for improved audio quality.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- To power on the soundbar, ensure the Main Power ON/OFF switch on the rear panel is in the 'ON' position, then press the **Standby** button on the remote control or the power button on the soundbar.
- To power off, press the **Standby** button again.

5.2 Selecting Input Mode

Press the corresponding input buttons on the remote control (e.g., **BT** for Bluetooth, **OPT** for Optical, **COX** for Coaxial, **AUX** for AUX/RCA) to switch between audio sources. The LED indicator on the soundbar will change color to indicate the selected mode.

5.3 Volume Control

- Use the **Volume Up (+)** and **Volume Down (-)** buttons on the remote control or the soundbar to adjust the volume.
- Press the **Mute** button to temporarily silence the sound. Press it again to restore audio.

5.4 Playback Control (Bluetooth Mode)

- Press **Play/Pause** to play or pause the current track.
- Press **Previous Track** to go to the beginning of the current track or the previous track.
- Press **Next Track** to skip to the next track.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your soundbar.

6.1 Cleaning

- Always unplug the soundbar from the power outlet before cleaning.
- Use a soft, dry cloth to wipe the exterior surfaces.
- Do not use liquid cleaners, abrasive cleaners, or spray cleaners, as they may damage the finish or internal components.

6.2 Storage

- If storing the soundbar for an extended period, unplug it from the power source.
- Store it in a cool, dry place, away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you encounter any issues with your MindKoo Soundbar, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from the soundbar.	<ul style="list-style-type: none"> • Soundbar is not powered on. • Incorrect input mode selected. • Volume is too low or muted. • Cables are not connected properly. • TV audio output settings are incorrect. 	<ul style="list-style-type: none"> • Ensure the soundbar is powered on and the main switch is ON. • Press the correct input button on the remote (BT, OPT, AUX, COX). • Increase volume or unmute the soundbar. • Check all cable connections (Optical, RCA, AUX). • For Optical connection, set TV audio output to PCM.
Bluetooth pairing fails.	<ul style="list-style-type: none"> • Soundbar is not in Bluetooth pairing mode. • Device is too far from the soundbar. • Interference from other devices. 	<ul style="list-style-type: none"> • Ensure the soundbar is in Bluetooth mode (flashing LED). • Move your device closer to the soundbar (within 10 meters). • Turn off other Bluetooth devices nearby. • Try unpairing and re-pairing the device.
Remote control not working.	<ul style="list-style-type: none"> • Batteries are dead or inserted incorrectly. • Obstruction between remote and soundbar. • Remote sensor on soundbar is blocked. 	<ul style="list-style-type: none"> • Replace batteries with new ones, ensuring correct polarity. • Remove any obstructions. • Ensure the remote sensor on the soundbar is clear.

8. SPECIFICATIONS

Detailed technical specifications for the MindKoo Soundbar:

Feature	Specification
Model Number	MK-BR01#DE
Color	Black
Product Dimensions	84 x 11 x 5.5 cm (33 inches long)
Item Weight	2.54 Kilograms
Speaker Maximum Output Power	40 Watts

Feature	Specification
Audio Output Mode	Stereo (2.0 Channels)
Connectivity Technology	Bluetooth, AUX, RCA, Optical, Coaxial
Mounting Type	Tabletop, Wall Mount
Special Feature	Remote Control
Recommended Uses	For surround sound audio systems
Compatible Devices	TV, Computer, MP3/MP4 Players, Notebooks, Tablets, Smartphones, Game Consoles

33-ZOLL SOUNDBAR FÜR TV(42-55 ZOLL)



Image 8.1: The 33-inch soundbar is designed to complement TVs ranging from 42 to 55 inches.

RIESIGE KOMPATIBILITÄT

TV, Computer, MP3, MP4, Notebooks, Tablets, Smartphones, Games consoles



Image 8.2: The soundbar offers broad compatibility with devices such as televisions, notebook computers, mobile phones, tablet PCs, desktop computers, MP3/MP4 players, and projectors.

9. WARRANTY AND SUPPORT

MindKoo is committed to providing high-quality products and customer satisfaction. For warranty information, technical support, or to register your product, please visit the official MindKoo website.

You can also scan the QR code found in your package or visit the following link for more information:

<http://www.mindkoo.com/signup>

Please retain your proof of purchase for any warranty claims.

