

[Manuals.plus](#) /

› [LKPower](#) /

› LKPower AC/DC Adapter Instruction Manual for Models G32DD-050400-A and G3200-050400-A (5V 4A)

LKPower 180115780

LKPower AC/DC Adapter Instruction Manual

Models: G32DD-050400-A, G3200-050400-A, 180115780

1. INTRODUCTION

This LKPower AC/DC Adapter is designed to provide reliable power to your compatible electronic devices. It efficiently converts standard AC wall power into the DC power required by your device, making it suitable for both home use and travel. This adapter has been rigorously tested to ensure compatibility and performance with models G32DD-050400-A and G3200-050400-A.

Cable Length: 127.8 inch




Image of the LKPower AC/DC adapter unit, showing its compact black casing and the DC output connector.

2. SAFETY INFORMATION

Please read and understand all safety instructions before using this product to prevent injury or damage.

- **Read all instructions:** Ensure you have read and understood this manual completely before operation.
- **Avoid liquids:** Do not expose the adapter to water, rain, or any other liquids.
- **Compatible devices only:** Use this adapter only with devices that match its voltage (5V) and current (4A) specifications. Using an incompatible adapter may damage your device.
- **Unplug when not in use:** Disconnect the adapter from the power outlet when not in use for extended periods.
- **Keep away from children:** Store the adapter out of reach of children.
- **Ventilation:** Ensure adequate ventilation around the adapter during use to prevent overheating. Do not cover the adapter.
- **Damage:** Do not use the adapter if the cord or plug is damaged. Contact customer support for assistance.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x LKPower AC/DC Adapter (Model 180115780)
- 1 x AC Power Cord



Image of the detachable AC power cord with a two-prong plug on one end and a figure-8 connector on the other, designed to connect to the adapter.

4. SETUP

Follow these steps to set up your LKPower AC/DC Adapter:

1. **Connect the AC power cord:** Insert the figure-8 connector of the AC power cord firmly into the corresponding port on the LKPower AC/DC adapter.

2. **Plug into wall outlet:** Insert the two-prong plug of the AC power cord into a standard wall power outlet (AC 100-240V, 50/61Hz).
3. **Connect to device:** Connect the DC output plug of the adapter to the power input port of your compatible electronic device.



The LKPower AC/DC adapter connected to a wall outlet and a device, demonstrating a typical setup on a desk next to a plant and a globe.

5. OPERATING INSTRUCTIONS

Once properly connected, the LKPower AC/DC Adapter will automatically begin supplying power to your device or charging its battery.

- **Power Supply:** The adapter provides a stable 5V DC output at 4A, suitable for devices requiring this power profile.
- **Protection Features:** The adapter is equipped with built-in over-voltage and over-heat protection mechanisms to ensure safe and reliable operation for both the adapter and your connected device.
- **Indicator Light:** A small LED indicator on the adapter may illuminate when connected to power, indicating

operational status.

6. MAINTENANCE

Proper care will extend the life of your LKPower AC/DC Adapter:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **No user-serviceable parts:** Do not attempt to open, modify, or repair the adapter. This will void any warranty and may pose a safety risk.

7. TROUBLESHOOTING

If you encounter issues with your LKPower AC/DC Adapter, try the following:

- **Device not powering on or charging:**
 - Ensure all connections (AC cord to adapter, adapter to wall outlet, adapter to device) are secure and fully inserted.
 - Verify that the wall outlet is functional by testing it with another device.
 - Confirm that your device's power requirements (voltage and current) match the adapter's specifications (5V 4A).
 - Inspect the adapter and cables for any visible damage. If damaged, discontinue use.
- **Adapter feels excessively hot:**
 - A slight warmth during operation is normal. However, if the adapter becomes excessively hot to the touch, immediately unplug it from the wall outlet and your device.
 - Ensure the adapter has proper ventilation and is not covered.
 - Check if the connected device is drawing too much power or has an internal fault.

8. SPECIFICATIONS

Brand	LKPower
Model Number	180115780
Input Voltage	AC 100-240V, 50/61Hz
Output Voltage	DC 5V
Output Current	4A
Power Source	Corded Electric
Protection Features	Over Voltage Protection, Over Heat Protection
Compatible Models	G32DD-050400-A, G3200-050400-A
Total Cable Length	Approx. 127.8 inches (324.6 cm)

Diagram illustrating the dimensions of the LKPower AC/DC adapter and its connected cables, showing a total cable length of approximately 127.8 inches.

9. WARRANTY INFORMATION

Specific warranty details for this LKPower AC/DC Adapter are not provided within this manual. For information regarding product warranty, including terms, conditions, and duration, please refer to the product packaging, any included warranty cards, or contact the manufacturer directly.

10. CUSTOMER SUPPORT

If you require further assistance, have questions about your LKPower AC/DC Adapter, or need to report an issue, please contact customer support:

- **Manufacturer Website:** Visit the official LKPower website for support resources and contact information.
- **Retailer Support:** Contact the retailer from whom you purchased the product for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question