Ingenuity 11576

Ingenuity Baby Base 2-in-1 Seat - Instruction Manual

Model: 11576 | Brand: Ingenuity

1. PRODUCT OVERVIEW

The Ingenuity Baby Base 2-in-1 Booster Seat is designed to provide a safe and comfortable seating solution for your child during meal times and playtime. This versatile seat easily transitions from a floor seat for infants to a booster seat for toddlers, attaching securely to most dining chairs. Its thoughtful design includes a removable tray that stores conveniently within the seat, and materials that are easy to clean, ensuring more family time and less clean-up.

Key Features:

- Wipeable feeding seat and tray for easier cleaning.
- Safe and secure baby seat for sitting up.
- Converts from baby booster to toddler seat.
- Removable tray stores neatly under the booster seat.
- Mealtime seat for at home or on the go use.
- BPA-Free Tray.

2. IMPORTANT SAFETY INFORMATION

WARNING: Infants have suffered skull fractures falling while in and from floor seats.

- USE ONLY on the floor.
- NEVER use on an elevated surface.
- ALWAYS use the restraint system. Adjust to fit snugly.
- NEVER lift or carry child in the product.
- STOP USING when the child can climb out or walk.
- ALWAYS keep child in view while in product.
- **DROWNING HAZARD: Infants have drowned when floor seat has been placed in a bathtub or pool. NEVER use in or near water.**

- Suggested Age: 6 Months and Up.
- Do not immerse in water.

Always ensure your child meets the minimum age and developmental requirements (able to hold head up unassisted) before using this product.

3. COMPONENTS

- Main Seat Base (White/Gray)
- Soft Foam Insert (Gray)
- Removable Tray (White)
- 3-Point Harness System
- Chair Attachment Straps (Gray)

Figure 3.1: Overview of the Ingenuity Baby Base 2-in-1 Seat with its main components.

4. Setup and Assembly

4.1 Attaching the Tray

1. Locate the removable tray stored underneath the seat base. Pull it out from the storage compartment.

2. Align the tray with the slots on either side of the seat.

3. Push the tray firmly into place until you hear a click on both sides, indicating it is securely locked.


Bandeja Removível
Bandeja removível de forma simples, dando mais autonomia para os pais, ela também é livre de BPA e pode ser limpa com facilidade

Sem ocupar Espaço
Quando não estiver usando, a bandeja pode ser guardada em um compartimento em baixo do assento

Figure 4.1: The removable tray conveniently stores underneath the seat when not in use.

4.2 Converting to Toddler Seat (Removing Foam Insert)

1. To convert the seat for a growing toddler, gently pull the soft foam insert upwards and out of the main seat base.

2. Store the foam insert in a safe place for future use or if transitioning back to infant mode.

Figure 4.2: The foam insert can be easily removed to accommodate growing toddlers.

5. OPERATING INSTRUCTIONS

5.1 Using as a Floor Seat

- Place the seat on a flat, stable floor surface.
- Ensure the 3-point harness is unbuckled.
- Carefully place your child into the seat, ensuring their legs are comfortably positioned in the leg openings.
- Buckle the 3-point harness securely around your child. Adjust straps to fit snugly.
- Attach the tray if desired for feeding or playtime.

Mais Segurança
Vem acompanhado de cinto de três pontos, garantindo segurança e evitando que o bebê se desprenda do assento

Protetor Entrepernas
Conta com protetor entrepernas, que também é almofadado, seguindo o mesmo padrão do assento

Figure 5.1: The seat provides a secure and upright position for infants on the floor.

5.2 Using as a Booster Seat

1. Place the seat on a sturdy adult dining chair. Ensure the chair has a backrest.

2. Locate the chair attachment straps on the underside and back of the booster seat.

3. Securely fasten the straps around the adult chair's backrest and underneath the seat, tightening them to ensure the booster seat is stable and does not move.

4. Place your child in the booster seat and secure them with the 3-point harness, adjusting for a snug fit.

5. Attach the tray if desired.

Figure 5.2: The seat can be securely attached to an adult chair for use as a booster.

5.3 Securing the Child with Harness

- Once the child is in the seat, bring the two side straps of the 3-point harness over their hips.
- Insert the buckles from the side straps into the center buckle until they click securely.
- Pull on the adjustable straps to ensure a snug and safe fit around your child.

Figure 5.3: Always use the 3-point harness to keep your child secure.

6. Maintenance and Cleaning

- The seat and tray are wipeable for easy cleaning.
- The tray is dishwasher-safe for thorough cleaning.
- For general cleaning, spot or wipe clean with a damp cloth and mild soap.
- The soft foam insert can be removed for separate cleaning.
- Do not immerse the entire seat in water.

Figure 6.1: The wipeable surfaces make cleaning quick and easy after meals.

7. TROUBLESHOOTING

- **Tray difficult to attach/remove:** Ensure buttons on both sides are fully depressed when attaching or removing the tray. Check for any food debris or obstructions in the slots.
- **Seat feels unstable on adult chair:** Verify that all chair attachment straps are securely fastened and tightened around the adult chair's backrest and underside. Ensure the adult chair itself is stable and suitable for booster seat use.
- **Child not fitting comfortably:** For older or larger children, ensure the soft foam insert has been removed to provide more space. Always check the maximum weight recommendation.

8. SPECIFICATIONS

Attribute	Value
Product Dimensions	16 x 15.88 x 7.25 inches
Item Model Number	11576
Maximum Weight Recommendation	23 Kilograms (approx. 50 lbs)
Material Type	Alloy Steel, Polypropylene, Polyurethane
Is Portable	Yes
Item Weight	4.99 pounds (approx. 2.27 Kilograms)
Color	Slate

9. WARRANTY AND SUPPORT

For warranty information, product registration, or further support, please refer to the manufacturer's official website or contact their customer service directly. Keep your purchase receipt for proof of purchase.

Manufacturer: Ingenuity