

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Ingenuity](#) /
- › [Ingenuity Baby Base 2-in-1 Booster and Floor Seat Instruction Manual](#)

Ingenuity 11579-2

Ingenuity Baby Base 2-in-1 Booster and Floor Seat Instruction Manual

MODEL: 11579-2

Brand: Ingenuity

Introduction

The Ingenuity Baby Base 2-in-1 Booster and Floor Seat is designed to provide a safe and comfortable seating solution for your child during feeding and playtime. This versatile product functions as both a floor seat for infants and a booster seat that can be securely attached to most dining chairs. It features a removable tray and a foam insert that can be removed as your child grows, adapting from baby to toddler use.

Booster Seat



Floor Seat



Ingenuity Baby Base 2-in-1 Booster and Floor Seat in both booster and floor modes.

Important Safety Warnings

Please read and understand all instructions and warnings before using this product. Failure to follow these warnings and instructions could result in serious injury or death.

- **FALL HAZARD:** Children have sustained skull fractures falling while in and from floor seats. Use **ONLY** on the floor. **NEVER** use on an elevated surface.
- Use only with a child who is able to sit up unassisted.
- Always secure child in the restraint system. Adjust to fit snugly.
- **NEVER** use in a motor vehicle.
- **NEVER** use in a bath tub or pool.
- **NEVER** lift or carry child in the product.
- **NEVER** leave child unattended.

Product Components

Before assembly, ensure all components are present:


- Seat Base
- Foam Insert
- Removable Tray
- Chair Straps (stored underneath the base)
- 3-Point Harness System

Setup Instructions

1. Assembling the Seat Back

1. Turn the seat base over.
2. Remove the seat back and chair straps from underneath the base.
3. Place the seat back onto the top of the base. Ensure it snaps securely into place.

Note: The seat back is designed for permanent installation and is not removable after it has been placed onto the base.



To assemble, remove the seat back and straps from underneath.

Step 1 of assembly: Remove the seat back and straps from underneath the base.



Back not removable after installation

Attaching the seat back to the base. Note: The back is not removable after initial installation.

2. Attaching and Storing the Tray

- To attach the tray, align the tray with the slots on the sides of the seat and slide it forward until it clicks into place.
- To remove the tray, press the release buttons on both sides of the seat and slide the tray backward.
- For convenient storage, the tray can be tucked away neatly underneath the booster seat.



Attaching the tray to the booster seat for feeding.



The removable tray stores neatly underneath the booster seat when not in use.

3. Storing Chair Straps

The chair straps are stored in a compartment underneath the seat base. When not in use, ensure they are securely tucked away to prevent loss or damage.



The chair straps are conveniently stored underneath the seat base.

Setup Video Overview

Your browser does not support the video tag.

Product overview video demonstrating the Ingenuity Baby Base 2-in-1 Booster and Floor Seat's compact design, tray storage, and versatility for small spaces and travel.

Operating Instructions

1. Using as a Floor Seat

Place the seat directly on the floor. Ensure the child is able to sit up unassisted before placing them in the seat. Always secure the child with the 3-point harness.



A baby comfortably seated in the Ingenuity Baby Base as a floor seat.



A baby playing in the floor seat, demonstrating its use during playtime.

2. Using as a Booster Seat

To use as a booster seat, retrieve the chair straps from the storage compartment. Securely attach the booster seat to a dining chair using both the bottom straps (22 inches with placement 5 inches up each side of the base) and the back strap (36 inches). Ensure the booster seat is stable and does not move before placing your child in it. Always secure the child with the 3-point harness.



An adult feeding a baby in the booster seat, securely attached to a dining chair.



A child using the booster seat in toddler mode, attached to a dining chair.

3. Harness Usage

The 3-point harness system ensures your child's safety. Adjust the straps to fit snugly around your child. Always ensure the harness is properly buckled and adjusted before leaving your child in the seat.



Securing the child with the adjustable 3-point harness.

4. Converting to Toddler Seat

As your child grows, the soft foam insert can be removed to provide more space, converting the baby booster into a toddler seat.

Easily
remove
for toddler
mode



Removing the foam insert to convert the booster for an older child.



The foam insert can be easily removed to accommodate growing toddlers.

Informational Video on Baby Seating

Your browser does not support the video tag.

Informational video from a pediatric physiotherapist discussing the importance of proper seating posture for babies, highlighting benefits for head control, digestion, and hip development.

Maintenance and Cleaning

Regular cleaning will help maintain the hygiene and longevity of your Ingenuity Baby Base.

- **Plastic Parts/Foam Insert:** Wipe clean with a damp cloth and mild soap. Air dry thoroughly. Do not immerse in water.
- **Tray:** The removable tray is dishwasher safe for thorough cleaning.



Wiping down the tray for quick and easy cleaning.



The tray is dishwasher safe for easy cleaning.

Troubleshooting

If you encounter any issues with your Ingenuity Baby Base, please refer to the following common solutions:

- **Seat not stable on dining chair:** Ensure all chair straps are securely fastened and adjusted tightly around the dining chair. Verify that the chair itself is stable and suitable for booster seat use.
- **Tray not attaching/detaching smoothly:** Check for any food debris or obstructions in the tray slots. Ensure the release buttons are fully pressed when detaching, and the tray is properly aligned when attaching.
- **Child not secure in harness:** Always adjust the 3-point harness snugly around your child. Ensure the buckle is fully engaged.

For further assistance, please contact Ingenuity customer support.

Specifications

| | |
|--------------------------------------|---|
| Model Number | 11579-2 |
| Product Dimensions | 17.25 x 15.25 x 11.75 inches (43.82 x 38.74 x 29.85 cm) |
| Item Weight | 2.86 pounds (1.3 kg) |
| Maximum Weight Recommendation | 33 Pounds (15 kg) |
| Material Type | Foam (50% plastic, 50% foam) |
| Target Gender | Unisex |
| Is Portable | Yes |
| Batteries Required | No |



Weight Max
50lbs, 23kg

Product dimensions and maximum weight capacity for the Ingenuity Baby Base.

Warranty and Support

For information regarding product warranty, returns, or customer support, please refer to the official Ingenuity website or contact their customer service department directly. Keep your purchase receipt for warranty claims.