

Zyliss E900032U

Zyliss SmoothGlide Dual Grater Instruction Manual

Model: E900032U

1. INTRODUCTION

The Zyliss SmoothGlide Dual Grater is designed for efficient grating of various food items. It features two distinct grating surfaces, allowing for both medium and coarse results. This manual provides essential information for the safe and effective use, maintenance, and storage of your grater.

2. SAFETY INFORMATION

Warning: The blades of this grater are extremely sharp. Exercise caution during use and cleaning to prevent injury.

- Keep fingers away from the grating surfaces during operation.
- Always use the protective cover when the grater is not in use or during storage.
- Keep out of reach of children.
- Do not attempt to sharpen the blades yourself.

3. PACKAGE CONTENTS

- 1 x Zyliss SmoothGlide Dual Grater
- 1 x Protective Blade Cover

4. SETUP

Before first use, wash the grater and its protective cover with warm, soapy water. Rinse thoroughly and dry completely. The grater is ready for use once cleaned.



Image: The Zyliss SmoothGlide Dual Grater, ready for use.

5. OPERATING INSTRUCTIONS

The Zyliss SmoothGlide Dual Grater features two acid-etched stainless steel grating surfaces: one medium and one coarse. This design allows for versatile food preparation.

Using the Dual Grating Surfaces

- **Medium Grating Surface:** Ideal for hard cheeses like Parmesan, as well as vegetables such as carrots or zucchini.
- **Coarse Grating Surface:** Suitable for softer cheeses, chocolate, ginger, and nutmeg.

To use, hold the ergonomic handle firmly. Place the desired food item against the chosen grating surface and move it across the blades with a consistent motion. The non-slip base provides stability during use.



grate.
zest.
scrape.

**dual grater for coarse
& fine results.**

Image: Demonstrating the grating action on cheese.

dual-sided design

grate soft and
hard cheeses
with ease



switch between coarse and fine grating effortlessly

the **cleverly swiss** brand

Image: The dual-sided design allows for grating soft and hard cheeses with ease.

Product Features Overview



1 hanging loop
convenient for storage option

2 ergonomic handle
for comfortable grip

3 stainless steel blades
ultra-sharp surface for smooth,
precise results

Image: Key features include a hanging loop for storage, an ergonomic handle for comfortable grip, and ultra-sharp stainless steel blades for precise results.

Official Product Video

Your browser does not support the video tag.

Video: An official overview of the Zyliss SmoothGlide Dual Grater, demonstrating its features and use.

6. MAINTENANCE AND CLEANING

The Zyliss SmoothGlide Dual Grater is designed for easy cleaning.

- **Dishwasher Safe:** The grater is safe for cleaning in a dishwasher. Place it on the top rack for best results.
- **Hand Washing:** For hand washing, use warm, soapy water and a brush to carefully clean the blades. Rinse thoroughly and dry immediately to prevent water spots and maintain blade integrity.
- Ensure all food particles are removed from the grating surfaces after each use.

7. STORAGE

Proper storage helps protect the blades and ensures safety.

- **Protective Cover:** Always place the fitted protective blade cover over the grating surfaces when the grater is not in use. This guards against accidental contact and protects the blades.
- **Hanging Loop:** The grater features a hanging loop on the handle for convenient storage on a kitchen hook or rack.



smoothglide

dual grater



3.7 X 11.2 in



dishwasher safe



acid-etched,
ultra-sharp blade



ergonomic handles



non-slip tip



blade cover
included

Image: The protective cover ensures safe storage and helps scrape off any remaining food.

8. TROUBLESHOOTING

If you encounter issues with your Zyliss SmoothGlide Dual Grater, consider the following:

- **Grating Difficulty:** Ensure the food item is firm enough for grating. For softer items, chilling them slightly may improve results.
- **Blade Dullness:** The acid-etched stainless steel blades are designed for long-lasting sharpness. If you notice significant dullness over time, refer to the warranty information.

- **Cleaning Residue:** If food residue remains after washing, use a small brush or sponge to dislodge particles from the blade holes.

9. SPECIFICATIONS

Feature	Detail
Model Number	E900032U
UPC	054067000329
Material	Stainless Steel blades, Plastic handle
Color	White
Product Dimensions (L x W x H)	11.22" x 3.74" x 1.18"
Item Weight	7.04 ounces
Dishwasher Safe	Yes




Image: Visual representation of the grater's dimensions: 11.22 inches long, 3.74 inches wide, and 1.18 inches high.

10. WARRANTY

The Zyliss SmoothGlide Dual Grater comes with a **5-year Zyliss Guarantee**. This warranty covers defects in materials and workmanship under normal household use. For specific terms and conditions, or to make a warranty claim, please refer to the official Zyliss website or contact customer support.

11. SUPPORT

For additional information, product registration, or customer support, please visit the official Zyliss website: www.zyliss.com.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question