

[Manuals.plus](#) /

› [Lasko](#) /

› Lasko Wind Machine 20-inch Air Circulator Instruction Manual

Lasko A20335

Lasko Wind Machine 20-inch Air Circulator Instruction Manual

INTRODUCTION

Thank you for choosing the Lasko Wind Machine 20-inch Air Circulator. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new air circulator. Please read all instructions carefully before use and retain this manual for future reference.



- ① 3 high-performance speeds
- ② Easy-carry handle
- ③ Pivoting head for directional air flow

Figure 1: Front view of the Lasko Wind Machine 20-inch Air Circulator.

Key Features

- **Three High-Performance Speeds:** Customize airflow for optimal comfort.
- **Rugged Design and Construction:** Built for durability and long-lasting performance.
- **Pivoting Head:** Direct air power precisely where needed.
- **Easy-Grip Carry Handle:** Ensures convenient portability.
- **Energy-Efficient Operation:** Designed to minimize power consumption.
- **Fully Assembled:** Ready to use right out of the box.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. This appliance features a **Patented Safety Fuse Technology** (often referred to as the 'Blue Plug') designed to cut current if the fuse inside detects potentially hazardous issues, providing an added layer of safety.

- Always plug the fan directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service

facility for examination and/or repair.

- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- Always unplug the fan before moving, servicing, or cleaning.
- Do not insert or allow fingers or foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the fan.
- Do not use outdoors or on wet surfaces.

SETUP AND ASSEMBLY

The Lasko Wind Machine 20-inch Air Circulator comes **fully assembled** and requires no additional installation. Simply remove it from its packaging, place it on a stable, flat surface, and plug it into a standard AC power outlet.

OPERATING YOUR AIR CIRCULATOR

Your Lasko Wind Machine is designed for straightforward operation with manual controls.

Speed Control

The fan features three high-performance speeds. To adjust the speed, locate the control knob on the side of the fan. Turn the knob to select your desired setting:

- **Setting 1:** Low Speed
- **Setting 2:** Medium Speed
- **Setting 3:** High Speed

Pivoting Head for Directional Airflow

The fan's head can be pivoted to direct airflow up, down, or straight ahead. To adjust the angle, gently tilt the fan body to the desired position. The side knobs allow you to tighten the fan in place once the desired angle is achieved, ensuring it stays in position even at high speeds.



Figure 2: Demonstrating the pivoting head feature for directional airflow.

CARE AND MAINTENANCE

Regular cleaning and maintenance will ensure your Lasko Wind Machine operates efficiently and safely for years to come. Always unplug the fan before performing any maintenance.

Cleaning Instructions

- Use a soft cloth or vacuum cleaner with a brush attachment to remove dust from the fan grilles.
- To clean the fan blades, you may need to partially disassemble the fan. Unscrew the side knobs and carefully remove the front grille. The fan blades can then be wiped clean with a soft, damp cloth. Ensure all parts are completely dry before reassembling.
- Do not immerse the fan in water or allow water to drip into the motor housing.
- Do not use gasoline, benzene, thinner, harsh cleaners, etc., as they will damage the fan.

PRODUCT SPECIFICATIONS

Brand	Lasko
-------	-------

Model Name	Wind Machine 20" Air Circulator
Model Number	A20335
Color	Black Wind 20
Electric Fan Design	Floor Fan
Power Source	AC
Product Dimensions (D x W x H)	7.19"D x 25.38"W x 23.38"H
Number of Speeds	3
Wattage	20 watts
Item Weight	8 Pounds
Included Components	Fan, Instruction Manual
UPC	046013462565

WARRANTY INFORMATION

This Lasko Wind Machine 20-inch Air Circulator comes with a**One Year Limited Warranty**. For detailed terms and conditions, or to make a warranty claim, please refer to the warranty card included with your product or visit the official Lasko website.