Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LIFESMART GLOBAL 1500W Infrared Quartz Space Heater (B079329YZ4)

LifeSmart Infrared Quartz Space Electric Heater User Manual

Model: 1500W Infrared Quartz Space Heater (B079329YZ4)
Brand: LIFESMART GLOBAL

Introduction

Thank you for choosing the LifeSmart Infrared Quartz Space Electric Heater. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new heater. Please read this manual thoroughly before use and retain it for future reference.

Important: Always adhere to all safety warnings and instructions to prevent injury or damage.



Figure 1: LifeSmart Infrared Quartz Space Electric Heater with Remote Control

Product Features

- **Powerful 1500W Heating:** Quickly warms up to 1000 sq. ft. with 8 infrared quartz elements for efficient, even heat distribution.
- **Precise Temperature Control:** Digital thermostat adjustable between 50-90°F with included remote for customized comfort.
- **Versatile 3-Mode Settings:** Choose from high, low, or eco heat settings, or use the fan-only mode for air circulation.
- **Safety Features:** Includes tip-over safety switch, overheat protection, and a programmable timer.

- **Portable Design:** Smooth-rolling metal casters and compact dimensions (13.1"D x 16"W x 16.5"H) for easy movement.




Figure 2: Key Features of the LifeSmart Heater



Figure 3: Product Dimensions

Components Included

- LifeSmart Infrared Quartz Space Electric Heater Unit
- Remote Control
- User Manual (this document)



Figure 4: Remote Control

Setup

1. **Unpack:** Carefully remove the heater and all accessories from the packaging. Retain packaging for storage.
2. **Placement:** Place the heater on a firm, level surface. Ensure there is at least 3 feet (0.9 meters) of clearance from any walls, furniture, curtains, or other combustible materials. Do not block air intakes or outlets.
3. **Power Connection:** Plug the power cord directly into a grounded 120V AC, 15-amp (or greater) outlet. Do not use extension cords or power strips.
4. **Initial Use:** For the first use, operate the heater on the highest setting for a few minutes to eliminate any initial odors from manufacturing. Ensure the area is well-ventilated during this period.



Figure 5: Proper Heater Placement

Operating Instructions

Control Panel and Digital Display

The heater features an intuitive control panel with a digital display for easy operation. All functions can also be controlled via the included remote.



Figure 6: Digital Control Panel

- **Power Button (On/Off):** Press to turn the heater on or off.
- **Mode Button (Mode):** Cycle through heating modes: High, Low, and ECO. A fan-only mode is also available.
- **Temperature Adjustment (Up/Down Arrows):** Adjust the desired temperature setting from 50°F to 90°F.
- **Timer Button (Timer):** Set the auto-off timer in hourly increments, up to 12 hours.

- **Child Lock Button (Lock Icon):** Press and hold to lock/unlock the control panel to prevent accidental changes.
- **°C/°F Button:** Toggle between Celsius and Fahrenheit temperature display.

Remote Control Operation

The remote control provides convenient access to all heater functions from a distance. Ensure line of sight to the heater's front panel for optimal performance.

- All buttons on the remote correspond to the functions on the main control panel.
- Insert 2 AAA batteries (not included) into the remote control before first use.

Safety Information

Your safety is paramount. Please read and follow all safety instructions carefully.

- **Overheat Protection:** The heater is equipped with an internal safety device that automatically shuts off the unit if it overheats. If this occurs, unplug the heater, allow it to cool for 30 minutes, and ensure no obstructions are blocking the air vents before restarting.
- **Tip-Over Safety Switch:** The heater will automatically turn off if it is accidentally tipped over. Place the heater on a stable, flat surface to prevent this.
- **Electrical Safety:**
  - Do not operate the heater with a damaged cord or plug.
  - Do not run the power cord under carpeting or cover it with throw rugs.
  - Always plug the heater directly into a wall outlet.
  - Do not use outdoors or in wet locations.
- **Clearance:** Maintain a minimum of 3 feet (0.9 meters) clearance from the front, sides, and rear of the heater to any combustible materials.
- **Supervision:** Close supervision is necessary when any heater is used by or near children or invalids.
- **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Maintenance

Cleaning

1. **Always unplug the heater** from the power outlet and allow it to cool completely before cleaning.
2. **Exterior Cleaning:** Use a soft, damp cloth to wipe the exterior surfaces of the heater. Do not use abrasive cleaners or solvents.
3. **Air Filter (if applicable):** Check the air filter (usually located at the rear) periodically. Clean by vacuuming or rinsing with water. Ensure it is completely dry before reinserting.
4. **Interior Cleaning:** Do not attempt to open or clean the interior of the heater. Refer to qualified service personnel for any internal maintenance.

Storage

When not in use, store the heater in a cool, dry place, preferably in its original packaging, away from direct sunlight and excessive dust.

Troubleshooting

Problem	Possible Cause	Solution
Heater does not turn on.	No power, power switch off, tip-over switch activated, overheat protection activated.	Check power outlet, ensure main power switch is ON, place heater on a flat surface, unplug and allow to cool.
Heater blows cold air.	Temperature setting too low, fan-only mode selected.	Increase desired temperature, select a heating mode (High, Low, ECO).
Heater makes unusual noise.	Obstruction in fan, loose component.	Unplug and check for obstructions. If noise persists, contact customer support.

If the problem persists after attempting these solutions, please contact LifeSmart customer support.

Specifications

Feature	Detail
Brand	LIFESMART GLOBAL
Model	Infrared Quartz Space Electric Heater
Power	1500W
Heating Coverage	Up to 1000 sq. ft.
Temperature Range	50°F - 90°F
Dimensions (D x W x H)	13.1" x 16" x 16.5"
Item Weight	12.3 pounds
Voltage	120V (AC)
Special Features	Portable, Programmable Thermostat, Remote Control, Tip-Over Safety, Overheat Protection

Warranty and Support

LifeSmart Global stands behind the quality of its products. For specific warranty details, including coverage period and terms, please refer to the warranty card included with your product packaging or visit the official LifeSmart Global website.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact LifeSmart Global customer service. Contact information can typically be found on the product packaging or the brand's official website.

Please have your product model number (B079329YZ4) and purchase date available when contacting support.

© 2025 LIFESMART GLOBAL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B079329YZ4

More documents and user manuals: **https://manuals.plus/**