

Tefal BL83SD65

Tefal Perfectmix Cook BL83SD65 Blender and Soup Maker Instruction Manual

Model: BL83SD65

1. PRODUCT OVERVIEW

The Tefal Perfectmix Cook BL83SD65 is a versatile kitchen appliance designed for both blending and cooking. It features high-performance Powelix blades and a powerful 1400W motor, enabling it to prepare a wide range of recipes, from cold smoothies and ice crushes to hot soups and sauces. The appliance includes 10 automatic programs and manual control options for precise preparation.



Image 1.1: The Tefal Perfectmix Cook BL83SD65 blender and soup maker, shown with its glass jug, base unit, lid, and included accessories: a steam basket, measuring cup, and cleaning brush.

ULTIMATE VERSATILITY

Endless results with **ONE**



Image 1.2: This illustration highlights the ultimate versatility of the Tefal Perfectmix Cook BL83SD65, showcasing its capabilities as a food processor, chopper, grinder, juicer, steamer, soy milk maker, and stirrer.

2. COMPONENTS AND ACCESSORIES

Familiarize yourself with the main components of your Tefal Perfectmix Cook BL83SD65:

- **Base Unit:** Contains the motor, control panel, and heating element.
- **Glass Jug:** Ultra-durable, heat-resistant, and stain-proof, suitable for both hot and cold preparations. Capacity: 1.75L (cold), 1.4L (hot).
- **Lid:** Secures the jug during operation.
- **Measuring Cap:** Integrated into the lid for adding ingredients during operation.
- **Powelix Blades:** Six precision-crafted, razor-sharp blades for efficient blending. Removable for cleaning.
- **Control Panel:** Intuitive touchscreen interface with automatic programs and manual controls.

Included accessories:

- **Steam Basket:** For steaming vegetables, fish, or other ingredients.
- **Measuring Cup:** For precise ingredient measurement.

- **Cleaning Brush:** Aids in cleaning around the removable blades.



Image 2.1: An exploded view illustrating the main components of the Tefal Perfectmix Cook BL83SD65, highlighting the ultra-durable glass jug suitable for both hot and cold use, the robust metal housing, and the intuitive touchscreen control panel.

Globally trusted brand since 1956



2 YEARS
Worldwide
Warranty



15 YEARS
Assurance Of
Repairability

COMPLIMENTARY ACCESSORIES INCLUDED

Steam Basket

| Measuring Cup

| Cleaning Brush



Image 2.2: The complimentary accessories included with the Tefal Perfectmix Cook BL83SD65: a steam basket, a measuring cup, and a cleaning brush.

3. SETUP AND INITIAL USE

3.1 Unpacking and Placement

1. Carefully remove all components from the packaging.
2. Remove any protective films or stickers from the appliance.
3. Place the base unit on a stable, flat, and dry surface, away from heat sources and water.

3.2 Initial Cleaning

Before first use, clean all parts that will come into contact with food:

1. Disassemble the jug by removing the blades from the bottom.
2. Wash the glass jug, lid, measuring cap, and blades with warm soapy water.
3. Rinse thoroughly and dry completely.
4. Wipe the base unit with a damp cloth. Do not immerse the base unit in water.

3.3 Assembly

1. Ensure the blades are securely reattached to the bottom of the glass jug.
2. Place the assembled jug onto the base unit, ensuring it is properly seated.

3. Place the lid onto the jug and twist to lock it into position. Ensure the measuring cap is inserted into the lid opening.

4. OPERATING INSTRUCTIONS

4.1 General Operation

1. Plug the appliance into a suitable power outlet. The control panel will illuminate.
2. Add ingredients to the glass jug. Observe the MAX fill lines for both hot and cold preparations (1.75L for cold, 1.4L for hot).
3. Secure the lid and measuring cap.
4. Select your desired program or manual setting from the touchscreen.
5. Press the "Start/Stop" button to begin operation.
6. The appliance will automatically stop when the program is complete.



Image 4.1: An illustration of the Powelix Blades Technology, highlighting the six precision-crafted, razor-sharp blades designed for smoother and faster blending, capable of processing even hard ingredients to a creamy texture.

4.2 Automatic Programs

The Perfectmix Cook BL83SD65 features 10 pre-set automatic programs for convenience:

Cold Programs (4 options):

- **Milk-shake:** For preparing creamy milkshakes.
- **Smoothie:** For blending fruits and vegetables into smooth drinks.
- **Dessert:** For creating various dessert preparations.
- **Ice Crush:** For crushing ice cubes.



Image 4.2: The control panel displaying the four cold automatic programs: Milk-shake, Smoothie, Dessert, and Ice crush, with examples of cold preparations.

Hot Programs (6 options):

- **Puree:** For smooth purees and baby food.
- **Multigrain Milk:** For preparing homemade plant-based milks (e.g., soy milk).
- **Detox Juice:** For hot detoxifying beverages.
- **Soup:** For cooking and blending smooth soups.
- **Porridge:** For preparing hot porridge.
- **Stir:** For stirring and heating ingredients without intense blending.



Image 4.3: The control panel displaying the six hot automatic programs: Puree, Multigrain milk, Detox Juice, Soup, Porridge, and Stir, with examples of hot preparations.

4.3 Manual Settings

For customized control, use the manual settings:

- **Blend:** Adjust blending speed for desired consistency.
- **Pulse:** Short bursts of high-speed blending for coarse chopping or quick mixing.
- **Heat:** Manually control heating temperature and duration.
- **Steam:** Use with the steam basket for steaming ingredients.



Image 4.4: The manual settings section of the control panel, illustrating options for blending, heating, and steaming. The image also shows the steam basket with carrots, indicating its capacity for steaming.

4.4 Using the Steam Basket

1. Fill the jug with water up to the indicated steam level (500ml max).
2. Place ingredients (e.g., vegetables, fish) into the steam basket.
3. Insert the steam basket into the jug.
4. Secure the lid.
5. Select the "Steam" manual setting and adjust time as needed, then press "Start/Stop".

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene of your appliance.

5.1 Automatic Deep Clean Program

The appliance features an automatic deep-clean program for convenience:

1. After use, rinse the jug to remove large food particles.
2. Fill the jug with water and a small amount of dish soap.

3. Select the "Clean" program on the control panel.
4. Press "Start/Stop". The program uses hot water (up to 100°C) to eliminate 99.99% of bacteria.
5. After the program finishes, rinse the jug thoroughly.

5.2 Manual Cleaning

1. **Jug and Lid:** These parts are dishwasher safe. For hand washing, use warm soapy water and the provided cleaning brush for hard-to-reach areas.
2. **Blades:** The Powelix blades are removable for thorough cleaning. Carefully detach them from the jug base. Use the cleaning brush to clean around the blades safely. Exercise caution as blades are sharp.
3. **Base Unit:** Wipe the base unit with a soft, damp cloth. Never immerse the base unit in water or any other liquid.



Image 5.1: The Tefal Perfectmix Cook BL83SD65 highlighting its automatic deep clean mode and the removable Powelix blades, which facilitate thorough and hygienic cleaning.

5.3 Storage

Store the appliance in a dry, safe place when not in use. Ensure all parts are clean and dry before storage.

6. TROUBLESHOOTING

If you encounter issues with your Tefal Perfectmix Cook BL83SD65, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not start.	Not plugged in; jug or lid not correctly assembled; power outage.	Check power connection; ensure jug and lid are securely locked; check household power supply.
Unusual noise or vibration.	Ingredients overloaded; jug not properly seated; foreign object in jug.	Reduce ingredient quantity; re-seat the jug on the base; check for and remove any foreign objects.
Food not blending properly.	Insufficient liquid; ingredients too large; blades dull or obstructed.	Add more liquid; cut ingredients into smaller pieces; ensure blades are clean and sharp.
Heating function not working.	Incorrect program selected; jug not properly seated for heating.	Ensure a hot program is selected; verify jug is correctly placed on the base.

If the problem persists after attempting these solutions, please contact customer support.

7. TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	Tefal
Model Number	BL83SD65
Power/Wattage	1400 watts
Voltage	230 Volts
Capacity (Cold)	1.75 Litres
Capacity (Hot)	1.4 Litres
Material	Glass jug, Metal housing
Number of Speeds	10 (automatic programs)
Special Features	Hot & Cold Blender, Auto Programs, Removable Blades, Cleaning Program, Steam Cooking
Product Dimensions	48.6 x 25.7 x 31.4 cm
Item Weight	5.8 kg

PERFECTMIX COOK

Blender | Steam Basket | Measuring Cup | Cleaning Brush



Power:
1400W

Capacity:
Cold: 1.75L
Hot: 1.4L

Material:
Durable Glass Jar with
Sturdy Metal Body

Blade Design:
Advanced Powelix Blades Technology

Programme:
10x Auto Pre-set Cooking Modes

Special Features:
Steam Cooking
Easily Removable Blades
User-Friendly Touchscreen Panel

Image 7.1: A visual representation of the Tefal Perfectmix Cook BL83SD65's dimensions and a summary of its key specifications, including power, capacity, material, blade design, programs, and special features.

8. WARRANTY AND SUPPORT

8.1 Warranty Information

The Tefal Perfectmix Cook BL83SD65 comes with a **2-year worldwide warranty**. This warranty covers manufacturing defects and ensures the product meets quality standards under normal use.

8.2 Repairability

Tefal is committed to product longevity. This appliance is designed to be **repairable for 10 years**, with an assurance of repairability for 15 years at a fair price. This commitment aims to reduce waste and extend the product's lifespan.

8.3 Customer Support

For further assistance, troubleshooting not covered in this manual, or warranty claims, please contact Tefal customer support through their official website or local service centers. Please have your model number (BL83SD65) and proof of purchase ready.

