

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Schleich](#) /

› [Schleich Farm World Advent Calendar 2018 Instruction Manual](#)

**Schleich 97700**

# Schleich Farm World Advent Calendar 2018 Instruction Manual

Model: 97700

## INTRODUCTION

This instruction manual provides essential information for the Schleich Farm World Advent Calendar 2018. This product offers a daily surprise of Schleich figurines and accessories, designed to enhance imaginative play and learning. Please read this manual thoroughly to ensure proper use and care of your advent calendar.

## PRODUCT CONTENTS

The Schleich Farm World Advent Calendar 2018 contains 24 individually packaged surprises behind numbered doors. These surprises typically include a variety of Schleich farm animal figurines and related accessories.

- Assorted Schleich farm animal figurines.
- Various accessories to complement the farm world theme.
- A total of 24 unique items.



Image: The exterior packaging of the Schleich Farm World Advent Calendar 2018, showing the product box with various farm animals and accessories depicted.



Image: A collection of Schleich farm animal figurines and accessories, including a dog, cat, lamb, horse, pig, rabbit, rooster, and various small items, representing the typical contents found within the advent calendar.

## SETUP AND USAGE

- 1. Unboxing:** Carefully remove the advent calendar from its outer packaging. Ensure the calendar itself is intact and all doors are closed.
- 2. Placement:** Place the calendar in a visible and accessible location, such as a table or shelf, where it

can be easily reached each day.

3. **Daily Opening:** Starting from December 1st, open one numbered door each day. Each door conceals a new figurine or accessory.
4. **Collection:** As each item is revealed, add it to your collection to build a complete farm world scene by December 24th.

## Maintenance and Care

- **Cleaning:** To clean the figurines, gently wipe them with a damp cloth. Avoid using harsh chemicals or abrasive materials, as these may damage the paint or material.
- **Storage:** Store figurines and accessories in a clean, dry place away from direct sunlight and extreme temperatures to prevent fading or damage.
- **Handling:** Handle figurines with care to prevent breakage, especially smaller or delicate parts.

## Safety Information

This product is recommended for ages 3 years and older. Due to small parts, it is not suitable for children under 36 months as it may pose a choking hazard. Adult supervision is recommended during play.

## Specifications

Product Dimensions	15.35 x 2.95 x 11.22 inches
Item Weight	1.14 pounds
Model Number	97700
Recommended Age	36 months - 8 years
Release Date	September 1, 2018
Manufacturer	Schleich
Color	Multicolor
Theme	Farm Toys



Image: A diagram illustrating the dimensions of the Schleich Farm World Advent Calendar 2018 packaging, showing a height of approximately 12 inches (30 cm).

## TROUBLESHOOTING

### Missing or Duplicate Items

While quality control is maintained, occasional discrepancies may occur. If you encounter a missing item or receive a duplicate, please contact Schleich customer support for assistance.

### Damaged Figurines

If any figurine is damaged upon opening, retain the item and its packaging. Contact customer support with details and images of the damage for resolution.

## WARRANTY AND SUPPORT

Schleich products are manufactured to high-quality standards. For any questions, concerns, or support regarding your Farm World Advent Calendar 2018, please visit the official Schleich website or contact their customer service department. Specific warranty details may vary by region and purchase location.

You can find more information and contact details on the [Schleich Official Store](#).

	<p><a href="#"><u>Schleich Farm World Goat Stable 42726 Assembly Instructions</u></a></p> <p>Step-by-step assembly guide for the Schleich Farm World Goat Stable playset (Model 42726), including a comprehensive parts list and detailed building instructions.</p>
	<p><a href="#"><u>Schleich Farm World Pony Box 42724 Assembly Instructions</u></a></p> <p>Step-by-step assembly instructions for the Schleich Farm World Pony Box playset, model number 42724. Includes a parts list, safety warnings, and assembly guidance.</p>
	<p><a href="#"><u>Schleich Farm World Large Farm 72102 Assembly Instructions</u></a></p> <p>Step-by-step assembly guide for the Schleich Farm World Large Farm playset (model 72102), including a detailed parts list and connection instructions for building the farm.</p>
	<p><a href="#"><u>Schleich Farm World Stable 42195 Assembly Instructions</u></a></p> <p>Detailed assembly guide for the Schleich Farm World Stable playset (model 42195), featuring step-by-step instructions and part identification for building the toy farm.</p>
	<p><a href="#"><u>Schleich 42706 Lakeside Horse Farm Assembly Instructions</u></a></p> <p>Detailed assembly instructions for the Schleich 42706 Lakeside Horse Farm playset, guiding users through the step-by-step building process for imaginative play.</p>
	<p><a href="#"><u>Schleich Horse Club Camping Trip with Caravan and Car Assembly Instructions</u></a></p> <p>A comprehensive guide for assembling the Schleich Horse Club Camping Trip playset, detailing the construction of the toy caravan and car with all included accessories and figures.</p>