

[manuals.plus](#) /› [Superior Electronics](#) /› [Superior Electronics Simply SUPTLB001 Universal Remote Control with Learning Function](#)

Superior Electronics SUPTLB001

Superior Electronics Simply SUPTLB001 Universal Remote Control

INSTRUCTION MANUAL

1. Introduction

The Superior Electronics Simply SUPTLB001 is a universal remote control designed for ease of use and simplicity. It features a self-learning function, allowing it to acquire commands directly from your original remote controls. This remote is capable of controlling up to two different devices, such as a television and a set-top box, making it an ideal solution for consolidating your remote controls. Its design prioritizes large, clearly identifiable buttons for comfortable operation.

2. Product Features

- **Universal Compatibility:** Controls a wide range of devices.
- **Self-Learning Function:** Easily acquires commands from existing remote controls.
- **Two-Device Control:** Manages up to two separate electronic devices.
- **Large Buttons:** Designed with oversized, clearly marked buttons for enhanced usability.
- **Intuitive Design:** Simple layout for straightforward operation.
- **Quick Programming:** Learning process typically takes less than one minute per button.

3. Setup

3.1. Battery Installation

The Superior Electronics Simply SUPTLB001 remote control requires two (2) AAA batteries (not included) for operation.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.



Image: Back of the remote control, indicating the battery compartment.

3.2. Learning Function Programming

The Simply SUPTLB001 remote learns functions directly from your original remote controls. You can program any button on the Simply remote to perform a function from your original remote.

- 1. Prepare Remotes:** Place the Simply SUPTLB001 remote and your original remote control on a flat surface, facing each other, with their infrared (IR) emitters aligned and approximately 1-3 cm apart.
- 2. Enter Learning Mode:** Press and hold the **POWER** button on the Simply remote for approximately 5 seconds until the red indicator light (usually near the power button) illuminates steadily. This indicates the remote is in learning mode.
- 3. Select Device (A or B):** If you are programming for Device A, press the **A** button. If for Device B, press the **B** button. The indicator light may flash to confirm selection.
- 4. Select Button to Learn:** Press the button on the Simply remote that you wish to program (e.g., **V+** for Volume Up). The indicator light will start flashing slowly, waiting for a signal.
- 5. Transmit Signal:** Press and hold the corresponding button on your original remote control (e.g., Volume Up) until the indicator light on the Simply remote flashes rapidly three times and then remains steady. This signifies successful learning.
- 6. Repeat for Other Buttons:** Repeat steps 4 and 5 for all other buttons you wish to program for the current device.
- 7. Exit Learning Mode:** Once all desired buttons are programmed, press the **POWER** button on the Simply remote again to exit learning mode. The indicator light will turn off.

Note: If the indicator light flashes rapidly and then turns off without remaining steady, the learning process

for that button may have failed. Ensure the remotes are properly aligned and try again. Some original remotes may require a longer press to transmit the signal effectively.



Image: Front view of the Simply SUPTLB001 remote control.

4. Operating Instructions

After successful programming, you can use your Simply SUPTLB001 remote control to operate your

devices.

- **Device Selection:** Press the **A** button to control the first programmed device or the **B** button to control the second programmed device. The indicator light may briefly flash to confirm the selected device.
- **Power On/Off:** Press the **POWER** button to turn the selected device on or off.
- **Volume Control:** Use the **V+** button to increase volume and **V-** to decrease volume.
- **Program/Channel Control:** Use the **P+** button to go to the next program/channel and **P-** to go to the previous program/channel.
- **AV Input:** Press the **AV** button to switch between video input sources on your television.

The functionality of each button depends on how it was programmed during the learning process.

5. Maintenance

- **Cleaning:** To clean the remote control, use a soft, dry cloth. Do not use abrasive cleaners, solvents, or alcohol, as these can damage the surface.
- **Battery Replacement:** Replace batteries when the remote's performance degrades or the indicator light does not respond as expected. Always replace both AAA batteries at the same time with new ones.
- **Storage:** Store the remote in a dry place, away from direct sunlight and extreme temperatures.

6. Troubleshooting

Problem	Possible Cause	Solution
Remote does not work.	Batteries are dead or incorrectly inserted.	Replace batteries with new AAA batteries, ensuring correct polarity.
Learning function fails (indicator light flashes rapidly and turns off).	Remotes not aligned, too far apart, or original remote signal is weak.	Ensure remotes are 1-3 cm apart and IR emitters are aligned. Press and hold the original remote button firmly. Try again.
Programmed button does not control the device.	Button was not programmed correctly or device selection is wrong.	Re-program the button following the learning instructions. Ensure you have selected the correct device (A or B) before attempting to control it.
Remote range is poor.	Low batteries or obstruction between remote and device.	Replace batteries. Ensure a clear line of sight between the remote and the device's IR receiver.

7. Specifications

Brand	Superior Electronics
Model Name	Simply
Model Number	SUPTLB001

Color	Black
Connectivity Technology	Infrared (IR) Learning Function
Compatible Devices	Television, other IR-controlled devices
Maximum Devices Supported	2
Number of Buttons	10 (Power, A, B, AV, V+, V-, P+, P-)
Battery Type	2 x AAA (not rechargeable)
Maximum Range	10 Meters (approx. 33 feet)
Dimensions (Approx.)	16.5 cm (Length) x 4.5 cm (Width)



Image: Side view of the remote control with approximate dimensions.

8. Warranty and Support

This Superior Electronics Simply SUPTLB001 remote control comes with a manufacturer's warranty of **2 years** from the date of purchase.

For warranty claims, technical assistance, or further support, please refer to the contact information provided with your purchase documentation or visit the official Superior Electronics website. Please retain your proof of purchase for warranty validation.