

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Fisher-Price](#) /

› Fisher-Price Paxton 4-in-1 Convertible Crib, Vintage Grey User Manual

## Fisher-Price 13660119

# Fisher-Price Paxton 4-in-1 Convertible Crib User Manual

Model: 13660119

## 1. INTRODUCTION

---

This manual provides essential information for the safe assembly, use, and maintenance of your Fisher-Price Paxton 4-in-1 Convertible Crib. Please read all instructions carefully before assembly and retain this manual for future reference. This crib is designed to convert into a toddler bed, daybed, and full-size bed, adapting to your child's growth.

## 2. SAFETY INFORMATION

---

- **WARNING:** Failure to follow these warnings and the assembly instructions could result in serious injury or death.
- Inspect the crib for damaged hardware, loose joints, missing parts, or sharp edges before assembly and periodically thereafter. Do not use the crib if any parts are missing or broken. Contact Fisher-Price for replacement parts and instructional literature if needed. Do not substitute parts.
- Ensure all bolts and screws are securely tightened.
- Do not place the crib near windows where cords from blinds or drapes could strangle a child.
- Do not suspend strings or toys over the crib.
- The mattress used with this crib must be at least 27 ¼ inches (69 cm) by 51 ⅝ inches (131 cm) with a thickness not exceeding 6 inches (15 cm).
- When a child is able to climb out, the crib shall no longer be used. The child should be placed in a toddler bed.
- Maximum weight recommendation for the crib is 22.68 kg (50 lbs).

## 3. PRODUCT OVERVIEW

---

The Fisher-Price Paxton 4-in-1 Convertible Crib features an industrial meets farmhouse chic design in a Vintage Grey finish. Constructed from wood, this crib is designed for durability and versatility, converting through four stages to accommodate your child's growth.



Image: The Fisher-Price Paxton 4-in-1 Convertible Crib in its standard crib configuration, showcasing its Vintage Grey finish and sturdy wooden construction.



Image: The Fisher-Price Paxton crib positioned within a nursery, demonstrating its aesthetic integration with other furniture, including a matching dresser.

## 4. SETUP AND ASSEMBLY

---

Assembly of the Fisher-Price Paxton 4-in-1 Convertible Crib is designed to be straightforward. All necessary hardware and tools are included in the packaging. Please follow the step-by-step instructions provided in the separate assembly guide that accompanies your product. Ensure all components are present and undamaged before beginning assembly.

1. Unpack all components and verify against the parts list in the assembly guide.
2. Assemble the crib frame according to the detailed diagrams.
3. Securely fasten all bolts and screws. Do not overtighten.
4. Install the mattress support at the appropriate height for your child's age and developmental stage.
5. Place the mattress inside the crib.



Image: An angled view of the Fisher-Price Paxton crib, illustrating its full structure and the placement of the mattress, useful for assembly reference.

## 5. OPERATING MODES (CONVERSIONS)

---

The Fisher-Price Paxton crib is designed to convert into four different bed configurations to grow with your child:

### 5.1. Crib Mode

This is the initial configuration for infants. Ensure the mattress support is set to the lowest position once your child can sit up unassisted.

### 5.2. Toddler Bed Mode

When your child is ready to transition from a crib (typically when they can climb out), convert the crib to a toddler bed. This involves removing the front rail and installing a toddler guard rail (sold separately).



Image: The Fisher-Price Paxton crib converted into a toddler bed, featuring a low side rail for easy access and a child-friendly design.

### 5.3. Daybed Mode

The daybed configuration is achieved by removing the front rail entirely, providing an open-front sleeping or lounging space. No guard rail is used in this mode.



Image: The Fisher-Price Paxton crib configured as a daybed, showing an open front for easy access and a more mature appearance suitable for a child's room.

#### **5.4. Full-Size Bed Mode**

For the final conversion, the crib can be transformed into a full-size bed. This requires a full-size bed frame (sold separately) to attach to the headboard and footboard of the crib.



Image: The Fisher-Price Paxton crib components used to form a full-size bed, demonstrating the long-term usability and adaptability of the furniture.

## 6. MAINTENANCE AND CARE

---

To maintain the appearance and integrity of your Fisher-Price Paxton Convertible Crib, follow these care instructions:

- **Cleaning:** Wipe surfaces with a dry cloth. Avoid abrasive cleaners or strong chemicals that could damage the finish.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Tighten as necessary.
- **Storage:** If storing the crib, ensure it is in a dry, temperature-controlled environment to prevent warping or damage to the wood.

## 7. TROUBLESHOOTING

---

If you encounter issues with your crib, consider the following common solutions:

- **Wobbling or Instability:** Ensure all bolts and screws are fully tightened. Re-check the assembly steps to confirm correct installation of all parts.
- **Missing or Damaged Parts:** Do not attempt to use the crib with missing or damaged parts. Contact customer support for replacement parts.
- **Conversion Difficulty:** Refer to the specific conversion instructions provided with your product for each stage (toddler bed, daybed, full-size bed). Ensure all necessary additional components (e.g., guard rail, full-size bed frame) are acquired.

## 8. SPECIFICATIONS

---

Feature	Detail
Brand	Fisher-Price
Model Number	13660119
Colour	Vintage Grey
Material	Wood
Product Dimensions (L x W x H)	136.4 cm x 74.7 cm x 113.3 cm
Item Weight	29 kg (63.9 Pounds)
Maximum Weight Recommendation	22.68 kg (50 lbs)
Assembly Required	Yes
Special Feature	Convertible, Drawer (Note: Drawer feature may refer to coordinating dresser, not integrated into crib)
UPC	849451075423




Image: A diagram illustrating the key dimensions of the Fisher-Price Paxton crib, including length, width, and height, for reference during setup and space planning.

## 9. WARRANTY AND SUPPORT

---

For warranty information, replacement parts, or customer support, please refer to the documentation included with your purchase or contact Fisher-Price directly through their official website or customer service channels. Ensure you have your model number (13660119) and proof of purchase available when contacting support.



© 2023 Fisher-Price. All rights reserved. This manual is for informational purposes only.