

Hot Wheels FNB21

Hot Wheels City Shark Beach Battle Play Set Instruction Manual

Model: FNB21 | Brand: Hot Wheels

INTRODUCTION

This instruction manual provides detailed information for the assembly, operation, and maintenance of your Hot Wheels City Shark Beach Battle Play Set. Designed for interactive play, this set allows users to launch Hot Wheels vehicles through a wave and challenge a menacing shark. Please read this manual thoroughly before use to ensure proper setup and enjoyment.

SAFETY INFORMATION

No specific safety warnings are applicable beyond general toy safety guidelines. Always supervise children during play. Keep small parts away from children under 3 years of age to prevent choking hazards. Do not modify the toy in any way.

PACKAGE CONTENTS

- Hot Wheels City Shark Beach Battle playset with shark and ramp
- One (1) Hot Wheels vehicle



Image: The Hot Wheels City Shark Beach Battle Play Set as it appears in its retail packaging, showcasing the main components.

SETUP AND ASSEMBLY

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all listed contents are present.
2. **Assemble the Base:** Connect the main beach-themed base pieces. These pieces are designed to interlock securely.
3. **Attach the Launcher:** Secure the tiki hut-themed launcher to the designated connection point on the track. The launcher features a green surfboard-shaped lever.
4. **Position the Shark and Wave:** Attach the shark and wave assembly to the main playset. The shark's mouth should be positioned to interact with cars passing through the wave.
5. **Connect Additional Tracks (Optional):** The playset is designed to connect with other Hot Wheels City sets and orange track pieces, allowing for expanded play. Look for connection points on the sides of the playset.



Image: A child demonstrates the setup of the playset, showing the launcher and main shark/wave assembly.



Image: The fully assembled playset, featuring the orange track, tiki hut launcher, and the shark with its wave.

OPERATING INSTRUCTIONS

The Hot Wheels City Shark Beach Battle Play Set offers dynamic play scenarios:

1. **Launch the Car:** Place a Hot Wheels vehicle onto the launcher. Press the lever firmly to send the car speeding up the track towards the wave.
2. **Navigate the Wave:** The car will attempt to drift through the wave. The goal is to avoid the shark's jaws and land in the designated winning positions (first or second place) on the other side.
3. **Shark Attack:** If the car hits the trigger point within the wave, the giant shark will chomp down, capturing the vehicle in its massive jaws.
4. **Defeat the Shark:** To rescue a captured car, launch another vehicle with precision. Aim to slam into the shark to defeat it. When the shark is defeated, the wave will crash back dramatically, freeing any captured vehicles.




Image: A Hot Wheels car is shown trapped inside the shark's open mouth, illustrating the "shark attack" feature.



Image: A child's hand is shown pressing the launcher, sending a car down the orange track towards the playset.

MAINTENANCE

To ensure the longevity and optimal performance of your Hot Wheels City Shark Beach Battle Play Set, follow these simple maintenance guidelines:

- **Cleaning:** Wipe down the playset with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners, as these may damage the plastic.
- **Storage:** When not in use, store the playset in a cool, dry place away from direct sunlight to prevent material degradation.
- **Inspection:** Periodically check all connection points and moving parts for any signs of wear or damage. Discontinue use if any part is broken or compromised.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|--------------------------------------|--|---|
| Car not launching effectively. | Insufficient force on launcher; car not properly seated. | Ensure car is correctly placed on the launcher. Apply firm, quick pressure to the launcher lever. |
| Shark not chomping or releasing car. | Trigger mechanism not activated; obstruction. | Ensure the car hits the designated trigger point. Check for any debris obstructing the shark's mechanism. |

| Problem | Possible Cause | Solution |
|------------------------------------|---|--|
| Playset pieces detach during play. | Pieces not fully connected; rough play. | Verify all interlocking pieces are securely fastened during assembly. Encourage gentle handling during play. |

SPECIFICATIONS

- **Model Number:** FNB21
- **Product Dimensions:** 14.96 x 17.91 x 3.54 inches
- **Item Weight:** 2.2 pounds
- **Recommended Age:** 5 years and up
- **Batteries:** Not required for operation.
- **Manufacturer:** Mattel

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the official Hot Wheels website or contact Mattel customer service directly. Keep your purchase receipt as proof of purchase.

Hot Wheels Official Website: www.hotwheels.com