Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Brightech 858100007906

Brightech Montage Modern Floor Lamp User Manual

Model: 858100007906

1. Introduction

Thank you for purchasing the Brightech Montage Modern Floor Lamp. This manual provides essential information for the safe and efficient use of your new lamp. Please read it thoroughly before assembly and operation to ensure proper functionality and longevity of the product.



Image: The Brightech Montage Modern Floor Lamp with a brass finish and white fabric shade, positioned next to a yellow sofa in a modern living room.

2. Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, please follow these guidelines:

- Read all instructions carefully before assembly and use.
- Do not operate the lamp near water or in excessively damp environments.
- Always unplug the lamp from the electrical outlet when not in use or before cleaning, moving, or replacing the bulb.
- Do not use the lamp with a damaged cord or plug. If the cord or plug is damaged, contact customer support for assistance.
- Do not modify the electrical plug in any way.
- Ensure the lamp is fully and correctly assembled before plugging it into an electrical outlet.
- Use only the specified bulb type and wattage as indicated in the specifications section of this manual.
- Keep the lamp away from heat sources and direct sunlight.

- This lamp is for indoor use only.

3. What's in the Box

Please verify that all the following components are present in your package:

- Lamp Base
- Lamp Pole Sections (multiple, to be screwed together)
- Lamp Head with Bulb Socket
- Fabric Lamp Shade
- E27 LED Bulb (9.5W, adjustable color temperature)



Image: An exploded view diagram illustrating the individual parts of the floor lamp, including the base, pole, shade, and bulb.

4. Setup and Assembly

Follow these steps to assemble your Brightech Montage Modern Floor Lamp:

1. **Unpack Components**: Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Assemble Lamp Pole**: Gently feed the power cord through the lamp pole sections. Screw the pole sections together clockwise until they are securely tightened. Ensure the cord is not twisted or pinched.
3. **Attach Base**: Secure the assembled lamp pole to the heavy weighted lamp base by screwing it clockwise until firm.
4. **Assemble Lamp Shade**: The fabric lamp shade may come rolled. Unroll it and attach it to the metal rings using the provided clips or Velcro strips to form a cylindrical shape.
5. **Attach Lamp Shade**: Carefully place the assembled shade onto the lamp head. Secure it in place using the shade ring, if included, by screwing it onto the bulb socket.
6. **Install LED Bulb**: Carefully screw the included E27 LED bulb into the lamp socket. Do not overtighten.
7. **Position Lamp**: Place the assembled lamp on a flat, stable surface in your desired location.
8. **Plug In**: Insert the power plug into a standard 110V electrical outlet.

Your browser does not support the video tag.

Video: A demonstration of assembling the fabric shade and attaching it to the lamp, followed by installing the bulb and positioning the lamp.



Image: A close-up view of the lamp's sturdy metal base and the lower part of the pole, highlighting the quality of construction.

5. Operating Instructions

5.1. Power On/Off

The lamp is equipped with a convenient foot switch located on the power cord. Simply step on the switch to turn the lamp on or off. Ensure the lamp is plugged into a live electrical outlet.

5.2. Adjustable Color Temperature

The included LED bulb offers five distinct color temperature settings, allowing you to customize the ambiance of your space:

- **Warm Glow (2700K)**: Ideal for cozy and relaxed lighting.
- **Warm White (3000K)**: Provides a comfortable and inviting light.
- **Neutral Glow (3500K)**: A balanced light suitable for general ambient lighting.
- **Soft White (4000K)**: Offers brighter clarity, good for reading or focused tasks.
- **Cool White (5000K)**: A crisp, bright light for task-oriented areas or modern aesthetics.

To change the color temperature, you must first **unplug the lamp** from the electrical outlet. Carefully remove the LED bulb from the socket. Locate the small switch on the side of the LED bulb and slide it to your desired setting. Reinstall the bulb and plug the lamp back in.



Image: An illustration demonstrating the five adjustable color temperature settings of the included LED bulb, ranging from warm to cool white light.



Image: A composite image showing the lamp illuminating different room environments with various color temperatures, from warm to cool.

5.3. Smart Home Compatibility

This lamp is designed to be compatible with smart outlets (sold separately) that work with popular smart home systems such as Alexa, Google Home Assistant, and Apple HomeKit. This feature allows for hands-free lighting control and seamless integration into your existing smart home routines. Please refer to your specific smart outlet's instructions for setup and pairing with your smart home system.

6. Maintenance

6.1. Cleaning

To maintain the appearance and functionality of your lamp, follow these cleaning instructions:

- Always **unplug the lamp** from the electrical outlet before cleaning.
- For the metal parts, wipe with a soft, dry cloth. Avoid using abrasive cleaners, polishes, or chemical solvents, as these can damage the finish.

- For the fabric shade, use a lint roller or a soft brush to gently remove dust and debris. Spot clean with a slightly damp cloth if necessary, but avoid saturating the fabric.
- Ensure all parts are completely dry before plugging the lamp back in.

6.2. Bulb Replacement

When the time comes to replace the LED bulb:

- Always **unplug the lamp** from the electrical outlet.
- Allow the old bulb to cool completely before touching it.
- Carefully unscrew the old bulb from the socket.
- Screw in a new E27 base LED bulb. Refer to the specifications section for recommended wattage. Do not exceed the maximum wattage.
- Dispose of the old bulb according to local regulations.

7. Troubleshooting

If you encounter any issues with your lamp, please refer to the table below for common problems and their solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	◦ Lamp not fully plugged in. ◦ Power outlet is not active. ◦ Bulb is loose or faulty. ◦ Foot switch is faulty.	◦ Ensure the plug is fully inserted into a working electrical outlet. ◦ Test the outlet with another device to confirm it has power. ◦ Tighten the bulb or replace it with a new, known-good bulb. ◦ If the switch is suspected to be faulty, contact Brightech customer support.
Light flickers.	◦ Loose bulb. ◦ Incompatible bulb. ◦ Unstable power supply.	◦ Unplug the lamp, tighten the bulb, and plug it back in. ◦ Ensure you are using an E27 base LED bulb. ◦ Try plugging the lamp into a different electrical outlet.
Color temperature not changing.	◦ Bulb switch not adjusted. ◦ Bulb is faulty.	◦ Unplug the lamp, remove the bulb, and ensure the color temperature switch on the bulb is set correctly. ◦ Replace the bulb if it is unresponsive.

8. Specifications

Feature	Detail
Model Number	858100007906
Brand	Brightech

Product Dimensions (D x W x H)	17"D x 14.75"W x 60"H
Item Weight	14 pounds
Finish Type	Antique Brass
Base Material	Metal
Shade Material	Cotton
Bulb Base	E27
Light Source Type	LED
Wattage	9.5 watts
Voltage	110 volts
Switch Type	Foot Switch
Connectivity	Wi-Fi (via smart outlet, sold separately)
Indoor/Outdoor Usage	Indoor
Included Components	LED Bulb

9. Warranty and Support

This Brightech product is covered by a **3-year manufacturer warranty**. To be eligible for warranty service, proof of purchase from Brightech USA is required. This warranty covers defects in materials and workmanship under normal use.

For customer support, technical assistance, or to inquire about warranty claims, please visit the official Brightech website or contact their customer service department directly. You can also find more information and products at the official Brightech store on Amazon:

Visit the Brightech Store on Amazon

© 2026 Brightech. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0797F2FMX

More documents and user manuals: **https://manuals.plus/**