

[Manuals.plus](#) /

› [LKPower](#) /

› LKPower AC Adapter Instruction Manual for Supersonic SC-257 / SC-257A Portable LCD Television DVD Player

LKPower 180124313

LKPower AC Adapter Instruction Manual

For Supersonic SC-257 / SC-257A 7" Portable LCD Television DVD Player

INTRODUCTION

This manual provides essential information for the safe and effective use of your LKPower AC Adapter. This adapter is specifically designed to power Supersonic SC-257 and SC-257A 7-inch portable LCD televisions and DVD players. Please read these instructions carefully before use and retain them for future reference.

SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following safety precautions:

- **Indoor Use Only:** This adapter is designed for indoor use. Do not expose it to rain, moisture, or extreme temperatures.
- **Avoid Liquids:** Do not immerse the adapter in water or other liquids. Keep it away from spills.
- **Proper Ventilation:** Ensure the adapter has adequate ventilation. Do not cover it or place it in an enclosed space where heat cannot dissipate.
- **Correct Voltage:** Only plug the adapter into a standard electrical wall outlet (AC 100-240V, 50/60Hz).
- **Handle with Care:** Do not drop, disassemble, or attempt to repair the adapter. Refer all servicing to qualified personnel.
- **Unplug When Not in Use:** Disconnect the adapter from the wall outlet when not in use for extended periods.
- **Keep Away from Children:** Store the adapter out of reach of children.



Image: LKPower AC Adapter plugged into a wall outlet. This illustrates typical usage and the importance of proper placement in an indoor environment.

SETUP

Follow these steps to connect your LKPower AC Adapter to your device:

1. **Identify Device Port:** Locate the DC power input port on your Supersonic SC-257 or SC-257A portable LCD television or DVD player.
2. **Connect DC Plug:** Carefully insert the DC output plug of the LKPower AC Adapter into the device's power input port. Ensure a snug and secure connection.
3. **Plug into Outlet:** Insert the AC input prongs of the adapter into a standard, functional electrical wall outlet (AC 100-240V, 50/60Hz).
4. **Verify Connection:** Confirm that both ends of the adapter are securely connected before powering on your device.



Cable Length: 76 inch

Image: Front and side view of the LKPower AC Adapter, displaying its input specifications (100-240V AC, 50/60Hz) and a cable length of approximately 76 inches. This image helps in identifying the adapter and understanding its connection points.

OPERATING INSTRUCTIONS

Once properly connected to both the wall outlet and your Supersonic device, the LKPower AC Adapter will automatically supply the necessary power. Your device will then be able to operate or charge its internal battery, if applicable. The adapter features automatic voltage adjustment, supporting worldwide AC input from 100V to 240V.

MAINTENANCE

To ensure the longevity and optimal performance of your AC adapter, follow these maintenance guidelines:

- **Cleaning:** Use a dry, soft cloth to clean the adapter. Do not use liquid or aerosol cleaners, as they may damage the unit.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures.

- **Cable Care:** Avoid bending or crimping the power cord excessively. Do not place heavy objects on the cord.

TROUBLESHOOTING

If you encounter issues with your LKPower AC Adapter, refer to the following common problems and solutions:

- **Device Not Powering On:**
 - Ensure the adapter's DC plug is fully inserted into your device's power input port.
 - Verify that the adapter's AC prongs are securely plugged into a functional wall outlet.
 - Check if your Supersonic device's power switch is in the 'ON' position.
- **Adapter Feels Warm During Use:**
 - It is normal for the adapter to generate some heat during operation. If it becomes excessively hot to the touch, immediately unplug it from the wall outlet and your device. Ensure it has proper ventilation and is not covered. If the issue persists, discontinue use and contact customer support.

SPECIFICATIONS

Brand	LKPower
Model Number	180124313
Input Voltage	AC 100-240V, 50/60Hz
Compatible Devices	Supersonic SC-257, SC-257A 7" Portable LCD Television DVD Player
Special Features	Over Voltage Protection, Over Heat Protection, Portable, Travel
Main Power Connector Type	2 Pin
Cable Length	Approx. 76 inches (193 cm)



Image: Dimensions of the LKPower AC Adapter, showing approximate measurements of 3.1 inches in length, 2.1 inches in width, and 1.2 inches in depth. This provides a visual reference for the adapter's physical size.

WARRANTY AND SUPPORT

For information regarding the product warranty, returns, or technical assistance, please refer to the documentation included with your original purchase or contact LKPower customer service directly. Contact details can typically be found on the product packaging or the manufacturer's official website.

© 2023 LKPower. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0797RSM3R>

More documents and user manuals: **<https://manuals.plus/>**