PRO-SYS V200M

PRO-SYS VarioSonic V200M Normal Soft Replacement Heads Instruction Manual

Model: V200M

Introduction

The PRO-SYS VarioSonic V200M Normal Soft Replacement Heads are designed for effective and gentle cleaning, suitable for individuals with healthy gums. These precision brush heads feature DuPont filaments, known for their quality in dental bristles. They are compatible with PRO-SYS VarioSonic electric toothbrushes and also fit Burst sonic toothbrushes.



Image: Front view of the PRO-SYS VarioSonic V200M Normal Soft Replacement Head.

Setup: Attaching the Brush Head

1. Ensure your electric toothbrush handle is clean and dry before attaching the new brush head.
2. Align the base of the replacement brush head with the metal shaft on the toothbrush handle.

3. Gently push the brush head down onto the shaft until it clicks securely into place. Do not force it.
4. Verify that the brush head is firmly attached and does not wobble.





Image: Angled view of the PRO-SYS VarioSonic V200M Normal Soft Replacement Head, showing the connection point.

Operating Instructions

These Normal Soft brush heads are designed for daily use with your compatible electric toothbrush. Follow these guidelines for optimal cleaning:

- Apply a small amount of toothpaste to the bristles.
- Place the brush head against your teeth at a slight angle towards the gum line.
- Turn on your electric toothbrush. Move the brush head slowly from tooth to tooth, allowing the sonic vibrations to clean each surface.
- Brush gently for two minutes, twice daily, as recommended by dental professionals. Avoid hard brushing, as this can damage teeth and gums.
- Refer to your electric toothbrush's manual for specific instructions regarding cleaning modes and pressure sensors.





Image: Close-up view of the blue DuPont filaments on the V200M Normal Soft brush head.

Maintenance and Replacement

- **Daily Cleaning:** After each use, rinse the brush head thoroughly under running water to remove any toothpaste residue and debris.
- **Storage:** Store the brush head in a clean, dry place to prevent bacterial growth.
- **Replacement:** For optimal oral hygiene and cleaning effectiveness, replace your brush head every three months, or sooner if the bristles appear frayed or worn.



Image: Side view of the PRO-SYS VarioSonic V200M Normal Soft Replacement Head, illustrating its profile.

Troubleshooting

If you encounter any issues with your PRO-SYS VarioSonic V200M Normal Soft Replacement Heads, consider the following:

- **Brush Head Not Fitting Securely:** Ensure the brush head is correctly aligned with the toothbrush handle's shaft and pushed down firmly. If it still doesn't fit, check for any debris obstructing the connection.
- **Reduced Cleaning Performance:** If the bristles appear worn or splayed, it's time to replace the brush head. Worn bristles are less effective at cleaning.
- **Unusual Noise/Vibration:** Ensure the brush head is fully seated on the handle. If the issue persists, it might indicate a problem with the toothbrush handle itself.

For further assistance, please refer to the support section.

Specifications

Model Name	V200M
Item Model Number	5266-786
Brand Name	PRO-SYS
Manufacturer	PRO-SYS
Bristle Material	Nylon (DuPont Filaments)
Item Firmness Description	Soft (Normal Soft)
Compatible Devices	PRO-SYS VarioSonic, Burst
Color	White
Number of Pieces	3
Age Range Description	Adult
Package Dimensions	5.16 x 3.9 x 0.91 inches; 1.13 ounces

Warranty Information

PRO-SYS is committed to customer satisfaction. While specific warranty details for replacement heads are not provided, the brand generally offers a satisfaction guarantee. If you experience any issues with your VarioSonic replacement heads, please contact customer support for assistance.

Customer Support

For any questions, concerns, or assistance with your PRO-SYS VarioSonic V200M Normal Soft Replacement Heads, please contact PRO-SYS customer support. They are dedicated to ensuring your satisfaction and will help resolve any issues you may encounter.
Visit the official PRO-SYS website for contact information and additional resources:PRO-SYS Store

Additional Information

Watch the official PRO-SYS VarioSonic Electric Toothbrush video for an overview of the system and its benefits. This video provides context on the toothbrush handle and its compatibility with various brush heads, including the V200M Normal Soft.

Your browser does not support the video tag.

Video: Official PRO-SYS VarioSonic Electric Toothbrush overview, demonstrating features and brush head compatibility.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question