

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Avantco](#) /

› [Avantco S30 11 Qt. Round Black Countertop Food / Soup Kettle Warmer Instruction Manual](#)

Avantco S30

Instruction Manual

AVANTCO S30 11 QT. ROUND BLACK COUNTERTOP FOOD / SOUP KETTLE WARMER

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before operating this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always connect the appliance to a properly grounded outlet.
- Do not immerse the main unit (base) in water or other liquids.
- Ensure the voltage and wattage of the appliance match your power supply (120V, 400W).
- Do not operate the appliance with a damaged cord or plug.
- Keep hands and face away from hot surfaces during operation. Use oven mitts or heat-resistant gloves when handling hot components.
- Unplug the appliance from the outlet when not in use and before cleaning.
- This appliance is intended for commercial food warming purposes only.

PRODUCT OVERVIEW

The Avantco S30 Soup Kettle Warmer is designed to keep soups, sauces, and other hot foods at serving temperature for extended periods. Its robust construction and user-friendly controls make it ideal for various food service environments.

Components

- Main Unit (Base with Heating Element)
- Removable Bain Marie Insert (Stainless Steel)
- Hinged Lid with Ladle Notch (Stainless Steel)
- Temperature Control Dial
- Power Indicator Light



An Avantco S30 11 Qt. Round Black Countertop Food / Soup Kettle Warmer. The black base features a temperature control dial and indicator lights. A stainless steel Bain Marie insert is visible, topped with a matching hinged lid. The power cord extends from the back of the unit.

SETUP

1. Unpack all components and remove any packaging materials.
2. Place the main unit on a stable, level, heat-resistant surface. Ensure there is adequate ventilation around the unit.
3. Insert the stainless steel Bain Marie insert into the main unit.
4. Fill the space between the main unit and the Bain Marie insert with water. Do not overfill; ensure the water level is below the rim of the Bain Marie insert.
5. Place the food to be warmed into the Bain Marie insert.
6. Place the hinged lid on top of the Bain Marie insert.
7. Plug the power cord into a grounded 120V electrical outlet.

OPERATING INSTRUCTIONS

1. **Initial Warming:** To quickly bring food to serving temperature, turn the temperature control dial to a higher setting, typically between 8 and 12. The red indicator light will illuminate, indicating that the unit is heating.
2. **Maintaining Temperature:** Once the food has reached the desired serving temperature, turn the dial down to a lower setting (e.g., 4-7) to maintain warmth. The indicator light will cycle on and off as the unit regulates the temperature.
3. **Monitoring:** Periodically check the food temperature to ensure it remains within safe serving guidelines.
4. **Serving:** Use the hinged lid's notch for convenient ladle access.
5. **Shutting Down:** When finished, turn the temperature control dial to the 'OFF' position and unplug the unit from the power outlet. Allow the unit to cool completely before cleaning or storing.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your kettle warmer.

- The Bain Marie insert and the lid are dishwasher safe for easy cleaning.
- Always unplug the unit and allow it to cool completely before cleaning.

Cleaning Steps:

1. Remove the Bain Marie insert and the lid. Wash them with warm, soapy water or place them in a dishwasher. Rinse thoroughly and dry.
2. Drain any water from the main unit's reservoir.
3. Wipe the exterior and interior of the main unit with a damp cloth. For stubborn stains, use a mild, non-abrasive cleaner.
4. Do not use abrasive cleaners or scouring pads, as they may damage the finish.
5. Ensure all parts are completely dry before reassembling or storing the unit.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not heat	Not plugged in; Power outlet not working; Temperature dial set to 'OFF' or too low.	Ensure unit is plugged in; Check power outlet; Turn dial to a higher setting.
Food not warm enough	Temperature dial set too low; Insufficient water in reservoir.	Increase temperature setting; Add water to the reservoir between the insert and base.
Food too hot	Temperature dial set too high.	Decrease temperature setting.

SPECIFICATIONS

- **Brand:** Avantco
- **Model:** S30
- **Capacity:** 11 Quarts
- **Voltage:** 120 Volts
- **Wattage:** 400 Watts
- **Material:** Stainless Steel (Insert & Lid)
- **Item Weight:** 12.52 pounds
- **Package Dimensions:** 15.3 x 14 x 13.9 inches
- **UPC:** 689227596734

Related Documents - S30

 <p>User Manual</p> <p>Electric Bain Marie Countertop Food Warmer</p> <p>Model: 177BMFW3, 177BMFW4, 177BMFW5</p> <p>Please read and keep these instructions. For commercial use only.</p>	<p>Avantco Electric Bain Marie Countertop Food Warmer User Manual Models 177BMFW3, 177BMFW4, 177BMFW5</p> <p>Comprehensive user manual for the Avantco Electric Bain Marie Countertop Food Warmer. Includes installation, operation, safety, cleaning, parts identification, wiring diagram, and limited warranty information for models 177BMFW3, 177BMFW4, and 177BMFW5.</p>
 <p>User Manual</p> <p>Countertop Display Refrigerator</p> <p>2-Shelf Model: REF360CRM5HC REF360CRM7HC</p> <p>3-Shelf Model: REF360CRM5HC REF360CRM7HC</p> <p>Note: www.avantcoappliances.com</p>	<p>Avantco Countertop Display Refrigerator User Manual - Models 360CRM5HC & 360CRM7HC</p> <p>Comprehensive user manual for Avantco Countertop Display Refrigerators, covering installation, operation, temperature controls, safety guidelines, cleaning, and troubleshooting for models like the 360CRM5HC and 360CRM7HC series.</p>
 <p>User Manual</p> <p>Electric Rice Warmers with Sealed Lids</p> <p>Stainless Steel Model: 177RWB60 177RWB92</p> <p>Wood Grain Model: 177RWB60W 177RWB92W</p> <p>Note: www.avantcoappliances.com</p>	<p>Avantco Electric Rice Warmers with Sealed Lids User Manual</p> <p>User manual for Avantco Electric Rice Warmers with Sealed Lids, covering safety, operation, cleaning, and warranty information for models 177RWB60, 177RWB92, 177RWB60W, and 177RWB92W.</p>
 <p>User Manual</p> <p>Electric Rice Warmers with Sealed Lids</p> <p>Stainless Steel Model: 177RWB60 177RWB92</p> <p>Wood Grain Model: 177RWB60W 177RWB92W</p> <p>Note: www.avantcoappliances.com</p>	<p>Avantco Electric Rice Warmers with Sealed Lids User Manual</p> <p>User manual for Avantco Electric Rice Warmers with Sealed Lids, covering safety, operation, cleaning, and warranty information for models 177RWB60, 177RWB92, 177RWB60W, and 177RWB92W.</p>
 <p>User Manual</p> <p>3500 Watt Counter Top Wok Induction Range</p> <p>Model: 177IWC35</p> <p>Please read and keep these instructions. Indoor use only.</p>	<p>Avantco 3500 Watt Countertop Wok Induction Range User Manual</p> <p>Comprehensive user manual for the Avantco 177IWC35 3500 Watt Countertop Wok Induction Range, detailing specifications, important safeguards, operation instructions, cleaning, maintenance, and warranty information.</p>
 <p>User Manual</p> <p>Countertop Refrigerated Prep Rails</p> <p>REF360CPT360CPT480CPT600CPT720CPT</p> <p>Please read and keep these instructions. Indoor use only.</p>	<p>Avantco Countertop Refrigerated Prep Rails User Manual</p> <p>Comprehensive user manual for Avantco Countertop Refrigerated Prep Rails (360CPT series), covering installation, operation, temperature control, safety, maintenance, and troubleshooting for commercial food service environments.</p>