

[Manuals.plus](#) /

› [hansgrohe](#) /

› hansgrohe 26240001 Raindance E Showerhead Instruction Manual

hansgrohe 26240001

hansgrohe 26240001 Raindance E Showerhead Instruction Manual

Model: 26240001

1. PRODUCT OVERVIEW

The hansgrohe Raindance E Showerhead (Model 26240001) is designed to provide a refreshing shower experience. This showerhead features air-infused droplets for a softer, more voluminous spray. It is engineered for water efficiency, utilizing a maximum of 1.8 gallons per minute (EcoRight technology).



Image 1.1: hansgrohe Raindance E Showerhead in Chrome. This image displays the square design of the showerhead with its numerous spray nozzles, finished in polished chrome.

Key Features:

- **Spray Modes:** Features 3 distinct sprays:
 - **PowderRain:** A luxurious, soft rain shower.
 - **Intense PowderRain:** An invigorating spray of fine droplets.
 - **RainStream:** A focused jet for a soothing experience.
- **Water Efficiency:** Uses a maximum of 1.8 gallons per minute (EcoRight).
- **Finish:** Brilliant, easy-to-clean chrome surface.

- **QuickClean:** Silicone nozzles allow for easy wiping away of limescale.
- **XXL Performance:** 11.8-inch shower head provides even, lush water flow.
- **Adjustability:** Offers a 26-degree range for optimal positioning.
- **Connection:** Standard 1/2-inch connection for easy retrofit.

2. SAFETY INFORMATION

Please read all instructions carefully before installation and use. Failure to follow these instructions may result in property damage or personal injury.

- Always turn off the main water supply before beginning any installation or maintenance.
- Ensure all connections are secure to prevent leaks.
- Do not use abrasive cleaners or harsh chemicals on the showerhead finish, as this may cause damage.
- If you are unsure about any part of the installation process, it is recommended to consult a licensed plumber.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- hansgrohe Raindance E Showerhead (Model 26240001)

Note: Additional plumbing components such as a shower arm, flange, or sealant are typically sold separately and are not included with the showerhead.

4. SETUP AND INSTALLATION

hansgrohe recommends that a licensed plumber install this product to ensure proper function and adherence to local plumbing codes.

Installation Steps:

1. **Turn off Water Supply:** Locate and turn off the main water supply to your shower area.
2. **Remove Old Showerhead (if applicable):** Unscrew the existing showerhead from the shower arm. Clean any old sealant or debris from the shower arm threads.
3. **Apply Thread Sealant:** Apply plumber's tape or thread sealant to the threads of the shower arm.
4. **Attach New Showerhead:** Carefully screw the hansgrohe Raindance E Showerhead onto the shower arm. Hand-tighten first, then use a wrench to tighten an additional quarter to half turn. Do not overtighten.
5. **Adjust Angle:** The showerhead can be adjusted up to 26 degrees to achieve the desired spray angle.
6. **Check for Leaks:** Turn the main water supply back on and check for any leaks around the connection point. If leaks occur, turn off the water, tighten the connection slightly, and recheck.

5. OPERATING INSTRUCTIONS

The hansgrohe Raindance E Showerhead is designed for simple operation, delivering a consistent flow of water with various spray modes.

Using Spray Modes:

This showerhead features a single control for selecting between its three spray modes: PowderRain, Intense PowderRain, and RainStream. Rotate the central dial on the showerhead face to cycle through the available spray patterns.

- **PowderRain:** Provides a gentle, enveloping spray.
- **Intense PowderRain:** Offers a more invigorating and focused spray.
- **RainStream:** Delivers a concentrated, soothing jet.

The showerhead operates at a flow rate of 1.8 gallons per minute (GPM) to conserve water while maintaining performance.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your hansgrohe Raindance E Showerhead.

Cleaning the Showerhead:

- **Limescale Removal (QuickClean):** The silicone nozzles are designed for easy limescale removal. Simply rub your finger across the nozzles to dislodge any mineral buildup.
- **Surface Cleaning:** Clean the chrome surface with a soft cloth and a mild, non-abrasive cleaner specifically designed for bathroom fixtures.
- **Avoid Harsh Chemicals:** Do not use cleaners containing ammonia, bleach, acids, or abrasive particles, as these can damage the finish and internal components.
- **Rinse Thoroughly:** After cleaning, rinse the showerhead thoroughly with clean water to remove any cleaner residue.

7. TROUBLESHOOTING

If you encounter issues with your hansgrohe Raindance E Showerhead, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Low Water Pressure	Clogged nozzles or internal filter.	Clean the silicone nozzles using the QuickClean feature. If pressure remains low, carefully unscrew the showerhead and check for debris in the internal filter screen. Clean as necessary.
Leaking at Connection Point	Loose connection or insufficient thread sealant.	Turn off water supply. Tighten the showerhead connection slightly. If leaking persists, remove the showerhead, reapply plumber's tape or thread sealant, and reattach.

Problem	Possible Cause	Solution
Water Spraying Unevenly	Blocked nozzles.	Use the QuickClean feature to rub the silicone nozzles and dislodge any mineral buildup.

If these steps do not resolve the issue, please contact hansgrohe customer support or a licensed plumber.

8. SPECIFICATIONS

Brand	hansgrohe
Model Number	26240001
Color	Chrome
Material	Ceramic (internal components)
Style	American
Shape	Showerhead (Square)
Flow Rate	1.8 GPM (Gallons Per Minute)
Number of Settings	3 (PowderRain, Intense PowderRain, RainStream)
Item Weight	7.72 pounds
Product Dimensions	11.75 x 11.75 x 1.75 inches
Connection Type	Standard 1/2-inch
Efficiency	Water-saving (EcoRight)

9. WARRANTY AND SUPPORT

Warranty Information:

Hansgrohe, Inc. warrants to the original consumer purchaser that hansgrohe products will be free from defects in material and workmanship for as long as the original consumer purchaser owns both the product and the home in which the product was originally installed. For commercial purchasers, the warranty period is one (1) year from the date of purchase. The warranty period for products in Rubbed Bronze, Matte Black, and Matte White finishes is three (3) years from the date of purchase. This warranty is non-transferable.

Please note that this warranty does not cover hansgrohe products purchased from unauthorized sellers, unless otherwise prohibited by law. Authorized sellers can be found on hansgrohe branded websites. Additional warranty restrictions apply.

For full warranty details, please visit the official hansgrohe website.

Customer Support:

For technical assistance, replacement parts, or further inquiries, please contact hansgrohe customer support through their official website or designated service channels.



© 2023 hansgrohe. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.