

Keter 231317

Keter Comfy Storage Box User Manual

Model: 231317

1. INTRODUCTION

Thank you for choosing the Keter Comfy Storage Box. This elegant and robust outdoor storage chest is designed to provide a practical and aesthetic solution for organizing your outdoor space. Made from high-quality, weather-resistant resin, it offers exceptional longevity and integrates harmoniously into any outdoor environment. With a generous capacity of 270 liters, it is ideal for storing outdoor cushions, garden tools, children's toys, and more.

This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your Keter Comfy Storage Box. Please read all instructions carefully before assembly and use.



Figure 1: Keter Comfy Storage Box (Closed)

2. SAFETY INFORMATION

- Always ensure the storage box is placed on a flat, stable surface to prevent tipping.
- Do not allow children to climb on or play inside the storage box. There is a risk of entrapment or injury.

- Do not store flammable, corrosive, or hazardous materials inside the box.
- Keep the lid closed when not in use to prevent water accumulation and to protect contents.
- Distribute weight evenly inside the box; do not overload.
- When moving the box, ensure the lid is securely closed and use the integrated side handles.

3. PARTS LIST

Before beginning assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, please contact Keter customer support.

- Front Panel (1)
- Back Panel (1)
- Side Panels (2)
- Base Panel (1)
- Lid (1)
- Hinges (2)
- Wheels (2) - *if applicable to your model*
- Assembly Instructions (1)

4. SETUP AND ASSEMBLY

The Keter Comfy Storage Box features an interlocking design for quick and easy assembly without the need for screws or complex tools. It can typically be assembled in approximately 3 minutes.

1. **Prepare the Area:** Choose a flat, clean, and stable surface for assembly.
2. **Attach Side Panels to Base:** Carefully align the grooves of the side panels with the corresponding slots on the base panel. Press firmly until they click into place.
3. **Attach Front and Back Panels:** Connect the front and back panels to the assembled side panels and base. Ensure all connections are secure and flush.
4. **Install Hinges:** Attach the hinges to the designated points on the back panel and the lid.
5. **Attach Lid:** Carefully align the lid with the hinges and press down until it securely attaches. Ensure the lid opens and closes smoothly.
6. **Install Wheels (Optional):** If your model includes wheels, snap them into the designated slots on one end of the base for easier mobility.



Figure 2: Key Features and Assembly Overview



Figure 3: Product Dimensions

5. OPERATING INSTRUCTIONS

5.1 Opening and Closing the Lid

To open the lid, simply lift it from the front. The lid is designed to open smoothly up to 90 degrees for easy access to your stored items. To close, gently lower the lid until it rests securely on the box.



Figure 4: Storage Box in Open Position

5.2 Storage Capacity

The Keter Comfy Storage Box has a capacity of 270 liters. It is suitable for storing various outdoor items such as cushions, garden tools, pool accessories, and toys. Ensure items are dry before storing to prevent mold or mildew.



Figure 5: Storing Items

5.3 Mobility

The box is equipped with integrated side handles for easy lifting and repositioning. If your model includes wheels, tilt the box slightly and roll it to your desired location.

5.4 Seating Functionality

The robust construction of the Keter Comfy Storage Box allows it to be used as additional seating. The lid is designed to support weight, making it a versatile addition to your patio or garden.



Figure 6: Using the Box as Seating

6. MAINTENANCE

The Keter Comfy Storage Box is made from durable, weather-resistant resin and requires minimal maintenance.

- **Cleaning:** Clean the box periodically with a soft cloth, mild soap, and water. Avoid abrasive cleaners or harsh chemicals, as these can damage the resin.
- **Weather Protection:** While the box is weather-resistant, prolonged exposure to extreme weather conditions (e.g., heavy snow, prolonged direct sunlight) may affect its appearance over time.
- **Inspection:** Periodically check hinges and panel connections to ensure they remain secure.

7. TROUBLESHOOTING

- **Lid does not close properly:** Ensure no items are obstructing the lid's path. Check that the box is on a level surface and that all panels are securely interlocked.
- **Water inside the box:** Although designed to be waterproof, ensure the lid is fully closed and latched.

Check for any cracks or damage to the resin. Ensure the box is not placed in an area where water can pool around its base.

- **Box feels unstable:** Verify that the box is placed on a completely flat and stable surface. Re-check all panel connections to ensure they are fully engaged.

8. SPECIFICATIONS

Feature	Detail
Brand	Keter
Model Number	231317
Product Dimensions (L x W x H)	116.7 x 44.7 x 57 cm
Weight	7.2 Kilograms
Color	Comfy Brown
Material	Resin
Special Feature	Weatherproof
Recommended Uses	Outdoor storage, seating
Capacity	270 Liters
Closure Type	Flip Lid
Water Resistance Level	Waterproof
Country of Origin	Israel

9. WARRANTY AND SUPPORT

For information regarding warranty coverage, please refer to the warranty card included with your product or visit the official Keter website. For technical support, missing parts, or any other inquiries, please contact Keter customer service through their official channels.

Thank you for choosing Keter. We hope you enjoy your Comfy Storage Box for many years to come.

Documents - Keter – 231317

no relevant documents