

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SEGA](#) /

› [Sega Love Live! Sunshine!! Little Daemon SPM Super Premium Figure Chika Takami Instruction Manual](#)

SEGA qpb

Sega Love Live! Sunshine!! Little Daemon SPM Super Premium Figure Chika Takami Instruction Manual

Model: qpb

1. INTRODUCTION

This manual provides essential instructions for the proper setup, assembly, care, and maintenance of your Sega Love Live! Sunshine!! Little Daemon SPM Super Premium Figure of Chika Takami. Please read this manual thoroughly before handling the figure to ensure its longevity and preserve its quality.

2. PRODUCT OVERVIEW

The Sega Love Live! Sunshine!! Little Daemon SPM Super Premium Figure features Chika Takami, a character from the popular anime series Love Live! Sunshine!! This collectible figure captures Chika in her distinctive "Little Daemon" outfit, showcasing intricate details and vibrant colors. It is designed as a display piece for enthusiasts and collectors.

- Officially Licensed:** This figure is an officially licensed product by Sega.
- Detailed Sculpting:** Features detailed sculpting of Chika Takami in her "Little Daemon" attire.
- Approximate Size:** Measures approximately 8.2 inches in height.
- Collectible Item:** Designed as a limited and collectible item.

3. SETUP AND ASSEMBLY

Your figure may require minor assembly. Please handle all parts with care to avoid damage. Ensure you have a clean, flat surface for assembly.

- Unboxing:** Carefully remove all components from the packaging. Inspect for any visible damage. Retain packaging for future storage or transport.
- Base Attachment:** The figure typically comes with a display base. Gently align the pegs on the figure's feet with the corresponding holes on the base. Apply light, even pressure to secure the figure onto the base. Do not force parts together.
- Accessory Placement (if applicable):** If any small accessories are included, carefully attach them to the designated areas on the figure. Refer to the product images for correct placement.

4. **Display:** Place the assembled figure on a stable, level surface away from direct sunlight, extreme temperatures, and high humidity.



Figure Components: This image displays the Chika Takami figure, highlighting its detailed costume and pose. The figure is typically packaged with its base and any minor accessories separate for assembly.



Assembled Figure: This image shows the Chika Takami figure fully assembled on its clear circular display base, ready for display. Note the secure attachment to the base for stability.

4. CARE AND MAINTENANCE

Proper care will help maintain the appearance and condition of your figure over time.

- **Dusting:** Regularly dust the figure with a soft, dry brush or a microfiber cloth. Avoid abrasive materials that could scratch the paint.
- **Cleaning:** For stubborn dirt, lightly dampen a soft cloth with plain water (distilled water is preferred) and gently wipe the affected area. Do not use harsh chemicals, solvents, or abrasive cleaners, as these can

damage the paint or material.

- **Handling:** Always handle the figure by its base or main body. Avoid touching delicate parts like hair, fingers, or small accessories, as they can be fragile.
- **Display Environment:**
 - Keep the figure away from direct sunlight to prevent fading of colors.
 - Avoid extreme temperature fluctuations and high humidity, which can cause material degradation.
 - Display in a stable location where it is unlikely to be knocked over.

5. TROUBLESHOOTING

If you encounter any issues with your figure, consider the following:

Problem	Possible Cause	Solution
Figure does not fit onto base.	Incorrect alignment or minor manufacturing variance.	Ensure pegs and holes are correctly aligned. Apply gentle, even pressure. Do not force. If still an issue, contact customer support.
Dust accumulation.	Exposure to open air.	Gently clean with a soft, dry brush or microfiber cloth. Consider displaying in a dust-proof case.
Figure appears unstable.	Improper base attachment or uneven display surface.	Re-attach figure to base, ensuring a secure fit. Place on a completely flat and stable surface.

6. SPECIFICATIONS




- **Brand:** SEGA
- **Model Number:** qpb
- **Approximate Height:** 8.2 inches
- **Item Weight:** 12.5 ounces
- **Package Dimensions:** 10.12 x 6.38 x 4.69 inches
- **Material:** PVC/ABS (typical for figures, inferred)

7. WARRANTY AND SUPPORT

Specific warranty information for collectible figures may vary by retailer or region. Please retain your proof of purchase. For any product-related inquiries, manufacturing defects, or support, please contact the retailer where the figure was purchased or the official SEGA customer support channels.

You can visit the official SEGA store for more information:[SEGA Store on Amazon](#)

Related Documents - qpb

	<p>Sega Genesis Motherboard Replacement Guide</p> <p>Detailed step-by-step instructions for replacing the motherboard in a Sega Genesis Model 1001. This guide covers disassembly, component identification, and reassembly for retro gaming enthusiasts.</p>
	<p>Kid Chameleon - SEGA Mega Drive Classics Game Manual</p> <p>Official game manual for Kid Chameleon on SEGA Mega Drive Classics, detailing gameplay, controls, character transformations, items, and support information.</p>
	<p>Sega Strike Fighter Owner's Manual</p> <p>Comprehensive owner's manual for the Sega Strike Fighter arcade game, detailing installation, operation, safety precautions, and maintenance.</p>
	<p>Sega Saturn Instruction Manual: Setup, Operation, and Troubleshooting Guide</p> <p>Comprehensive instruction manual for the Sega Saturn video game console, covering setup, connecting to your TV, operating the system, playing games and audio CDs, troubleshooting, and hardware specifications.</p>
	<p>After Burner Sega 32X Instruction Manual</p> <p>Instruction manual for the Sega 32X game After Burner, detailing gameplay, controls, mission objectives, and game features.</p>
	<p>Sega Saturn Instruction Manual: Setup, Operation, and Troubleshooting</p> <p>Comprehensive instruction manual for the Sega Saturn video game console, covering setup, connecting peripherals, gameplay, audio CD functions, system settings, troubleshooting, hardware specifications, and warranty information.</p>