

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [MAYFLASH](#) /

› [MAYFLASH Magic NS Wireless Bluetooth Controller USB Adapter for Switch/Switch 2, Steam Deck, macOS, Windows, Raspberry Pi, Compatible with Xbox Series S/X,PS5 Controller and More MAGIC NS 1](#)

## MAYFLASH MAGIC-NS

# MAYFLASH Magic NS Wireless Bluetooth Controller USB Adapter

Model: MAGIC-NS

### INTRODUCTION

The MAYFLASH Magic NS Wireless Bluetooth Controller USB Adapter is a versatile device designed to expand your controller compatibility across multiple gaming platforms. This adapter allows you to use your favorite Bluetooth and wired USB controllers with systems such as Nintendo Switch, PC (Windows), Steam Deck, macOS, and Raspberry Pi. It supports advanced features like 6-axis motion, vibration, Turbo, and Auto Fire, providing a seamless and enhanced gaming experience.



*The MAYFLASH Magic NS USB Adapter, a compact device for expanded controller compatibility.*

## SETUP GUIDE

### Connecting the Adapter to Your System

The Magic NS adapter connects via a standard USB-A port. A USB Type-C cable is included for systems requiring it.



*The adapter connected to a Nintendo Switch dock, demonstrating its compact size and integration.*

#### **Nintendo Switch/Switch 2 Setup:**

1. Ensure your Nintendo Switch is docked.
2. Navigate to System Settings > Controllers and Sensors.
3. Enable the "Pro Controller Wired Communication" option.
4. Plug the Magic NS adapter into an available USB port on the Switch dock.

#### **PC (Windows), Steam Deck, macOS, Raspberry Pi Setup:**

- Plug the Magic NS adapter into an available USB port on your device.
- The system should automatically recognize the adapter.

#### **Pairing Your Controller**

The Magic NS adapter supports both Bluetooth and wired USB controllers.

#### **Bluetooth Controllers (PS5/PS4/PS3, Xbox Series X/S, Switch Pro, Joy-Con, Wii Remote, Wii U Pro):**

1. Press the SYNC button on the Magic NS adapter until the LED indicator starts blinking rapidly (indicating pairing mode).
2. Put your Bluetooth controller into pairing mode (refer to your controller's manual for specific instructions).

3. The adapter's LED will become solid when successfully paired.

### **Wired USB Controllers:**

- Connect your wired USB controller directly to the female USB port on the Magic NS adapter.
- The adapter will automatically recognize the controller.

*Official video demonstrating the setup and use of the MAGIC-NS Wireless BT Controller USB Adapter for Switch.*

## **OPERATING INSTRUCTIONS**

### **LED Indicators and Modes**

The Magic NS adapter features LED indicators that show the current operating mode:

- **Red:** Dinput (PS3/PC)
- **Purple:** Switch Pro
- **Green:** Xinput (PC)
- **Yellow:** NEOGEO
- **White:** SEGA
- **Blue:** macOS

### **Switching Modes**

To switch between modes, press and hold the button on the side of the Magic NS adapter for 3-5 seconds until the LED changes to the desired color.



*The adapter seamlessly integrates into your gaming setup, providing versatile controller options.*

## Special Features

- **6-axis Motion (Gyroscope):** Supported on Nintendo Switch and Switch 2.
- **Vibration:** Supported on Switch/Switch 2, Xinput, and PS3. Vibration intensity can be adjusted.
- **Turbo and Auto Fire:** Features 3 turbo speeds for rapid input.
- **Button Exchange:** Buttons A, B, X, Y can be exchanged for customized layouts.
- **Lag-Free:** Designed for a responsive gaming experience.

*Official video showcasing the MAGIC-NS Wireless BT Controller USB Adapter for Steam Deck, highlighting its features.*

*Official video demonstrating the MAGIC-NS Wireless Bluetooth Controller USB Adapter for PC, including turbo and auto-fire functions.*

## MAINTENANCE

To ensure the longevity and optimal performance of your MAYFLASH Magic NS adapter, follow these

simple maintenance guidelines:

- Keep the adapter clean by wiping it with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures.
- Regularly check for and install firmware updates from the official Mayflash website to ensure compatibility with the latest controllers and systems.

## TROUBLESHOOTING

If you encounter issues with your Magic NS adapter, consider the following common solutions:

- **Xbox Series S/X Controller Connection Issues:** Update your Xbox Series S/X controller to the latest version.
- **PS5 Edge Controller Issues:** Update the adapter to the latest firmware from the Mayflash website.
- **Nintendo Switch Connection Issues:** Reboot your Switch game console twice if you experience problems.
- **General Connectivity:** Ensure the adapter is firmly plugged into the USB port. Try a different USB port if available.
- **Pairing Problems:** Ensure both the adapter and controller are in pairing mode. Try re-pairing the devices.

For more detailed troubleshooting guides and specific error resolutions, please visit the official Mayflash website.

## SPECIFICATIONS

Feature	Detail
Model Number	MAGIC-NS
Product Dimensions	3.5 x 2.2 x 0.6 inches
Item Weight	1.06 ounces
System Compatibility	Switch, Switch 2, PC Windows, Steam Deck, macOS, Raspberry Pi, Steam, PS3, NEOGEO Arcade Stick Pro, MEGA DRIVE mini, Genesis Mini
Bluetooth Controller Compatibility	PS5/PS4/PS3 controllers, Xbox Series X/S, Xbox One Bluetooth controllers, Xbox Elite Wireless Controller Series 2, Switch Pro, Switch Joy-Con, Wii Remote, Wii U Pro controllers

Wired USB Controller Compatibility	PS5/PS4/PS3 Controller, Xbox Bluetooth Controller, Switch Pro, ASTRO Gaming C40 TR Controller PlayStation 4, PlayStation 4 SCUF Vantage 2 Controller, SEGA MEGA DRIVE and SEGA Genesis Mini USB Controller Pads, Logitech rumble gamepad F510 and F310, PS Classic Controller, Switch Taiko Drum, PS4 Taiko Drum
Special Features	6-axis motion (gyroscope) on Switch, Vibration on Switch/Xinput/PS3, Adjustable vibration intensity and dead zone, Turbo and Auto Fire (3 speeds), Exchangeable A/B/X/Y buttons, Lag-free
Included in Box	Magic NS Adapter, USB Type C Cable, Manual

## WARRANTY INFORMATION

Specific warranty details for the MAYFLASH Magic NS Wireless Bluetooth Controller USB Adapter are typically provided by the manufacturer. Please refer to the official Mayflash website or the product packaging for the most up-to-date and comprehensive warranty information.

## SUPPORT


For further assistance, technical support, or to download the latest firmware updates for your MAYFLASH Magic NS adapter, please visit the official Mayflash website:

[www.mayflash.com](http://www.mayflash.com)

Regularly checking the website for updates is recommended to ensure optimal performance and compatibility with new controllers and systems.

## Related Documents - MAGIC-NS

	<p><a href="#"><u>Mayflash MAGIC-NS Lite USB Wireless Adapter User Manual</u></a></p> <p>Comprehensive user manual for the Mayflash MAGIC-NS Lite USB Wireless Adapter, covering setup, system and controller compatibility, mode switching, advanced features like vibration and dead zone adjustment, firmware updates, and troubleshooting.</p>
	<p><a href="#"><u>MAYFLASH MAGIC-NS Lite USB Wireless Adapter User Manual</u></a></p> <p>User manual for the MAYFLASH MAGIC-NS Lite, a USB wireless adapter that enables connection of various Bluetooth controllers to Nintendo Switch, PC, PlayStation 3, macOS, and other systems. Includes setup, compatibility, mode switching, vibration, and dead zone adjustments.</p>

 <p><b>Mayflash Magic NS Controller Adapter</b> Mayflash Magic NS Controller Adapter is a wireless adapter that allows you to connect your Nintendo Switch, PC, or PS3 to your computer via a USB port. It features a built-in rechargeable battery and a compact design. The adapter supports various controllers, including Joy-Con, DualShock 4, and PS3 DualShock 3. It also includes a built-in microphone and speaker for audio output. The adapter is easy to set up and use, making it a great addition to your gaming setup.</p>	<p><a href="#"><u>Mayflash Magic NS Controller Adapter Quick Start Guide</u></a></p> <p>A comprehensive quick start guide for the Mayflash Magic NS Wireless Bluetooth Controller USB Adapter, detailing setup for Nintendo Switch, PC, and PS3 with various controllers, LED indicators, mode switching, and software updates.</p>
	<p><a href="#"><u>Mayflash MAGIC-X USB Wireless Adapter User Manual</u></a></p> <p>User manual for the Mayflash MAGIC-X USB Wireless Adapter, detailing its compatibility, setup, and advanced functions for connecting various controllers to multiple gaming systems.</p>
	<p><a href="#"><u>Mayflash MAGIC-S PRO 2 USB Wireless Adapter User Manual and Guide</u></a></p> <p>Comprehensive user manual for the Mayflash MAGIC-S PRO 2 USB Wireless Adapter, detailing system compatibility, controller setup, advanced features like vibration and dead zone adjustment, software updates, and FCC compliance.</p>
	<p><a href="#"><u>Mayflash MAGIC-S PRO 2 USB Wireless Adapter User Manual</u></a></p> <p>Comprehensive guide to the Mayflash MAGIC-S PRO 2 USB Wireless Adapter, covering system compatibility, controller connections, setup, firmware updates, and advanced features for gaming.</p>