

Manuals.plus /

› Siljoy /

› Siljoy 42-inch Tiffany Ceiling Fan Instruction Manual

Siljoy 788601819060

Siljoy 42-inch Tiffany Ceiling Fan Instruction Manual

Model: 788601819060

1. SAFETY INSTRUCTIONS

Please read all instructions carefully before installation and use. Retain this manual for future reference.

- Ensure the power supply is disconnected before installation, cleaning, or maintenance.
- Installation must be performed by a qualified electrician.
- Mounting surface must be capable of supporting a minimum of 40 kg (88 lbs).
- Do not install the fan on a roof with leaks or in damp conditions.
- Ensure all connections are secure and properly insulated.
- Keep hands clear of fan blades during operation.

2. PACKAGE CONTENTS

Verify all components are present before beginning installation.



Image: Overview of all components included in the package.

Item No.	Component
1	Remote Control
2	Downrod
3	LED Driver
4	Canopy
5	Long Downrod
6	LED Panel
7	Mounting Bracket
8	Light Shade
9	Hardware Bag
10	Instruction Manual
11	Light Shade (Tiffany style)
12	Fan Motor Assembly

3. SETUP & INSTALLATION

3.1 Tools Required

- Phillips screwdriver
- Flat blade screwdriver
- Adjustable wrench
- Step ladder
- Wire cutters
- Electrical tape

3.2 Assembly Steps

For a detailed visual guide, please refer to the 'Tiffany Installation Video' below.

Your browser does not support the video tag.

Video: A comprehensive guide to installing the Tiffany Ceiling Fan.

1. **Prepare the Fan Motor Assembly:** Carefully remove any protective packaging from the fan motor assembly.
2. **Attach Fan Blades:** Secure each fan blade to its corresponding blade holder using the provided screws and washers. Ensure they are tightened firmly.
3. **Install Downrod:** Feed the electrical wires from the fan motor through the downrod. Secure the downrod to the fan motor assembly using the provided pin and screws.
4. **Mounting Bracket Installation:** Secure the mounting bracket to your ceiling junction box. For concrete ceilings, drill holes and use expansion screws. For wooden ceilings, use wood screws. Ensure the bracket is firmly attached and can support the fan's weight.

5. **Hang the Fan:** Carefully lift the fan assembly and hang it onto the mounting bracket. Ensure the downrod ball is properly seated in the bracket's groove.
6. **Electrical Wiring:** Connect the fan's electrical wires to your household wiring according to the wiring diagram in the manual. Ensure all connections are secure with wire nuts and electrical tape. Connect the receiver for the remote control at this stage.
7. **Install LED Panel:** Attach the LED panel to the fan motor assembly and connect its wires to the LED driver.
8. **Attach Light Shade:** Carefully attach the Tiffany-style light shade to the fan motor assembly, ensuring it is secure.
9. **Final Checks:** Double-check all connections and ensure no wires are pinched. Restore power and test the fan and light functions.

4. OPERATING INSTRUCTIONS

4.1 Remote Control Functions

The fan and light can be controlled using the included remote control.



Image: Layout of the remote control with button descriptions.

- **Lights On/Off:** Toggles the light on or off.
- **All Off:** Turns off both the light and the fan.
- **Quick Switch for Light Colors:** Cycles through cool white, natural white, and warm white.
- **Night Mode:** Activates a low-light setting.
- **SET UP:** Press to adjust color temperature.
- **F/R (Forward/Reverse Wind):** Changes the direction of fan blade rotation for summer (downward airflow) or winter (upward airflow).
- **6 Fan Speed Buttons (1-6):** Adjusts fan speed from gentle (1-2) to strong (5-6).
- **Wind Speeds Changed Auto:** Activates a natural wind simulation mode.
- **Timer Buttons (1H, 2H, 4H, 8H):** Sets the fan to turn off automatically after the selected duration.
- **Fan Off:** Turns off the fan.

Note: Please insert 2 AAA 1.5V batteries before using the remote (not included).

4.2 App Control

Control your fan and light conveniently from your smartphone.



Image: Smartphone app interface for controlling the fan and light.

Scan the QR code in the image above or visit <http://www.jasonghost.com/fanlamppro/> to download the FanLampPro app. The app allows for individual control of fan and light, dimming, color temperature adjustment, fan speed settings, and timing functions.

4.3 Light Settings

The integrated LED light offers three adjustable color temperatures and dimming capabilities:

- **Cool White (6000K):** Ideal for work or study environments.
- **Natural White (4500K):** Suitable for general family life.
- **Warm White (3000K):** Creates a cozy atmosphere for relaxation.

Brightness is dimmable from 5% to 100% via remote or app.



Optional Color Temperature: 6000K-2700K



Dimming Range: 5%-100%



5%

25%

50%

75%

100%




Image: Visual representation of adjustable color temperatures and dimming range.

4.4 Fan Speed and Modes

The fan features 6 wind speeds and a reversible motor for year-round comfort.

- **6 Wind Speeds:** Ranging from gentle breeze to super cool wind.
- **Reversible Motor:** Changes the direction of airflow. Downward airflow (summer mode) provides a cooling effect, while upward airflow (winter mode) helps circulate warm air.
- **Retractable Blades:** The 4 acrylic blades automatically extend when the fan is on and retract when turned off, maintaining a sleek appearance.

PRODUCT SPECIFICATION



SUMMER MODE

Cool and comfortable
Increase the flow of cold air!

WINTER MODE

360 ° circulating air flow
Reduce the temperature difference
between cold and warm!

Image: Illustration of summer mode (downward airflow) and winter mode (upward airflow).

Your browser does not support the video tag.

Video: Demonstrates the automatic retraction and extension of the fan blades.


5. MAINTENANCE

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure power is off before cleaning.
- **Light Source:** The LED light strip is designed for easy replacement if needed.
- **General Care:** Periodically check all screws and connections for tightness.


6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not start	No power supply; loose wiring; remote control battery low.	Check circuit breaker; ensure all wires are connected; replace remote batteries.
Light does not turn on	Loose wiring; LED panel issue.	Check light wiring connections; contact support if LED panel is faulty.
Fan makes noise	Loose screws; unbalanced blades.	Tighten all screws; ensure blades are balanced (refer to installation video for guidance).
Remote control not working	Batteries dead; remote not paired.	Replace batteries; refer to remote pairing instructions (if applicable).

7. SPECIFICATIONS



DIMENSIONS



PRODUCT SPECIFICATION

Fan Speed: 6	Voltage: 120V
Diameter: 42"	Fan Control: Remote & APP Control
Light Source: 32W LED Panel(INCLEDUED)	Material: Metal, Acrylic, Stained Glass
Overall Height Min: 21" with a 5" rod	Overall Height Max : 26" with a 10" rod

Image: Detailed dimensions and key product specifications.

Feature	Detail
Brand	Siljoy
Model Number	788601819060
Color	Brown
Material	Iron, Acrylic, Stained Glass
Product Dimensions (Blades Extended)	42"L x 20"W x 19"H (107cm L x 51cm W x 48cm H)
Product Dimensions (Blades Folded)	Diameter 18" (46cm)
Overall Height (with 5" rod)	18.7 inches (47.5cm)
Indoor/Outdoor Usage	Indoor
Power Source	DC
Voltage	120 Volts
Light Source Type	LED (32W LED Panel included)
Wattage	36 watts
Light Color	Cool White, Natural White, Warm White
Brightness	425-6120 Lumen
Control Method	Remote, App Control
Fan Speed	6 speeds
Timing Function	1/2/4/8 hours
Item Weight	20 Pounds

8. WARRANTY & SUPPORT

Siljoy is committed to providing quality products and customer satisfaction. This product comes with assured quality and service.

For any questions, technical assistance, or warranty claims, please refer to the contact information provided with your purchase or visit the official Siljoy website.