Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AP Products 013-4300

AP Products 013-4300 Slide-Out Sled User Manual

Model: 013-4300

Product Overview

The AP Products 013-4300 Slide-Out Sled is designed to protect the hard surfaces, such as linoleum flooring, in your RV from damage caused by slide-out mechanisms. These durable and reusable sleds provide a smooth surface for the slide-out to glide over, preventing scratches, tears, and other wear.



Image: A pair of AP Products 013-4300 Slide-Out Sleds. One sled is displayed with its white PVC-coated top surface visible, while the other is flipped to show its black rubber foam backing. Both sleds feature eyelets at each end.

Components

- **Slide-Out Sleds (Pair):** Each package contains two sleds.
- **Durable PVC Coating:** The top surface of the sleds is coated with durable PVC for smooth gliding.

- **Rubber Foam Backing:** The bottom surface features a rubber foam backing to prevent the sleds from slipping during use.
- **Eyelets:** Each end of the sled includes an eyelet, allowing for optional bungee cord attachment if needed to secure multiple sleds together or for retrieval.



Image: A top-down view of the two sleds, clearly showing the white PVC top surface of one sled and the black rubber foam backing of the other, highlighting the different materials on each side.

Setup and Operation

The AP Products 013-4300 Slide-Out Sleds are designed for simple and effective use to protect your RV's flooring.

1. **Extend Slide-Out:** Ensure your RV's slide-out room is fully extended to its outward position.
2. **Position Sleds:** Place the slide-out sleds on the floor directly underneath the leading edge of the slide-out room. The white, smooth PVC side should face upwards, and the black rubber foam backing should be in contact with your RV's floor.
3. **Align with Slide-Out:** Push the sleds slightly under the slide-out's edge, ensuring they are positioned where the slide-out will make contact with the floor during retraction. It is recommended to use a sled on each side of the slide-out, and for longer slide-outs, additional sleds may be necessary to provide continuous protection.
4. **Retract Slide-Out:** Slowly retract the RV's slide-out room. The slide-out mechanism will glide smoothly over the sleds, preventing direct contact and friction with your flooring.
5. **Remove Sleds:** Once the slide-out is fully retracted, carefully remove the sleds from underneath.

These sleds are designed to be flexible and durable, allowing the slide-out to glide without damaging the floor. They are also known as slide-out glides, slickers, or protectors.

Maintenance

The AP Products 013-4300 Slide-Out Sleds are designed for long-lasting and reusable performance with minimal maintenance.

- **Cleaning:** Periodically inspect the sleds for dirt, debris, or grime. Clean with a damp cloth and mild soap if necessary. Ensure they are dry before storage.
- **Storage:** Store the sleds in a clean, dry place when not in use to prolong their lifespan.
- **Inspection:** Before each use, check the sleds for any signs of wear, cracks, or damage to the PVC coating or foam backing. Replace if significant damage is observed to ensure optimal floor protection.

Troubleshooting

Problem	Possible Cause	Solution
Sleds slip during slide-out retraction.	Incorrect orientation (foam side not down) or debris on foam backing/floor.	Ensure the black rubber foam backing is facing down on the floor. Clean the foam backing and the floor surface to remove any slippery substances or debris.
Slide-out does not glide smoothly over sleds.	Sleds are not properly aligned or there is excessive friction.	Reposition the sleds to ensure they are directly under the slide-out's contact points. Verify the white PVC surface is clean and free of obstructions.
Floor still shows signs of wear/damage.	Insufficient number of sleds used for slide-out length, or sleds are worn out.	For longer slide-outs, use additional sleds to cover the entire contact area. Inspect sleds for wear and replace if necessary. Ensure the slide-out mechanism itself is functioning correctly and not causing excessive pressure.

Specifications

- **Model:** 013-4300
- **Brand:** AP Products
- **Material:** PVC (top coating), Rubber Foam (backing)
- **Color:** Black/White
- **Product Dimensions (Each Sled):** 47 inches (Length) x 7 inches (Width) x 0.75 inches (Thickness)
- **Item Weight (Each Sled):** Approximately 1.85 pounds
- **Package Contents:** 2 x Slide-Out Sleds
- **UPC:** 796976483953
- **Country of Origin:** USA

Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the official AP Products website or contact their customer service directly. Contact details are typically available on the product packaging or the manufacturer's official website.
AP Products Official Website: www.approducts.net

© 2025 AP Products. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B079CT1N51

More documents and user manuals: **https://manuals.plus/**