

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Skagen](#) /
- › [Skagen SKW6461 Analog Blue Dial Watch User Manual](#)

Skagen SKW6461

Skagen SKW6461 Analog Blue Dial Watch User Manual

Model: SKW6461

1. INTRODUCTION

Thank you for choosing the Skagen SKW6461 Analog Blue Dial Watch. This manual provides essential information for the proper setup, operation, maintenance, and care of your timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

The Skagen SKW6461 features a sophisticated blue sunray dial, two-hand movement, and a date window, all housed within a slim 38mm stainless steel case. Its design emphasizes both elegance and functionality, making it a versatile accessory.

2. SETUP AND INITIAL USE

2.1 Unboxing

Carefully remove the watch from its packaging. Inspect the watch for any protective films on the crystal or case back and remove them before use.



Image: The white Skagen watch packaging box, indicating the brand and origin.

2.2 Setting the Time

1. **Pull out the crown:** Gently pull the crown (the small knob on the side of the watch case) to its outermost position. For watches with a date function, there might be an intermediate position for setting the date.
2. **Rotate the crown:** Turn the crown clockwise or counter-clockwise to move the hour and minute hands to the correct time.
3. **Push in the crown:** Once the time is set, push the crown back into its original position against the watch case. This will start the watch movement.

2.3 Setting the Date (if applicable)

If your watch includes a date display, pull the crown out to the intermediate position. Rotate the crown to adjust the date. Once the correct date is displayed, push the crown back to the fully closed position.



Image: The Skagen SKW6461 watch, showcasing its blue dial, two-hand movement, and black stainless steel mesh strap.

2.4 Interchanging the Strap

The SKW6461 features a quick-release-pin construction, allowing for easy interchangeability of the 18mm watch strap. To change the strap, locate the small lever on the underside of the strap where it connects to the watch case. Slide the lever to release the pin, then gently remove the strap. To attach a new strap, align the pins with the lug holes and slide the lever to secure it.

3. OPERATING YOUR WATCH

Your Skagen SKW6461 watch is an analog timepiece powered by a quartz movement. Once the time is set, the watch will operate continuously until the battery requires replacement.

3.1 Timekeeping

The watch displays time using hour and minute hands. The smaller hand indicates the hour, and the longer hand indicates the minute. Some models may include a second hand.

3.2 Date Display

If your model includes a date window, it will automatically advance once every 24 hours. You may need to manually adjust the date at the end of months with fewer than 31 days (e.g., February, April, June, September, November).

4. CARE AND MAINTENANCE

4.1 Cleaning

To clean your watch, wipe the case and strap with a soft, damp cloth. For stainless steel mesh straps, a soft brush can be used to remove dirt from the links. Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish.

4.2 Water Resistance

Your Skagen SKW6461 watch has a water resistance depth of 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming, showering, or washing hands. **It is not suitable for diving, snorkeling, or prolonged water activities.** Always ensure the crown is fully pushed in before any contact with water. Water resistance is not a permanent condition and may diminish over time due to wear and tear or accidental impact.

4.3 Battery Replacement

The watch is powered by a Lithium Metal battery. When the watch stops running, it indicates that the battery needs to be replaced. Battery replacement should be performed by a qualified watch technician to ensure the water resistance seal is maintained and to prevent damage to the movement.

4.4 Storage

When not wearing your watch, store it in a cool, dry place, away from direct sunlight and extreme temperatures. The original watch box is ideal for storage.

5. TROUBLESHOOTING

- **Watch not running:**

Ensure the crown is fully pushed in. If it is, the battery may need replacement. Contact a qualified watch technician.

- **Time is incorrect:**

Reset the time as described in Section 2.2. If the time continues to be inaccurate, the watch may require servicing.

- **Moisture inside the dial:**

This indicates a breach in the water resistance. Immediately take the watch to a qualified service center. Avoid further contact with water. Even with 50-meter water resistance, exposure to steam (e.g., hot showers) or sudden temperature changes can compromise seals.

- **Strap discomfort or irritation:**

Ensure the strap is clean and dry. Adjust the strap for a comfortable fit, not too tight. If irritation persists, consult a dermatologist or consider changing the strap material.

6. SPECIFICATIONS

Feature	Detail
Model Number	SKW6461
Dial Color	Blue
Case Shape	Round
Dial Glass Material	Scratch Resistant Glass
Band Color	Black
Band Material	Stainless Steel
Watch Movement Type	Quartz
Watch Display Type	Analog
Case Material	Stainless Steel
Case Diameter	38 millimeters
Water Resistance Depth	50 meters (5 ATM)
Battery Type	1 Lithium Metal battery (included)
Product Dimensions	3.5 x 3.5 x 3.5 cm
Item Weight	67 g

7. WARRANTY INFORMATION

Your Skagen SKW6461 watch comes with a **2-year international warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear of the case, crystal, or strap.

To claim warranty service, please retain your proof of purchase and contact Skagen customer support or an authorized service center.

8. CUSTOMER SUPPORT

For further assistance, technical support, or warranty inquiries, please visit the official Skagen website or contact their customer service department. You can find contact details on the Skagen website or in the warranty booklet provided with your watch.

Online Resources: www.skagen.com

