Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LKPower 180125036

LKPower AC Adapter Instruction Manual

Model: 180125036

For Sennheiser HDR120 Wireless Headphone TR120 Cradle Base

1. Product Overview

The LKPower AC Adapter is a high-quality replacement power supply designed to meet the power requirements of your Sennheiser HDR120 Wireless Headphone TR120 Cradle Base. This adapter converts standard AC electrical power into the DC power necessary for operating your device or charging its battery. It features built-in over-voltage and over-heat protection to ensure safe and reliable operation.



Image 1.1: The LKPower AC Adapter, showing the main unit with integrated US plug, attached power cord, and DC output connector.

2. Package Contents

Please verify that all items are present in the package:

- 1 x LKPower AC Adapter (Model: 180125036)

3. Technical Specifications

Model Number	180125036
Input Voltage	AC 100-240V, 50/60Hz (Worldwide Auto Input)
Output Voltage	5 Volts (DC)
Wattage	5 Watts
Connector Type	AC Wall Power Charger (DC Barrel Connector)
Compatible Devices	Sennheiser HDR120, Sennheiser Wireless Headphone models, TR120 Cradle Base
Special Features	Over Voltage Protection, Over Heat Protection, Travel-friendly




Image 3.1: Physical dimensions of the LKPower AC Adapter, indicating a length of 2.6 inches, width of 1.6 inches, and thickness of 1.2 inches for the main body, with a cable length of 76 inches.

4. Setup Instructions

Follow these steps to properly set up your LKPower AC Adapter:

1. **Identify Your Device:** Ensure that your device is compatible with a 5V DC power input and that the connector type matches the adapter's DC barrel connector. This adapter is specifically designed for Sennheiser HDR120 Wireless Headphone TR120 Cradle Base.
2. **Connect to Device:** Carefully insert the DC output connector of the LKPower AC Adapter into the power input port of your Sennheiser HDR120 TR120 Cradle Base. Ensure a snug and secure connection.
3. **Plug into Power Outlet:** Insert the AC plug of the adapter into a standard wall electrical outlet (100-240V AC). The adapter is designed for worldwide use.
4. **Verify Power:** Once connected, your device should receive power or begin charging. Refer to your device's manual for indicators of successful power connection or charging status.



Image 4.1: The LKPower AC Adapter plugged into a power strip, demonstrating a typical setup for use in an office or home environment.

5. Operating Instructions

The LKPower AC Adapter operates automatically once connected to a power source and a compatible device. It

provides a stable 5V DC output to power or charge your Sennheiser HDR120 Wireless Headphone TR120 Cradle Base. No manual adjustments are required for voltage or current, as the adapter is designed to deliver the correct power output for compatible devices.

6. Maintenance and Care

To ensure the longevity and optimal performance of your AC adapter, follow these maintenance guidelines:

- **Keep Dry:** Avoid exposing the adapter to water, moisture, or high humidity.
- **Clean Gently:** Use a soft, dry cloth to clean the adapter. Do not use liquid cleaners or aerosols.
- **Avoid Physical Damage:** Do not drop, bend, or apply excessive force to the adapter or its cable.
- **Proper Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Unplug When Not in Use:** For energy conservation and safety, unplug the adapter from the wall outlet when it is not in use for extended periods.

7. Troubleshooting

If you encounter issues with your LKPower AC Adapter, please refer to the following common problems and solutions:

- **No Power to Device:**
  - Ensure the adapter is securely plugged into a working wall outlet.
  - Verify that the DC connector is firmly inserted into your device's power port.
  - Test the wall outlet with another known working appliance to confirm it has power.
  - Check the adapter cable for any visible damage or kinks.
- **Device Not Charging:**
  - Confirm that your device's battery is not fully charged.
  - Ensure the device itself is functioning correctly.
  - Verify that the adapter's output specifications (5V DC) match your device's requirements.
- **Adapter Overheating:**
  - While the adapter has over-heat protection, ensure it is used in a well-ventilated area and not covered.
  - If overheating persists, discontinue use and contact support.

If these steps do not resolve the issue, please contact customer support for further assistance.

8. Important Safety Information

Please read and follow these safety precautions to prevent injury or damage:

- **Indoor Use Only:** This adapter is designed for indoor use. Do not use it outdoors or in wet conditions.
- **Avoid Water:** Do not expose the adapter to rain, water, or excessive moisture.
- **Proper Voltage:** Only connect the adapter to power outlets within the specified input voltage range (AC 100-240V).
- **Ventilation:** Ensure adequate ventilation around the adapter during use. Do not cover it with cloth or other materials.
- **Children and Pets:** Keep the adapter and its cable out of reach of children and pets.

- **Disconnect Safely:** Always grasp the plug when disconnecting from the wall outlet; do not pull on the cord.
- **Damaged Adapter:** Do not use the adapter if the casing or cable is damaged.

9. Warranty and Support

For warranty information and customer support regarding your LKPower AC Adapter, please refer to the documentation provided at the time of purchase or contact the manufacturer directly. Ensure you have your model number (180125036) and purchase details available when seeking support.

© 2023 LKPower. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B079DPC1D1

More documents and user manuals: **https://manuals.plus/**