

VAXCEL T0387

VAXCEL Dorado Outdoor Wall Light with Motion Sensor

INSTRUCTION MANUAL FOR MODEL T0387

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your VAXCEL Dorado Outdoor Wall Light with Motion Sensor, Model T0387. This fixture is designed for outdoor use, offering enhanced security and convenience with its integrated motion sensor and dusk-to-dawn photocell.

Safety Information

- **WARNING:** Always turn off power at the circuit breaker before beginning installation or performing any maintenance.
- Consult a qualified electrician if you are unsure about the installation process.
- Ensure all wiring connections are secure and comply with local electrical codes.
- This product is designed for outdoor, hardwired installation.
- Do not exceed the maximum wattage specified for the bulb.
- Please check your local laws and building codes before installing this product.

What's in the Box

Carefully unpack the contents and ensure all items are present:


- Dorado Outdoor Wall Light Fixture
- Shade
- Mounting Hardware
- Instruction Manual

Specifications


Feature	Detail
Brand	VAXCEL
Model Number	T0387

Dimensions (L x W x H)	13.5" x 12" x 12.25"
Material	Alloy Steel, Glass Shade
Color	Dark Bronze and Light Gold
Power Source	Hardwired
Voltage	120 Volts
Bulb Base	E26 Medium
Max Wattage	60 Watts (Bulb not included)
Special Features	Motion Sensor, Dusk-to-Dawn Sensor, Dark Sky Compliant
Motion Sensor Detection Angle	180 degrees
Motion Sensor Detection Range	Up to 40 feet
Weather Resistance	Wet Rated, Water Resistant
Certifications	ETL Listed

For detailed dimensions, refer to the diagram below:



A: 12"
B: 12-1/4"
C: 13-1/2"



PRODUCT DIMENSIONS

Figure 1: Product dimensions for the VAXCEL Dorado Wall Light. A indicates the width of the shade, B indicates the overall height, and C indicates the projection from the wall.

Setup and Installation

Installation of the VAXCEL Dorado Wall Light requires hardwiring to an existing electrical circuit. It is recommended to have this installed by a qualified electrician.

1. **Prepare for Installation:** Turn off power at the main circuit breaker to the location where the fixture will be installed.
2. **Mounting Location:** This fixture is designed for wall mount installation. Ensure the mounting surface is structurally sound. Note that a standard electrical box may require a hole cut into the wall for flush mounting.
3. **Install Mounting Hardware:** Secure the provided mounting hardware to the electrical box in the wall.
4. **Wire Connections:** Connect the fixture's wires to your household wiring according to local electrical codes. Typically, this involves connecting the black wire (live) to the black wire, the white wire (neutral) to the white wire, and the ground wire to the ground wire. Use appropriate wire connectors.
5. **Attach Fixture:** Carefully align the fixture with the mounting hardware and secure it to the wall.
6. **Install Bulb:** Insert one E26 medium base bulb (not included) into the socket. Do not exceed 60 watts.
7. **Restore Power:** Once installation is complete and secure, restore power at the circuit breaker.



Figure 2: The VAXCEL Dorado Wall Light installed on an exterior wall, demonstrating its appearance.

Operating Instructions

The VAXCEL Dorado Wall Light features multiple operational modes for convenience and energy efficiency.

Key Features:

- **Motion Sensor:** Detects movement within a 180-degree angle and up to 40 feet, automatically turning the light on to full brightness.
- **Dusk-to-Dawn Photocell:** Automatically turns the light on at dusk and off at dawn, conserving energy during daylight hours.
- **Timer Function:** Allows selection of continuous bright light illumination for 0, 3, or 6 hours after dusk.
- **Dual-Level Brightness:** Features an adjustable low-level standby brightness (0-50%) that increases to 100% upon motion detection.

THREE LIGHTS IN ONE

1. MOTION SENSOR



2. DUSK TO DAWN



3. SWITCH CONTROLLED



MULTI
3-IN-1
FUNCTION

VARIABLE
LIGHT ACTIVATION
VIA
3 UNIQUE MODES

Figure 3: Overview of the three primary operational modes: Motion Sensor, Dusk-to-Dawn, and Switch Controlled.

Customizable Settings:

The fixture offers customizable settings to tailor its operation to your needs. These settings are typically adjusted via internal controls on the fixture itself, or in some models, through a remote control (if included).

- **Motion Shut-off Delay:** Adjust the duration the light stays on after motion is no longer detected (e.g., 5 seconds to 3 minutes).
- **Motion Sensitivity:** Adjust the detection range of the motion sensor (up to 40 feet).
- **Early Evening Timer:** Set the duration for continuous bright light after dusk (0, 3, or 6 hours) before switching to motion-activated mode or low-level standby.
- **Low-Level Standby Brightness:** Adjust the percentage of brightness (0-50%) for the standby mode when no motion is detected and the light is on after dusk.

FULLY CUSTOMIZABLE SETTINGS



CONVENIENT
CONTROL ACCESS

MOTION SHUT-OFF DELAY
5 sec - 3 min

MOTION SENSITIVITY
40 ft

EARLY EVENING TIMER
0, 3, 6 hrs

MODES of OPERATION
5 modes

PATENTED DUAL-LEVEL BRIGHTNESS

ADJUSTABLE
low-level brightness

up to
0-50%

LOW LEVEL
STAND-BY

100%

MOTION



HOW IT
DUALUX
WORKS

SECURITY OPTIONS
TO FIT YOUR
LIFESTYLE

Figure 4: Customizable settings for the VAXCEL Dorado light, allowing adjustment of motion detection and timing.

EXTRA SAFETY & SECURITY



Figure 5: Motion sensor detection range and angle, providing broad coverage for security.

Maintenance

Bulb Replacement:

Ensure power is turned off at the circuit breaker before replacing the bulb. Allow the bulb to cool completely before handling. This fixture uses one E26 medium base bulb, up to 60 watts.

Cleaning:

To clean the fixture, turn off power at the circuit breaker. Use a soft, damp cloth. Avoid abrasive cleaners or solvents, as they may damage the finish or electrical components. Periodically check for debris accumulation on the motion sensor and photocell to ensure optimal performance.

Troubleshooting

• Light does not turn on:

- Check if the power is on at the circuit breaker.
- Ensure the bulb is correctly installed and not burnt out.
- Verify that the dusk-to-dawn sensor is not obstructed by light or debris.

- Check motion sensor sensitivity settings.
- **Light stays on continuously:**
 - Ensure the motion sensor is not continuously detecting movement (e.g., from trees, traffic). Adjust sensitivity if necessary.
 - Check the timer settings; if set to 3 or 6 hours, the light will remain on for that duration after dusk.
 - Verify the dusk-to-dawn sensor is functioning correctly and not in a constantly dark environment.
- **Motion sensor is not detecting movement:**
 - Check the motion sensor sensitivity settings and increase if needed.
 - Ensure the sensor lens is clean and free from obstructions.
 - Confirm the sensor's detection range covers the desired area.
- **Features not responding as expected:**
 - Review the operating instructions carefully to ensure settings are correctly applied.
 - If the fixture has internal adjustment dials or buttons, ensure they are accessible and correctly manipulated.
 - Power cycling the fixture (turning off and on at the breaker) may reset its internal logic.



Warranty and Support

This VAXCEL product comes with a Limited Warranty. For specific details regarding the warranty period and coverage, please refer to the documentation included with your purchase or contact VAXCEL customer support.

For technical assistance, replacement parts, or further inquiries, please contact VAXCEL customer support through their official website or the contact information provided with your product.

© 2024 VAXCEL. All rights reserved.

Related Documents - T0387

	<p>Vaxcel T0599 Assembly and Installation Instructions</p> <p>Comprehensive assembly and installation guide for the Vaxcel T0599 outdoor motion sensor wall light. Includes features, operation modes, troubleshooting, and spare parts.</p>
	<p>Vaxcel T0694/T0695 Motion Activated Light Installation and Mounting Instructions</p> <p>This guide provides detailed instructions for installing and operating the Vaxcel T0694/T0695 motion activated outdoor light fixture. It covers important safety information, features, mounting options, sensor and light head adjustments, various operating modes, troubleshooting tips, and warranty details.</p>





[\[pdf\]](#) Warranty Borchure

VAX2021 Dualux Brochure Page by vaxcel 2021 01 |||

Enhance the beauty and safety of your home 2 DUALUX MULTI-LEVEL LIGHTING
Get style, convenience ... COLLECTION REF MODEL WIDTH HEIGHT DEPTH
BULBS FINISH GLASS DETAILS A T0385 10 W B T0388 12 W C **T0387** 12 W 13-3/4
H 12 D 1-60 M Outer: Oil Burnished Bronze Inner: Light Gold 12-1/4 H 13-1/2...
lang:en **score:24** filesize: 3.42 M page_count: 20 document date: 2021-01-12

[\[pdf\]](#) Instructions Specifications

356 4919 Assembly and Installation InstructionsVaxcel Dorado 12 1 Light Dark Bronze Gold Motion
Sensor Dus Lamps DepotT0387 INTcdn shopify s files 0686 3156 0499 T0387 INT v 1671765378
InstructionsInstallation SheetVaxcel DepotVaxcel Lighting Single 4 Tall Outdoor Wall Sconce Ferguson
Homevaxcel lighting t0387 installation sheetcdn 1671765378s1 img b build mediabase specifications
vaxcel 1440770 sheet InstructionsAssembly Silver Dusk to Dawn Farmhouse HomeT0388 INTvaxcel
1671765378cdn T0388 1671765846s1 light assembly Vaxcel vxl3879 T0387light vxl3880 T0388Assembly
T0387vxl3880 T0388Vaxcel sheetsecure img1 ag wfcdn dm document fcf35fd7 fe0c 4790 aae5
36441e74354f assemblysecure assemblycdn |||
**ASSEMBLY AND INSTALLATION T0387 / T0388 INSTRUCTIONS WARNING: TO
AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER
BEFORE INSTALLING OR SERVICING THIS FIXTURE. NOTES: 1. Before installing,
consult local electrical codes for wiring and grounding requirements. 2. Read and
save these instru...**
lang:en **score:20** filesize: 1.66 M page_count: 4 document date: 2018-01-18



[\[pdf\]](#) Dimension Guide Catalog

Vaxcel Catalog 2 18 x 0 75 Bronze Steel Ceiling Fan Downrod Extension Lamps Depot v 1658996884
cdn shopify s files 1 0555 9527 0317 |||
INDOOR MID CENTURY MODERN NUAGE Mid-century yet modern at the same
time, the Nuage semi- ush ceil ... rsatile collection, where light is the hero. T0367
OUTDOOR WALL DORADO ITEM NO T0367 T0368 T0369 **T0387** T0570 T0571
T0572 FINISH NAME Dark Bronze and Light Gold Dark Bronze and Light Gold Dark
Bron...
lang:en **score:20** filesize: 5.4 M page_count: 101 document date: 2022-07-28



[\[pdf\]](#) Dimension Guide Catalog

Vaxcel Catalog 3 18 x 0 75 Bronze Steel Ceiling Fan Downrod Extension Lamps Depot v 1658996884
cdn.shopify.com/files/1/0555/9527/0317/|||

OUTDOORS TRANSITIONAL NOTTINGHAM This updated traditional take in the Nottingham collection will ... 259 Delano Oil Burnished Bronze and Light Gold T0291 Delano Oil Burnished Bronze and Light Gold **T0387** Dorado Dark Bronze and Light Gold T0388 Dorado Satin Silver and White T0385 Franklin Oil ...

lang:en score:19 filesize: 8.47 M page_count: 141 document date: 2022-07-28



[\[pdf\]](#) Catalog

Vaxcel International Co Ltd Catalog 22 1 Page Created with Publitas 34863d1b 57f7 4bc9 8f87
ddc33398bb71 response content disposition attachment filename* UTF 8 view publitas 34360 1405469 s
|||

TABLE OF CONTENTS 01 WELCOME 04 NEW PRODUCTS 72 BEST SELLERS 94 INDOORS 296 CEILING FANS 346 ... rsatile collection, where light is the hero. T0367 OUTDOOR WALL DORADO ITEM NO T0367 T0368 T0369 **T0387** T0570 T0571 T0572 FINISH NAME Dark Bronze and Light Gold Dark Bronze and Light Gold Dark Bron...

lang:en score:16 filesize: 49.59 M page_count: 341 document date: 2022-01-04