



Manuals.plus /

› Funko /

› Funko Pop! Anime: One Piece - Tony Tony Chopper Vinyl Figure Instruction Manual

Funko Chopper9467

Funko Pop! Anime: One Piece - Tony Tony Chopper Vinyl Figure Instruction Manual

INTRODUCTION

This manual provides essential information for the proper handling, display, and care of your Funko Pop! Anime: One Piece - Tony Tony Chopper Vinyl Figure, bundled with a Pop Box Protector Case. Please read these instructions carefully to ensure the longevity and preservation of your collectible.

PRODUCT OVERVIEW

The Funko Pop! Tony Tony Chopper figure is a stylized vinyl collectible from the popular anime series One Piece. This product includes:

- One (1) Funko Pop! Tony Tony Chopper Vinyl Figure.
- One (1) Acid-free PET Plastic Pop Protector Case with peel-able protective film.



Image: The Funko Pop! Anime: One Piece - Tony Tony Chopper Vinyl Figure, showcasing its design and the included protector case.

SETUP AND ASSEMBLY

Your Funko Pop! figure comes with a protective case to help preserve its condition. Follow these steps to set up your figure:

1. Carefully remove the Funko Pop! figure from its original packaging.
2. Unfold the bundled plastic Pop Protector Case. The case features a push-lock tab designed to add structural integrity once formed.
3. Peel off the protective film from both sides of the Pop Protector Case to reveal its clear surface.
4. Gently place the Funko Pop! figure, still in its original box, inside the assembled Pop Protector Case. Ensure the case is fully formed and secured.
5. Position your protected figure on a stable, flat surface away from direct sunlight and extreme temperatures.

Your browser does not support the video tag.

Video: A closer look at the Funko Pop! figure and its components, demonstrating the unboxing process and the figure's features.

CARE AND MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to gently wipe dust from the figure and the protector case. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Display Environment:** Keep the figure away from direct sunlight, high humidity, and extreme temperatures to prevent discoloration or material degradation.
- **Handling:** Handle the figure by its base or body to avoid damaging delicate parts.
- **Protector Case:** The acid-free PET plastic protector case is designed for long-term preservation. Ensure it remains free of scratches or damage to maintain visibility and protection.

SPECIFICATIONS

Feature	Detail
Brand	Funko
Model Number	Chopper9467
ASIN	B079F6WFMM
Item Weight	7.2 ounces
Package Dimensions	6.57 x 4.76 x 3.7 inches
Material	Vinyl Figure, PET Plastic Protector Case

TROUBLESHOOTING

- **Dust Accumulation:** If dust collects on the figure or inside the protector, carefully remove the figure and use a soft, dry brush or compressed air to clean.
- **Discoloration:** Exposure to direct sunlight or strong artificial light can cause colors to fade over time. Ensure the figure is displayed in a shaded area.
- **Protector Case Damage:** If the protector case becomes scratched or damaged, it can be replaced to maintain the figure's aesthetic and protection.

WARRANTY AND SUPPORT

For information regarding product warranty or support, please refer to the official Funko website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

IMPORTANT SAFETY INFORMATION

This product is a collectible item and not intended as a toy. It may contain small parts that could pose a choking hazard to young children. Please keep out of reach of children under 3 years of age.