Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dyson AM09

Dyson Replacement Remote Control User Manual

Model: AM09 Fan Heater Remote (Part No. 966538-01)

Introduction

This manual provides essential information for the proper use and care of your Dyson Replacement Remote Control, specifically designed for the Dyson AM09 Fan Heater. This remote control serves as a direct replacement for lost or broken original units, ensuring full functionality of your fan heater.



Image: Front view of the white Dyson AM09 Replacement Remote Control. It features a sleek, elongated design with clearly labeled buttons for power, fan speed, heating/cooling mode, oscillation, and timer functions.

Setup and First Use

The Dyson Replacement Remote Control (Part No. 966538-01) is pre-paired with compatible Dyson AM09 Fan Heater models and typically requires no additional setup. It is designed to work immediately out of the packaging.

Battery Installation/Check

The remote control requires 1 Lithium Ion battery. While often pre-installed, if the remote does not respond, check or replace the battery.

1. Locate the battery compartment on the back of the remote control.
2. Using a #1 Phillips head screwdriver, carefully open the battery compartment.
3. Insert or replace the Lithium Ion battery, ensuring correct polarity.
4. Securely close the battery compartment.



Image: Angled view of the white Dyson AM09 Replacement Remote Control, highlighting its ergonomic design. The magnetic base allows it to be stored securely on the Dyson fan heater unit.

Operating Instructions

This remote control provides full command over your Dyson AM09 Fan Heater's functions.

Remote Control Button Functions

Button Icon	Function	Description
(Power)	Power On/Off	Turns the Dyson AM09 Fan Heater on or off.
● (Blue)	Cooling Mode	Activates the fan's cooling function.
● (Red)	Heating Mode	Activates the fan's heating function.
○ (Large Circle)	Increase Fan Speed	Increases the airflow speed.
○ (Small Circle)	Decrease Fan Speed	Decreases the airflow speed.
(Timer)	Timer Function	Sets the fan heater to turn off automatically after a set period.
▲▼ (Up/Down Arrows)	Temperature Adjustment	Adjusts the target temperature in heating mode.
▼ (Inverted Triangle)	Airflow Direction (Vertical)	Adjusts the vertical tilt of the airflow.
● (Fan Icon)	Oscillation	Activates or deactivates the oscillation feature for wider air distribution.

Note: The remote control is designed to magnetically attach to the top of your Dyson AM09 Fan Heater for convenient storage and to minimize the risk of misplacement.

Maintenance

To ensure the longevity and optimal performance of your remote control, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these can damage the surface and button markings.
- **Battery Replacement:** Replace the Lithium Ion battery when the remote's responsiveness decreases or it stops functioning. Refer to the "Battery Installation/Check" section for instructions.
- **Storage:** When not in use, store the remote control in a dry place, ideally magnetically attached to your Dyson AM09 Fan Heater to prevent loss.
- **Avoid Moisture:** Do not expose the remote control to water or excessive humidity. Accidental exposure to liquids can cause permanent damage.

Troubleshooting

If you experience issues with your Dyson Replacement Remote Control, consider the following troubleshooting steps:

- **Remote Not Responding:**
  - Check the battery. Replace it with a new Lithium Ion battery if necessary.
  - Ensure there are no obstructions between the remote control and the Dyson AM09 Fan Heater's infrared receiver.
  - Confirm you are pointing the remote directly at the fan heater.
- **Limited Functionality:**
  - Verify that the remote control is indeed the correct model (Part No. 966538-01) for your Dyson AM09 Fan Heater. This remote is specifically designed for the AM09 model.

- Ensure the fan heater itself is powered on and functioning correctly.

If problems persist after attempting these steps, contact Dyson customer support for further assistance.

Specifications

Feature	Detail
Brand	Dyson
Model Compatibility	Dyson AM09 Fan Heater
Part Number	966538-01
Color	White
Power Source	1 Lithium Ion battery (required)
Item Weight	0.882 ounces
Package Dimensions	4.3 x 3.5 x 0.3 inches
Special Feature	Ergonomic design, Magnetic attachment to fan heater

Warranty and Support

Information regarding specific warranty terms for this replacement remote control is not provided in the product details. For warranty claims, technical support, or further inquiries, please refer to the official Dyson website or contact Dyson customer service directly.
You can typically find support contact information on the Dyson official website:www.dyson.com

© 2024 Dyson. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B079FJ5LMQ

More documents and user manuals: **https://manuals.plus/**